



6 Home

Back

6 Flash

Rear Camera

Fingerprint

SIM Card Installation

A SIM card contains your phone number and other necessary data. Your device has one SIM slot supports 4G(LTE).

To Install the SIM Card

 Make sure the device is turned off and the front facing down. Hold the firmly and use the notch at the bottom corner to loosen the cover. Use material with a hard, thin edge such as your fingernal or a credit carefully un along the seam to lossen, then lift the cover until it detaches completely.





Locate the SIM card slot and insert the proper SIM card into the proper slot. For more information on SIM card installation, check out the included SIM Card & Micro SD Card Installation Guide.

3. To turn on/off a SIM, card go to Settings > SIM management, then slide the SIM card sliders. To turn on/off a SIM card? 3 data connection, go to Settings > SIM management, click on the "Data connection" option, and select a SIM card that has 4G capability.

Keys/Touch Points

Power Key: To power on/off it, press and hold power key for a few seconds, when it is ON, press the power key once to activate or deactivate the screen.

Home key (O): Touch the key to return to the home screen. In idle screen, touch and hold the key to view recently opened

Options key(D): In home screen , touch the key to set wallpaper, manage apps, and to access system settings. Touch it to view menu options.

Back key (): Touch to go back to the previous menu.

New batteries are shipped partially charged. Before using your device, install and charge the battery. Batteries perform best after several full charge / discharge cycles.

Please charge the battery using the following methods:

1. Charge the phone by connecting it to a computer via the USB

capie.

2. Connect the USB cable to the phone and the AC adapter. Plug the AC adapter into an electrical outlet to start charging.



Do not remove the battery while the device is charging,
 Use only the AC adapter & USB cable provided with your device.

Note: For safely, the battery will stop charaing if in danger of overheating

Sleep Mode

- Turn on sleep mode to save your hattery nower

Audio Profile/Sleep Mode

From the home screen, swipe up to open APP Drawer & select

"Settings", Go to "Sound" and change the audio settings by Changing Sound levels and change your ring tones.

Sound & Utramer

3. Select "Sleep" and choose a time interval from the list.

1. On the home screen, touch the "APP Menu" & select "Settings".
2. Select "Securify and location " then select "Screen lock".
3. Select the desired type of lock & follow the prompts to set up.

Phone Features

Description Icons

Icons Descriptions ons Descriptions Speaker has been activated. You have unread SMS. Call on hold USB storage Turned on. $\mathbf{0}$ e ringing type is Right Mode 4G network in use 3G network in use. You have missed calls A clock olarm is active. In call Bluetooth ON

Main Menu & Its Functions

Select to enter the main menu...

Allow you to view a list of features available in your phone

Clock
 Allow you to set the Alarm from Clock.

- Prowser
 Browse the internet. Search engine-default set as Google.
 Calculator
 Allow you to make tedious calculations quickly.

Allows you set up your POP/IMAP email accounts

- View the calendar & add events.

5. Camera Alowyou to click pictures anylime you want. Your ASTRO 6T has a 8. MP High Definition camera with LED Flash supporting many special feature like Face Detection which ensures you to take good qualify of picture and stores them in the Gallety. In Camera, easily choose Camcarde

To see your list of Contacts. Access your digital phonebook through this

Gallery
Gallery is a light, fast and easy to use offline gallery
Google Play

Phone Features

Google Play is your entertainment unbound. It brings together all of the entertainment you love and helps you explore it in new ways, anytime, anywhere.

To use this app please connect to an internet connection

10. Messaging Allow you to view messages sent & received as a thread 1. YouTube Music

The music streaming app. Made by YouTube. Discover all the music on YouTube that you can't find anywhere else, organized in one new app and web player.



Allow you to make phone calls

He wanager
 You could browse, view, modify and install your files.

This service is provided by the operator. It provides phone plan

15. Sound Recorder Allows you to record sounds.

16. Videos View from list of videos.

maxwest

ASTRO 6T

Phone calls/Texting WLAN

To Make Phone Calls



Composing text messages Maxwest automatically corrects and suggests words as you



Cut, Copy and Paste Touch and hold text content to bring up the magnifying glass, and then slide your finger to move the insertion points. Then choose to cut, copy, or paste. It is very easy to copy text from web pages, email, or text messages.

Turn on WLAN

Maxwest supports WLAN Direct which allows Android™ 14(Go edition) or later devices with the appropriate hardware to connect directly to each other via Wi-Fi without an intermediate access point. Using the APIs, you can discove and connect to other devices, if each devices, if each device supports Wi-Fi Direct, then communicate over a speedy connection across distances much longer than a Bluetooth connection. This is useful for applications that share data among users, such as a multiplayer game or file sharing




a. Enter "Settings" >> Click "NETWORKS & Internet ">> Select "WHE!" >> Select "WHE!" >> Select "Advanced ">> Then click "WHE internet ">> Select "Advanced ">> Then click "WHE direct " to access WHE direct feature. b. After click "Search" at the bottom and it will display the c. Click "DIRECT-f2-HP M427 LaserJet" (in this case specifically) and

d. Click "Connect" to connect and it will not up an interface to



e. Click "OK" and the devices will be connected

Capture images or record videos and share with family and



cameara



Loa into your e-mail accounts.

You may log-in to your e-mail accounts from the phone to

Connecting to E-mails

occess your e-mails.

From the Home screen select Application "Gmail Go" and then Entergour email address, password and top. "Next".

Select which type of email account you are setting up and enter the proper settings. (POP3 / IMAP / Microsoft Exchange Account)

You will need to enter your user name, password, and server information depending on the type of emoil account or you can change the settings by tapping "Manual setup" at the top right corner screen. Tap "Next" and select "OK" to

Acres 18

4 [1]

175-mm

Steman I N Internet

SE STORAGE SHOP 1

Compose new:

1. Press MENU& select "Compose" 2. Add recipients by typing a name or email address in the "To" field. Matching contacts will appear. Select a recipient or continue typing in the email address to send to multiple

contacts.
3. Once finished typing the mail, elect "Send", "Save as draft", or "Discard".
4. The reply tab contains "Reply", Reply all " and "Forward" options.

Delete message:

Go to Inbox to display messages.
 Touch & hold the message you want to delete.
 Select "Delete",

File Transfer

Connecting Smartphone to PC Connect the USB cable to your smartphone and computer. Once connected successfully, on your phone, slide the top menu down and click on "Android System", then, press "Transfer Files."

A new storage named ASTRO 6T will appear on your PC file My Computer * . Click on it to review files in the smartphone and or to transfer documents between devices. When finished, press

Disconnect device from PC .

Note: Photos taken with the camera will be saved under the "DCIM" folder. Screenthots captured will be saved under "Pictures" folder. Put Musicfiles in the "Music" folder for the files to be played properly.



Screen Capture

Press Volume(-) and power button at the same time to conture shot". All captured screenshot will be saved under gallen



Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the PCC Rules. Operation is subject to the following two conditions: [1] this device may not couse interference [2] this device must accept any interference, including interference that may cause undesired operation of the device.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC or a class B digital device, pursuant to part 15 of the FCC or a class the part of the p and, if not installed and used in accordance with the instructions, my cause harmful interference to radio communications. However, there is no guarantee to this interference will not occur in a interference to radio or television reception, which can be determined by turning the equipment of fan don, the user is encouraged to ty to carred the interference by one more of the fallowing measures.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet an a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

■ SAR tests are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenance, the lover the power output.

Before a new device is a available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each device are performed in positions and locations as required by the FCC.

■ For body worn operation, this device has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positio ns the handset a minimum of 10mm from the body.

Non-compliance with the above restrictions may result in violation of RF exposure guidelines.

