
USER MANUAL




What's in the box?

- 1. Speaker*1
- 2. User manual*1
- 3. Type-C cable*1

MADE IN CHINA FCC ID: 2BCGV0023

Overview

- 1. Flashlight
- 2. Flashlight button
- 3. Next track/ Vol+/ Channel
- 4. Microphone
- Power ON/OFF/Auto search FM/ Play /Pause/Answer/End call
- 6. Previous track / Vol -/ Channel
- 7. Mode
- 8. USB port
- 9. TF slot
- 10.Type-C port
- 11.LED Indicator
- 12.Lamp
- 13.Strip with carabiner



Specifications:

- 1. Item: 25267
- 2. Model: CT02117
- 3. Input: DC 5V/400mA
- 4. Speaker output power: 5W
- 5. Battery capacity: 3.7V/1200mAh, 4.44Wh

Operation Instructions

- 1. **Power On:** Long press the power button to turn on the speaker, you will hear a tone.
- Pairing: Once speaker is turned on, open your mobile device, search the wireless devices, and select wireless ID '25267', It will pair automatically.
- 3. Play/Pause/ Answer/End/Redial call: Short press the button to play or pause the music in paly music mode. When call is incoming, short press the button to answer the call, short press again to end call, double press the button to redial the number you last called.
- 4. **Next track/Vol+:** Short press to next track, long press to increase volume
- Previous track/Vol -: Short press to last track, long press to decrease volume
 Switch Bluetooth, FM. TF and USB disc (If
- Switch Bluetooth, FM, TF and USB disc (If ready) mode: Short press the mode button
- FM mode: Plug the Type-C cable into Type-C input port, tap the mode button to enter FM mode, short press auto search FM button to

50_{mm}

search channel, after the search stop automatically or press the button again to end search, short press the next track and previous track to switch channel.

- USB play: Plug the USB disc into USB port, it will automatically play the music.
- TF card play: Plug the TF card into TF slot, it will automatically play the music.
- 10.Charging: Use the Type-C cable included to connect the speaker to a computer or adaptor, the LED indicator will illuminate a solid red. When the speaker is fully charged, the red LED will be turned off.
- 11. Power Off: Long press the power button to turn off the speaker.
- 12.**Flashlight:** Tap the flashlight button to turn on/off the flashlight.

Caution

- Please enjoy music with an appropriate volume, which will avoid to damage your hearing and sound system.
- Please avoid exposure, rain, water droplets, avoid prolonged exposure to high temperature, high humidity environment.
- During use, please make it away from heat, high pressure, and prevent children from playing with this product.
- Please use the power which meets the requirements.

Do not drop or bump and applied heavy pressure to avoid damage to the product.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1)This device may not cause harmful interference, and
- (2)This device must accept any interference received, including interference that may cause undesired operation.

Warning: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful

interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio /TV technician for help.

RF Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by (Shenzhen SHD Electronic Tech. Co., Ltd.) is under license. Other trademarks and trade names are those of their respective owners.

Bluetooth Listing Declaration ID: D063501