

名创国际部 漫威蓝牙音箱A25说明书 材质:128G双铜+风琴折 尺寸:550\*97MM

MINISO

PRODUCT MANUAL

使用說明書

MARVEL WIRELESS SPEAKER

漫威-長條藍牙音箱

MODEL: A25

使用產品前請仔細閱讀本使用說明書，並請妥善保管。  
PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE  
PRODUCT AND KEEP IT IN A SAFE PLACE.

尊敬的客戶


感謝您購買本公司音箱產品  
為了您能儘快熟悉操作本機，我們隨機配備了內容詳盡的使用者手冊，從中您可以獲取有關產品的介紹，使用方法，系統設置以及使用注意事項等內容，在您使用本產品前，請務必仔細閱讀本手冊及所有資料，這有助於您更好的使用本產品。

在編寫手冊時我們非常細心嚴謹，並認為本手冊所有提供的資訊是正確可靠的，倘若有疏漏之處，請多包涵並熱切指正；如果您使用產品過程中發現什麼問題，請及時與我們聯繫，謝謝您的合作。

注意事項

電池（電池包或組合電池）不得暴露在諸如日照、火烤或類似過熱環境中，如果電池更換不當會有爆炸危，只能用同樣類型或等效類型的電池來更換

產品指示圖



產品參數

1.1 整機規格

序號	項目	規 格	備 注
L	L(長)	40cm	
W	W(寬)	6.5cm	
H	H(厚)	6cm	

1.2 防水等級

無防水

1.3 基本功能

支援藍牙連接播放；  
支援TF卡連接播放；  
支援U盤連接播放；  
支援 AUX LINE IN連接播放

2. 產品參數

無線方案	Jieli AC6925A	待機時長	85小時
版本	BT V5.0	充電時長	3小時
特性	A2DP,AVRCP,HFP,HSP	燈光	紅/藍燈
傳輸距離	10M	電池容量	3.7V 1200毫安时
播放時長	3~5小時	配對密碼	N/A
通話時長	12~15小時	配對名	MINISO-A25

序號	功能	狀態	動作	聲音提示
1	開機	開機時	打開撥動開關	有語音提示
2	接聽	來電時	按一下播放/暫停鍵	無
3	掛機	通話時	按一下播放/暫停鍵	無
4	重撥最後撥出號碼	待機/音樂時	按兩下播放/暫停鍵	無
5	拒聽來電	來電時	長按播放/暫停鍵3秒	有提示音
6	音量加	通話/音樂時	短按“下一曲/音量加”鍵	最大音量提示音
7	音量減	通話/音樂時	短按“上一曲/音量減”鍵	無
8	播放/暫停	待機/音樂時	按一下播放/暫停鍵	無
9	上一曲	播放音樂時	長按“上一曲/音量減”鍵	無
10	下一曲	播放音樂時	長按“下一曲/音量加”鍵	無
11	關機	待機/音樂時	關閉撥動開關	無
12	模式切換	待機/音樂時	短按MODE鍵	
13	藍牙配對強制退出	待機/音樂時	長按播放/暫停鍵	

產品清單

藍牙音箱\*1 使用說明書\*1 充電線\*1

功能操作介紹

- 功能切換鍵：短按切換到藍牙、TF卡、USB、LINE IN，其中一種模式。
- 上一曲/音量減：長按選擇上一曲/短按可逐級遞減音量。
- 播放/暫停/接聽/電話/回撥：短按播放或暫停音樂，來電短按接聽電話，長按拒接，快速按兩下兩次回拔電話給最近一次通話連絡人。
- 下一曲/音量加/：長按選擇下一曲/短按可逐級增加音量。
- 藍牙指示燈：藍牙模式下藍燈閃爍，藍牙連接後藍燈常亮，其它模式下藍燈常亮。
- 麥克風孔：藍牙狀態下與手機連接後可進行通話。
- 電源開關：拔動開關機。
- AUX介面：可插入直徑3.5mm立體頭的音訊線外接音源。
- USB介面：可外接USB設備，播放裡面的音訊檔。
- TF卡介面：可插入TF卡播放卡裡面的音訊檔。
- DC 5V：插入充電介面並接通電源可對機器進行充電。
- 充電指示燈：插入電源線紅燈亮，充滿電時燈熄滅。

故障排除

**音量太小了，怎麼解決：**  
按機器上的音量加或減功能按鍵，如聲音還是小請把手機也調到最大音量。

**多久可以把電充滿？**  
3小時左右，（充滿後紅色指示燈會熄滅）

**藍牙播放歌斷斷續續的怎麼辦？**  
有可能電量不足、需要充電，或者超出使用範圍，避免靠近無線路由器等干擾源

**藍牙連接不上怎麼辦？**  
一.保證音箱電量足夠；二.打開手機的藍牙功能且靠近音箱；三.機器開機後藍牙打開，在手機上找到MINISO-A25 點配對連接即可

Dear customer


Thank you for purchasing MINISO speaker. In order for you to get familiar with the operation machine as soon as possible, we provided the detailed user manual, from which you can read about the product introduction, usage, system settings and cautions. Before using this product, please read this manual, as it may help you better understand this product.

We were very careful in the preparation of this manual, and we believe that all the information provided in this manual is correct and reliable. If there are any omissions, please kindly forgive and correct. If you find any problems during use of the product, please contact us in time.

Caution

Keep the battery (battery pack or assembled battery) away from direct sunlight, fire and high temperature. There is a risk of explosion if the battery is not replaced properly, only replace it with the same type or equivalent type of battery.

Product Layout



Product Parameter

1.1 Specification

Item	Specification	Remark
L	40cm	
W	6.5cm	
H	6cm	

1.2 Waterproofing grade

Not waterproof product.

1.3 Function

Support BT connection  
Support TF card play  
Support USB play  
Support AUX line in play

2. Specifications

BT solution	Jieli AC6925A	Standby (connected)	85H
BT version	V5.0	Charging time	3H
BT feature	A2DP,AVRCP,HFP,HSP	Led	Red/blue
Effective distance	10M	Battery	3.7V 1200mAh
Playing time	3H~5H	Pairing code	N/A
Dialog time	12H~15H	Pairing name	MINISO-A25

3. Button Instruction

Item	Status	Operation	Audio prompt
Power on	Power off	Turn on the switch	Audio prompt
Answer	Phone call in	Press "play/pause" button	
Hang up	Dialog	Press "play/pause" button	3.7V 1200mAh
Last call recall	Standby/playing	Double press the "play/pause" button	
Refuse	Phone call in	Long press the "play/pause" button for 3s	Prompt tone
Volume+	Dialog/playing	Short press the "volume +"	Maximum volume prompt
Volume-	Dialog/playing	Short press the "volume -"	
Play/pause	Standby/playing	Press "play/pause" button	
Previous	Music playing	Long press the "volume -"	
Next	Music playing	Long press the "volume +"	
Power off	Standby/playing	Turn on the switch	
Mode switch	Standby/playing	Short press the "MODE" button	Prompt tone
Force Bluetooth disconnection	Standby/playing	Long press the play/pause button	Prompt tone

Packing list

Wireless Speaker\*1 User manual\*1 Charging line\*1

Function introduction

- Mode switch: short press to transfer among BLT, TF card, USB mode;
- Previous track/volume -: long press for the previous track, short press to decrease the volume;
- Next track/volume +: slong press for the next track, short press to increase the volume;
- Play/pause/answer/call/recall: short press to play, press again to pause the track, short press to answer, long press to reject, double press to recall the last dialog;
- BT indicator: the blue indicator flashes in BT mode, keeps on lighting in connection or other mode;
- Microphone: in BT mode, it can be used to dialog after connected with phone;
- Power: switch it to turn on or off the product;
- AUX: applicable with Φ3.5mm AUX;
- USB: connect with USB devices to play the audio file;
- TF card: insert TF card to play the audio file;
- DC 5V: connect the charging port with the power can charge the product;
- Charging indicator: the red indicator lights up while charging, fades out when fully charged.

Trouble shooting

**Low voice**  
Press the volume button to adjust the volume, if it doesn't work, adjust the volume of your phone.  
**Charging time**  
Around 3 hours. (The red indicator will fade out when fully charged)

**Discontinuous of the voice**  
Low battery level, or the speaker is out of range of BT signal.

**Fail BT connection**  
Check the battery level; 2. Turn on the BT function and close it to the speaker; 3. Find MINISO-A25 on your phone and connect with it.

FCC information:  
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) this device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation.  
Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
— Reorient or relocate the receiving antenna.  
— Increase the separation between the equipment and receiver.  
— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
— Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:  
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.