

蓝悦F9(亚马逊 六人行)说明书第二版

材质:128g双铜+风琴折 四色印刷

展开尺寸:260x86mm 折后尺寸:65x86mm

料号: Y.047.0997





\oplus	Short press to increase the volume
	Long press to next a song
	Short press to reduce the volume
\bigcirc	Long press to previous a song
	Short press to pause music / answer / end call
(Þ)	Long press to disconnect wireless
_	Double click to call back the last call
(i)	Long press to turn on / off
(1)	Short press to switch playback mode
0	Short press to TWS pairing
	Long press to disconnect TWS
(a)	Click to switch light mode
(1)	Long Press to turn off lights


Specifications

0

6

•			
	Device Name	F9	
	Wireless Version	V5.1	
	Wireless Range	30ft	
	TWS Range	10ft	
	TF-Card Max Capacity	32GB	
	True Wireless Pairing	Yes	
	Charging Voltage	DC-5V/1A	
	Compatible Protocl	A2DP/AVRCP/HFP/HSP	






- ▶ Alexa Connection
- 1. Disconnect wireless speaker with all device.

0

- 2. Put your wireless device in pairing mode.
- 3. Open the Alexa app, click the 'Settings'.
- 4. Click the 'xx's Echo Dot.
- 5. Click the 'Wireless'.
- 6. Click the 'F9' to pair the speaker.

>> TWS Wireless Pairing

- 1.Turn on two F9 speakers.
- 2. Disconnect all devices with F9.
- 3. Short press the TWS button " □ "on the one of speakers



4. TWS pairing will auto finish after "beep". 5. Click the device name "F9" to pair on.



- After using TWS for the first time, TWS wireless pairing will be automatically connected after the two speakers are turned on.
- After TWS wireless pairing ,two speakers will mutual wireless synchronization.
- When one of the speakers is playing, the other speaker will also TWS automatically when it is turned on.

>> Warm Note:

Thank you for choosing us! Every order will enjoy following after-sale policy:

30 Days refund.

180 Days worry-free warranty. Lifetime technical support.

Share advise for product and design, you will get 365 Days Extended Warranty, contact us to collect it.

Use Tips:

- · Full charge for first use
- · Disconnect all devices for Alexa Pairing

Maintenance: After contacting the water source, please wipe / shake off the water stains in time to prolong the service life of the speaker.

>> Customer Support:



support@lenrue.com

▶ FCC STATEMENT

NOTE: This equipment has been tested and found to comply NOTE: In sequipment has been tested and found to comply with the limits for a class 8 digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part

15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may ause undesired operation.

0