

**Instruction Manual, 1 Sheet Folded -
Printed Front & Back
OUTSIDE**

**! FOR PRODUCTION PLEASE UPDATE
FCC ID # FOR CUSTOMER FIVE BELOW**

FRONT

Instruction Manual
Wireless Keyboard

1 Wireless Keyboard 12.77in. x 1 in. x 5.54 in.
(32.43 cm 2.54 cm x 14.07 cm), 1 User Manual

SPECIFICATIONS

- Contact bounce: $\leq 10\text{ms}$
- Operation Voltage: 1.5V
- Operation Current $\leq 5\text{mA}$
- Operation Force: 55 \pm 7g
- Storage Temperature: -10 \sim 70 $^{\circ}\text{C}$
- Total Travel: 3 \pm 0.5mm
- Battery Requirement: 1 x AA 1.5V (Not Included)

OPERATING INSTRUCTIONS:

1. Insert USB into computer or mobile phone (compatible with keyboard function)
2. Put 1 AA battery into the battery box on the back (not included), put it near the USB connector, and then turn on the keyboard switch to the "ON" position, the light flashes, and then the light is turned off after the pairing is successful.
3. If the pairing fails, press and hold the Esc+Q button combination for 2 seconds to force the code alignment. After the code light blinks, the connection can be used.

NOTES

- While connected, the keyboard will enter standby mode without any operation, and after 10 minutes without operation it will enter the Deep Sleep Mode - Press any key to wake it up immediately.
- While not connected, keyboard will enter Deep Sleep Mode in 10 minutes - Press any key to wake it up.
- "Ctrl" shortcut key for Windows,
"⌘" shortcut key for macOS

PrimeConnect™

Instruction Manual

Wireless Star Keyboard



Windows		Apple MAC	
Button	Function	Button	Function
FN+F1	Volume	FN+F1	Volume
FN+F2	Mute	FN+F2	Volume
FN+F3	Volume+	FN+F3	Volume+
FN+F4	Mute	FN+F4	Mute
FN+F5	Previous song	FN+F5	Previous song
FN+F6	Next song	FN+F6	Next song
FN+F7	Play/Pause	FN+F7	Play/Pause
FN+F8	Stop	FN+F8	/
FN+F9	Homepage	FN+F9	/
FN+F10	Email	FN+F10	/
FN+F11	My computer	FN+F11	Homepage
F12	Favorite	Fn+Esc	Brightness

BACK



Keyboard: FCC ID: 2BFXU-KYB001
Dongle: FCC ID: 2BFXU-KYB001D

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

© 2025 PRIMECONNECT 240 W. 37TH ST. NEW YORK, NY 10018
The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by iWorld is under license. All other trademarks and trade names are those of their respective owners. Actual product may differ slightly from image shown. MADE IN CHINA

CAUTION

- This is not a toy. Please keep away from small children.
- Please keep the unit away from water and heat.
- This unit is for indoor use only.
- Do not operate this unit with a damaged plug.

TECHNICAL SUPPORT

TECHNICAL SUPPORT
Please do not attempt to fix the product yourself. If you are experiencing any problems with the product please do not return it to the store you bought it from. You can contact our technical support representatives and they will assist you with any questions you may have. For assistance operating your product, please consult the User's Manual or feel free to contact iWorld technical support:

PRIMECONNECT
240 W. 37 TH ST. NEW YORK,
NY 10018, USA

www.iworldnyc.com
email: support@iworldnyc.com
Please keep instructions for further reference.

⚠ WARNING: TO AVOID BATTERY LEAKAGE

- 1) Be sure to insert the battery correctly, and always follow the toy/game and battery manufacturers' instructions.
- 2) Always remove a weak or dead battery from the product.
- 3) Remove the battery if the product is left unused for a long period of time.