


## Playing manual

### 1 Batteries installation:

#### (Transmitter):

1. Unscrew and remove the battery cover on controller.
2. Places 3x AAA with polarity as shown into the compartment
3. Replace the battery covers and tighten the screws

### 2 Operating



1. Press the left and right forward buttons together to make the car moves forward.
2. Press the left and right backward buttons together to make the car moves backward.
3. Press together left forward and right backward button will make the car forward rotates in anti-clockwise.
4. Press together right forward and left backward button will make the car rotates in clockwise.
5. Press only the single left forward or right forward will make the car turns left or right from forward.
6. Press only the single left backward or right backward will make the car turns left or right from backward.

**FCC NOTE:**

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

**FCC Warning Statement for FCC ID Label Requirements:**

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.

OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.