
















成品尺寸：70x100mm

80g书纸

单色印刷

风琴折

<div><div>HEAR BETTER SOUNDS</div><div>sanag M15 便携式蓝牙音箱</div><div></div><div>使用指南 Operating guide</div></div>	<div><div>● 包装清单</div><div><div>音箱×1</div><div>说明书×1</div><div>Type-C充电线×1</div><div>保修卡×1</div></div></div>	<div><div>● 产品概述</div><div></div><div><div>● 按键功能操作</div><div><div>⏻ 开机（长按1S）/ 关机（长按3S） 播放 / 暂停 / 接听 / 挂断（单击） FM模式频道搜索（单击） 启动手机语音助手（不打开APP状态下 双击）</div><div>⏮ 上一曲（长按）/ 减音量（短按） ⏭ 下一曲（长按）/ 加音量（短按）</div><div>🌟 拒接（长按2S） 切换蓝牙 / FM模式（长按3S） 灯光模式切换 / 打开和关闭灯效（双击） 复位（开机状态下 长按8S）</div><div>⏮ ⏭ 清除配对（开机状态下 长按“音量+”8S）</div></div></div></div>	<div><div>● 蓝牙操作</div><div><div>● 蓝牙连接成功： 1.音箱进入蓝牙模式，手机搜索蓝牙配对名“sanag M15”，点击连接即可。 2.音箱默认回连上一次设备。</div><div>● 蓝牙断开： 1.手动关闭手机蓝牙端，音箱进入蓝牙配对模式。 2.音箱与手机超距后断开，5分钟内回到有效距离范围，能正常回连手机，超过5分钟会自动关机。</div></div><div><div>搜索音箱</div><div>连接成功</div></div></div>	<div><div>● 规格参数</div><div><div>● 名称：便携式蓝牙音箱</div><div>● 型号：sanag M15</div><div>● 蓝牙版本：V5.3</div><div>● 连接范围：≥10m</div><div>● 电池容量：1200mAh</div><div>● 输入：5V 1A</div></div><div><div>● 注意事项</div><div><div>● 切勿使用具有磨蚀性的清洁剂清理本产品。</div><div>● 切勿让本产品加热或靠近火源，如煮食炉。</div><div>● 切勿让本产品长时间受阳光直接照射。</div><div>● 切勿将本产品弃置于火中，避免发生爆炸。</div><div>● 切勿尝试拆开本产品作出任何修改，因为它并不包含任何维修组件。</div><div>● 切勿在雨中使用本产品。</div><div>● 如果长时期内不打算使用本产品，请您将它储存在干燥的环境中，并每月至少为耳机充电一次以延长寿命，避免极端的温度和灰尘。</div></div></div></div>
<div><div>● Packing list</div><div><div>Speaker×1</div><div>Instruction manual×1</div><div>Type-C charging cable×1</div><div>Warranty card×1</div></div></div>	<div><div>● Product Overview</div><div></div><div><div>● Key function operation</div><div><div>⏻ Power on (hold 1S) / Power Off (hold 3S) Play / Pause / Answer / Hang Up (Click) FM Mode Channel Search (click) Start the phone's voice assistant (double click without opening the APP)</div><div>⏮ Previous (Long Press) / Volume Reduction (Short press) ⏭ Next (Long press) / Add volume (short press)</div><div>🌟 Contact rejection (long press 2S) Switch Bluetooth / FM mode (hold 3S) Light mode switch/Turn on and off light effects (double click) Reset (Hold down for 8S when powered on)</div><div>⏮ ⏭ Clear pairing (Hold down "Volume +-" for 8S while on)</div></div></div></div>	<div><div>● Bluetooth operation</div><div><div>● Bluetooth connection is successful: 1. The speaker enters Bluetooth mode, and the phone searches for the Bluetooth pairing name "sanag M15 ". Click on the connection. 2. The speaker connects to the device once by default.</div><div>● Bluetooth disconnected: 1. Manually turn off the Bluetooth of the mobile phone, and the speaker enters the Bluetooth pairing mode. 2. Disconnect the speaker from the phone after overdistance, return to the effective distance range within 5 minutes, and can connect the phone normally, more than 5 Minutes will automatically shut down.</div></div><div><div>Search for Bluetooth speakers</div><div>Connection successful</div></div></div>	<div><div>● Specifications</div><div><div>● Name: Portable Bluetooth speaker</div><div>● Model: sanag M15</div><div>● Bluetooth version: V5.3</div><div>● Connection range: ≥10m</div><div>● Battery capacity: 1200mAh</div><div>● Input: 5V 1A</div></div><div><div>● Matters needing attention</div><div><div>● Do not use abrasive cleaners to clean this product.</div><div>● Do not allow this product to be heated or close to a fire source, such as a cooking stove.</div><div>● Do not expose the product to direct sunlight for a long time.</div><div>● Do not discard this product in fire to avoid explosion.</div><div>● Do not attempt to disassemble this product to make any modifications, as it does not contain any maintenance components.</div><div>● Do not use this product in rain.</div><div>● If you do not plan to use this product for a long time, please store it in a dry environment and charge the headset at least once a month to extend its life and avoid extreme temperatures and dust.</div></div></div></div>	

FCC Warning Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.