





Press the button to change the mode 按下按键,改变模式








Right Horizontal Line





Right Rotation 左旋转

esture sensing Vehicle deformation 手势感应, 车辆变形

2.4G AUTOMATIC CODE INSTRUCTIONS 2.4G自动对码说明





HOW TO CHARGE 如何充电

1. Before playing please charge the new battery pack.

Left Horizontal Line

按下切换模式按钮切换 手势操作功能

- 1. 这个新的电池组,需要充电后才能使用。
- 2. First plug the battery pack plug in the charger, then plug the charger plugged in the socket (figure 1)
- 2. 先把电池组的电线插头插在充电器的插头里,再把充电器插头插在插座上。(如图1)
- 3. The time required for the battery to be fully charged is 90-150 minutes. The charging plug is equipped with a charging indicator light. During charging, the red light is always on, and when it is fully charged, the red light goes out. Do not overcharge, Charging for a long time will not increase the power.
- 电池充满电量所需时间为90-150分钟,充电插头带充电指示灯,充电中为红灯常亮,充满时红灯熄灭。不要过量充电,过长时间的充电也不会

2

SCHEMATIC DIAGRAM OF GESTURE SENSING OPERATION 手势感应操作示意图

4. legularly check the toys and batteries, charging wire, plugs, such as damaged parts shoule be discontinued until repaired or replaced before use. 定期检查玩具和电池,充电线的电线,插头、这些配件如有破损应停止使用,直到修好或换新后方可使用

Note:Ortherwise repeat the above operation.

4. When you need to pair with other models with remote control or remote control car, you nred to turn off the remote control and remote control car power can be re-paired.

3. After one minute. The remote controll did not find the 2.4g signal from the remote control vehicle,

1. After put the batteries in the remote control, the indicate light flashing, and put the batteries in

2. Each remote control can only be connected with a remote control car, when the connection is

the car and set it on, starting to contect it, if success, the controller indicate light off.

the power indicator flashed, and the power switch should be restarted to frequency.

1.遥控器装好电池,遥控器指示灯开始闪烁,遥控车装好电池打开开关,开始进入连接状态。连接成功时,遥控器指示灯熄灭。

4.当需要配对其他同型号遥控器或遥控车时,需关闭遥控器与遥控车电源才可重配对。

successful, each car does not interfere with each other.

2.每个遥控器只可与一辆遥控车连接,当连接成功后,每辆车互不干扰。注:不可多辆车同时连接。

3.遥控器在一分钟后没有发现遥控车通电发出的2.4G信号,电源指示灯闪烁,须重启电源开关来对频。

Note: not many cars connected at the same time.

PRODUCT CONFIGURATION 产品配置










Battery Pack X1





The remote control does not have a successful code blinking indicator, the good code indicator does not light up 編成集內分配成功無不均內集,对好與指示技术系




HOW TO INSTALL THE BATTERY 如何安装电池

- I 、 The Remote Control → 、遥控器
- 1. Open the battery cover of teh remote control and load the 2X1.5V AA batteriesaccording to the indication of the positive and negative poles of the remote control battery compartment
- 1.打开遥控器电池盖,按照遥控器电池仓里的正负极的指示来装入电池。
- 2. Close teh battery cover. 2.盖上电池盖。
- II、 Remote Control Car 二、遥控车
- 1. Open the car battery cover and connect the rechargeable battery pack to
- the power socket into the car battery compartment.

 1.打开车底电池盖,把可充电电池组连接到电源插口装入车底电池仓里。
- 2. Close the battery cover and tighten with a screwdriver. 2.盖上电池盖,并用螺丝刀拧紧。

2X1.5V"AA





button has the function of lifting,Two lights keep flashing

(紧按按键有升降功能) (o o o o)

Functions Of Switch Keys: 1.Press once to turn on, the body light is always on, then it is induction mode 2.Press again, the body light will flash, then it is dodge mode 3.Press again to Watch Strap 手表固定带

turn off sensing mode Long press to shut down. 开关按键功能:1按一下开启,车身灯光常亮,则为感应模式 2.再按一下,车身灯光闪烁, 则为躲避模式,再按一下关掉感应模式3.长按关机。

All four indicator lights of the watch are on: forward and backward left and right 4 indicator lights in turn: left and right horizontal / left and right rotating in place Press and hold the switch key: the watch turns into two lights that flicker, horizontally upward the vehicle deforms, switch the climbing mode, and then release the switch key Press and hold the switch key: the watch turns into two lights that flicker, the vehicle is deformed horizontally downward, and the flat running mode is switched.

(Figure 1)图1

Right Horizontal Line

轻按一下遥控开关按键,车身2个红灯 为常闪为躲避模式,手放在感应头位 置,车身会随机前进后退或者旋转。


车身灯光闪烁则为手势操作横行

running mode is switched. 手表4个指示灯全亮:前进后退左右

按住切换键:手表变成2个灯跳动闪烁,水平往上车辆变形,切换攀爬形态,之后松开切换键 按住切换键:手表变成2个灯跳动闪烁,水平往下车辆变形, 切换平跑形态。


> the charging line light is red, and when it is full, the red light goes out 3.7V电池充电时充电线灯为红灯,充满时红灯熄灭

WATCH REMOTE CONTROL OPERATION DIAGRAM 手表遥控操作演示图












Press the button to enable the twist mode 紧按按键,开启扭变模式

2

When the car is not operated for 50 seconds, the car will automatically enter the sleep state. Wait for the next remote control to turn off the car switch and then turn it on again, 当车子50秒没操作,车子会自动进入休眠状态。等下次遥控时必须关闭车子开关后再打开方可对码







Buttons Small buttons down in parallel 按键小按键平行向下下降

FCC Compliance Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.