





MODEL: BH462A

Package List



	Volume- / Previous		Volume+ / Next
	ON/OFF		LED indicator
	Charging Port		Microphone
MFB Multifunction Button(MFB)			
	Earbuds Retract Button(L)		
	Earbuds Retract Button(R)		





1. Keep your headset and device as close to each other as possible, less than 1 meter is better.
2. Switch to "ON", wait for few seconds, the LED will flash red and blue alternately, which means that it is ready for pairing.
3. Turn on Bluetooth on your device and find the headset's name "Mpow Wings".
4. Click "Mpow Wings", Bluetooth headset will get connected with your device automatically. Input 0000 if it requires a password.

1. After successfully pairing with one device, turn off the Bluetooth of the device and switch the button of "Mpow Wings" to "OFF".
2. Follow the same steps as above to get your 2nd device paired with the Bluetooth headset.
3. Turn on the Bluetooth of the 1st device, and then choose "Mpow Wings".
4. Now, both devices have been connected with Mpow Wings.


Note:

1. The headset will automatically reconnect to the last-time paired and used device.
2. If it does not automatically reconnect, you can delete "Mpow Wings" on the Bluetooth list of your device, and then re-pair.




 The correct way to retract the wire
To prolong the lifespan of the headset, please hold the wire with your hands to make it retract slowly when you press both Earbuds Retract Buttons. You can follow the steps shown below.

1. Hold the wire with your hands.
2. Press both Earbuds Retract Buttons with your forefingers.
3. Slowly retract the wire.
4. Press both Earbuds Retract Buttons again to let the rest of the wire and earbuds to retract.



-  **The wrong way to retract the wire**
Directly press both Earbuds Retract Buttons. In this way, the earbuds will hit the headset aggressively.



 (Waste Electrical & Electronic Equipment)

This Marking shown on the product or its literature, indicate that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household user should

contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

1. Please fully charge it if it was going to lay idle for a long time and place it in a cool and dry place. Please recharge it each 2 months for storage.
2. Please fully charge it for the first use.