



OUTSIDE WIRE

MIC & CONTROLLER



GUIDELINES FOR WEARING YOUR CONTROLLER



1. Connect the controller to your Relay device via the USB-C connector
2. Connect the earpiece via the 3.5mm connector
3. Clip the controller to your shirt near your neck area with the controller no more than 8 inches from your mouth when speaking.
4. Route the earpiece to your ear; it works on either ear.


Pacemaker and Other Implanted Devices:

This Relay accessory contains magnets and could interfere with pacemakers or other electronic medical devices. Before using this Relay Accessory, consult with your doctor or medical device manufacturer about the required safe distance between Relay accessory and your medical device.

FCC ID: 2AMBHR220110 IC: 25353-R220110

HIDDEN WIRE

MIC & CONTROLLER



GUIDELINES FOR WEARING YOUR CONTROLLER



1. Connect the controller to your Relay device via the USB-C connector
2. Connect the earpiece via the 3.5mm connector
3. To hide the wire, route the controller through your outer clothing and clip it to the collar or shirt edge. Keep the controller within 8 inches of your mouth for best audio performance.
4. Route the earpiece to your ear similarly; it works on either ear.

Pacemaker and Other Implanted Devices:

This Relay accessory contains magnets and could interfere with pacemakers or other electronic medical devices. Before using this Relay Accessory, consult with your doctor or medical device manufacturer about the required safe distance between Relay accessory and your medical device.