

User Manual

Thank you for purchasing the Bluetooth ® Speaker for smart phones, tablets, notebook computers and other Bluetooth enabled devices. This product combines high-tech innovation with design to provide you with years of dependability and enjoyment.

Safety Precautions and Maintenance

connecting.

Please read these operating and maintenance (servicing) instructions before installing and operating your speaker.

Warning: To reduce the risk of fire or electric shock, do not expose this speaker system to rain or moisture (including swimming pools or objects filled with liquids, such as vases or drinks).

Important Safety Instructions

- 1. Always read Safety and Operation instructions before use. Retain instructions for later reference.
- 2. For indoor use only. Do not expose the speaker to liquid, moisture or
- Do not use abrasive cleaners to clean the speaker case as they may damage the finish. Always unplug the unit before cleaning.
- 4. Do not expose the speaker to extremely high or low temperatures. Keep the unit away from direct sunlight.
- 6. Use only accessories and attachments as supplied and designated in
- the instruction manual. 7. Do not attempt to open or modify the speaker in any way, as it does
- not contain any serviceable parts. Please refer all servicing to
- 8. Please store the unit in a dry place that is free from extreme temperatures and dust.
- Always operate the speaker on a flat and level surface. 10. Always operate the speaker away from children and small animals as
- they may play with the power cord and other small parts. 11. Always dispose of the packaging and the unit in accordance with the local regulations and in a responsible manner.

2

harmful interference to radio communications.

The FCC Wants You To Know

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference

to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.


Consult the dealer or an experienced radio/TV technician for help. This device complies with Part 15 of the FCC Rules. Operation is subject

to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including

interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.


Speaker Overview



7.AUX-IN 8.Charging port

User manual x 1

Play Conference Mode **少**/ ≯ Bluetooth connect Press and hold to switch on, The Bluetooth PAIR indicator light press and hold to switch off. will start blinking rapidly. Now you can begin to play music on your speaker. Press " • " " • " to adjust volume, and press " ▶ " to Pause or Play. Activate the Bluetooth function on your You can adjust the light color when pressing the light device and search Bluetooth devices, Once paired, the Blue LED light and select "BW ROSWELL" to start



When receiving an incoming call on your cell phone via Bluetooth linked with the speaker, tap " * " to answer. Press" * " " * " to obtain the desired sound level. To end the call, just tap the PHONE" (" on the speaker. To gnore an incoming call, simply press and hold the " on the speaker for about 2 seconds.

Solid red light means the battery is charging. Red light off means the charge is complete. Note: When your battery is low, the red light will blink slowly.

Charge \forall / \forall \text{ \(\sqrt{\sq}}}}}}}}}}}}} \signtimes\signtifta\sinthinity}}}}}}} \end{\sqrt{\sq}}}}}}}}}}}} \end{\sqrt{\sqrt{\sqrt{\sqrt{\sq}}}}}}}}} \end{\sqititin}}}}} \end{\sqitinititin}}}}} \end{\sqitititititit{\sintiin}}}}}}}

Can be charged by

using the USB to

Micro USB cord

Approximately 3

hours required for

last up to 5 hours when connected wirelessly.

full charge.Note: Battery will

(included) through computer or AC adaptor with USB iack (not

1.Power ON/OFF Switch


2.Speaker phone

3.Play/Pause

5.Volume up

6.Light key

4.Volume down



Use a 3.5mm cable (not included) to connect the speaker to another audio source. Press Play on the device and adjust the volume on the unit to obtain the desired volume. Note: Play/Pause controls on the unit will not work when using the "AUX-IN".

Technical Specifications

- Amplifier power: 3W
- · Battery type: Li-ion rechargeable

Package Contents

Main unit x 1

USB Charging Cord x 1

- Bluetooth transmitter frequency range: 2.402 2.480GHz
- · Bluetooth transmitter power: 0 4dBm