

User Manual

TMW-DM



INSTALLATION INSTRUCTIONS

Installation Procedure for TMW-DM meters, FCC ID:NTAXMETER6

To insure reception with maximum transmission range of the meters

The user and the installer should be aware that changes and modifications to the equipment not expressly approved by Master Meter could void warranty and the user's authority to operate the equipment. Professionally trained personnel should install the equipment.

NOTE: The antenna used for this transmitter must be installed to normally provide minimum separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

Pit Setting

- 1) Meter should be installed as close to the center of the meter box as possible.
- 2) Distance between the top of the installed meter and the metal pit lid should be between 4 and 8 inches.

Proper residential meter installation depicted in a pit setting.



ATTENTION:

The digital portion of the transceiver has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1.) Reorient or relocate the receiving antenna.
- 2.) Increase the separation between the equipment and receiver.
- 3.) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- 4.) Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device is factory-limited not to exceed the following transmission duty cycles: FCC ID:NTAXMETER6: 0.1%.

WARNING

Sensitive Electronics Inside

HANDLE CAREFULLY

Master Meter

101 Regency Parkway Mansfield, TX 76063

Main: 817 842 8000

Toll Free: 800 765 6518

Fax: 817 842 8100