

Label Location

The XSLATE R12 SlateMate™ (RPM001 and RPM002) are permanently attached to the Tablet at the Factory or qualified Service Center.

The label is located in the battery bay and is visible when end users installed the battery.

The Back of Tablet

