

# G96B TWS earphone - Hybrid ANC+ENC

## User Manual



### Warning

Please read the warnings below carefully. Store this manual with product packaging. The safety precaution manual reduce the risk of fire or injury when correctly complied to.

To reduce the risk of injury :

Keep batteries out of reach of children.

Do not heat, open, or dispose of battery pack in fire.

Do not allow metal objects to touch the battery on the device.

Do not expose battery pack to excessive heat.

Do not use a high current charger, or the charging line will burn out.

Please Charging with a DC 5V adapter (not included in the package)

### Product Specification

- Bluetooth solutions: JL7016 hybrid ANC+6mic ENC
- Bluetooth version: 5.4
- Support: A2DP, AVRCP, HSP, HFP
- Earphones battery capacity: 40mAh
- Charging case battery capacity: 300mAh with protection
- Playing time:4-5hours(High quality music and volume may accelerate battery consumption)
- Effective distance: 10M
- Speaker size: 10mm
- Sensitivity(horn unit): 115±1.5 dB S.P.L at 1KHz
- Speaker impedance(horn unit):32± 15% at 1mW / 1000Hz
- Mic sensitivity:-38±1dB
- Earphone charging time: about 2H
- Charging case charging time: about 2H
- Product Weight:earphone 4.0g,charging case 41.5 g
- Size of earphone & charging case:earphone 20\*36\*25mm,charging case 53\*55\*32mm

# Paring

## Auto Pairing

Taking the earphones out of the charging case, and then the earphones will automatically turn on, sync together and enter pairing mode.

Open up Bluetooth setting on your smart device and scan for **GEARit Earbuds AS011**.

# Operation

## 1: Power on/off .

- 1.) Take the earphones out of the charging case, automatically turn on;  
Put the earphones back to the charging case, automatically turn off;
- 2.) Long press 5 seconds to turn off.

## 2: Play/Pause music.

When listening to music.

Tap left/right earphones **once** to play or pause the music.

## 3: ANC Mode

Quickly tap the Right headset twice: switch ANC mode

When taking the earphones out of the charging case, it is regular Bluetooth mode.

After the noise reduction is turned on, the adaptive noise reduction technology can detect the current ear canal structure and wearing status, and intelligently match the best parameters in multiple sets of noise reduction parameters, so that your ears can get a unique noise reduction effect.

## 4:Previous /Next Song

When listening to music.

Long press left earphones for 2 seconds to go to previous song.

Long press right earphones for 2 seconds to go to next song.

## 5: spatial sound effects

When listening to music.

Quickly tap the left earphone twice: turn on spatial Sound effects.

(if it do not work try long press left side two second when music is playing)

Enhance the three-dimensional sense of audio, make the audio more spatial, and bring immersive experience to the audience

## 6: Intelligent pick free

In ANC mode:

Four taps on the left or right ear to **Intelligent pick free ON**;

Four taps on the left or right ear to **Intelligent pick free Off**.

The headset can automatically detect the sound of speaking, and automatically pause the music and turn on the ambient sound (the volume needs to be less than 70%, the best effect), so that you can wear the headset to talk to others.

#### **7: Answer/Hang up**

When there is an incoming call.

Tap left or right earphones once to answer the call.

Tap left or right earphones again to end the call.

#### **8: Reject**

When there is an incoming call.

Quick **twice** tap left/ right earphones to Reject call.

#### **9: Voice assistant**

Quick tap left or right earphones 3 times to activate voice assistant.

## **Charging Function**

Fully charge the case and earphones before using for the first time.

1: Charging the charging case

(a) There is a Type-C cable included in the packaging. Connect it to the Type-C charging port and the other end into a USB powered source to charge your case.

(b) White light will flash to indicate charging has begun.

(a) Once fully charged, the white light stays firm.

2: Earphone charging

When battery is low, each 5s flash once for left and right side white light at the same time, you will listen to a warning sign or tone. It will turn off when the earphones completely out of battery.

(a) Place the earphones into the charging case.

(b) White light on the earphones turn on when charging has begun. The light will turn off when charging is complete.

## **FCC ID:2BKO4-G96B**

## **FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment