

Start
Here

TuneCast® Universal
Quick Start Guide

BELKIN®

BELKIN®

www.belkin.com

Belkin Tech Support

US: <http://www.belkin.com/support>

UK: <http://www.belkin.com/uk/support>

Australia: <http://www.belkin.com/au/support>

New Zealand: <http://www.belkin.com/au/support>

Singapore: 1800 622 1130


Europe: <http://www.belkin.com/uk/support>

© 2010 Belkin International, Inc. All rights reserved. All trade names are registered trademarks of respective manufacturers listed.


8820-00576

F8M066-P


Car Installation




1. Plug adapter into car's cigarette-lighter outlet.




2. Plug headphone plug into media player's audio jack.



3. Find a frequency without a station on it. A good frequency will be between other stations, with a lot of static. To identify the best available frequencies in your area, visit www.belkin.com/mybestfm.




4. Match station using up and down buttons.




5. Play music.

Storing Frequency (optional)



1. Press and hold the MI or MII button for two seconds to store station. When the MI or MII icon blinks, release the button.



2. To recall a stored station, simply press the same MI or MII button.