

Wireless Charger Instruction Sheet

THE DIAGRAM of INSTALLATION



- Phone Stand
- Charging area
- White board
- Mark Pen
- 6 Eraser
- 6 Instruction sheet



Wireless Charger's Charging Method

- 1)Connect wireless charging pad to a power source via included Type-C cable. The charging pad will enter standby mode and the indicator light will flash white.
- 2)Place your portable device in the center area of the charging pad. When the charging begins the indicator light will turn on.

Product specs:

Product Model:

Main Functions: Wireless Charging Transmitter:

Standard Version: WPC - 1.1:

Charging Type: One-on-one charge corresponding area;

Ilnput Specs:5V/2A.9V/1.67A

Output Specs:5V/1A.9V/1.1A

Effective Distance: 4 to 6 MM:

Conversion Efficiency: ≥70%:

Charging Methods: Induction Model;

Working Frequency: 111.5-205 kHz;

Accessories: USB cable: Wireless charging pad:

Packing box, and instruction sheet.

Warning!

This wireless charger is designed to charge Qi compatible mobile phones. Not for use with Airpods®, Airpod Pros® or other

earphones with wireless charging cases.

Airpods is a trademark of Apple Inc., registered in the U.S. and other countries.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection

against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency

energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- --Reorient or relocate the receiving antenna.
- --Increase the separation between the device and receiver.
- --Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- --Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The distance between user and products should be no less than 20cm