# CLIP 01 夹耳式蓝牙耳机



使用说明书 使用前请仔细阅读本说明书

# 产品使用简介

- (1) 除说明书有特殊标示的操作方式以外, 请勿尝试拆卸或更 换产品内的任何零件。
- (2) 请勿将产品放入水或其他任何液体中, 此产品非防水设计。 (3) 如果有任何液体不小心进入产品内时, 请立即断开连接并
- (4) 为避免触电,请在安装或卸载产品时,确保手上没有沾水。 (5) 请勿将此产品放置于热源附近或直接暴露在火源附近。
- (6) 请勿将本产品放置在有强大电磁力的环境中,否则会导致产 品故障。断开连接并移开此产品。

# 包装清单



8

耳机 X 2

使用说明书×



充电仓 X 1

充电线 X 1

# 产品示意说明



-功能触摸区





# 产品规格

蓝牙版本: V5.4 传输距离: 10-15米 电池容量: 25mAh 使用时长:约4小时 充电时长:约1小时

额定输入: 5V-20mA

# 充电仓规格

电池容量: 180mAh 充电时长: 1小时 额定输入: 5V=200mA

(所有技术信息以实际性能为准)

采用Type-C充电线连接充电仓到5V电源适配器,本设备不支持快充头。 (温馨提示:当充电仓指示灯红灯闪烁时,请及时给充电仓充电。)

### LED指示灯说明

给耳机充电未充满: 红灯常亮

• 给耳机充满电: 红灯灭 充电仓 •给充电仓充电:绿灯闪烁 指示灯

• 充电仓充满电: 绿灯常亮 • 充电仓低电: 蓝灯闪烁

• 开机: 红蓝灯交替闪 • 关机: 红灯闪一下灭 耳机指示灯

• 蓝牙配对状态: 无灯

• 耳机配对成功: 红蓝灯交替闪

## 产品操作说明

方式一: 将耳机从充电仓中取出, 耳机自动开机。

方式二: 当耳机处于关机状态,长按3秒耳机功能键,耳机开机。

方式一: 将耳机放回充电仓, 耳机关机。


方式二:长按8秒,耳机关机。

# 3.配对

步骤一: 将耳机从充电仓中取出, 耳机自动开机, 开机后耳机 自动配对

步骤二: 打开智能设备的蓝牙列表:搜索设备型号(见包装封面

型号)并点击连接(支持单耳使用)。



### 触控按键的操作 ■■ 左/右耳机操作



音量-: 三击左耳机 (L)功能键 音量+: 三击右耳机 (R)功能键

上一曲: 双击左耳机 (L)功能键

下一曲: 双击右耳机 (R)功能键 暂停/播放: 单击任意耳机功能键

# ■ 电话免提

# ■■ 左/右耳机操作(来电状态下)



接听: 单击任意耳机功能键

拒接: 长按任意耳机功能键2秒 挂断: 单击任意耳机功能键

■ 激活语音助手(智能设备支持语音助手)

# ■■ 左/右耳机操作



激活:长按任意耳机功能键2秒(通 话状态下除外)

# CLIP 01

# clip on Bluetooth Headsets



Please read this manual carefully before use the device.

# Product Usage Introduction

(1) Do not attempt to disassemble or replace any part of the product except for those operations specifically indicated in the instruction manual.

(2) Do not immerse the product in water or any other liquid, the product is not designed (3) If any liquid accidentally enters the product, disconnect and remove the product

immediately.
(4) To avoid electric shock, make sure there is no water on your hands when installing or uninstalling the product.

uninsualing the product.

(5) Do not place this product near a heat source or expose it directly to an ignition source.

(6) Do not place this product in an environment with strong electromagnetic force, otherwise it may cause the product to malfunction. In the above cases, it is necessary to

# Packing list



Earphones X 2



Charging caseX 1



Manual X 1



Charging cable X

### Product schematic description



# Headsets Specifications

Bluetooth Version: V5.4 Transmission distance: 10-15 metres Battery capacity: 25 mAh Usage time: about 4 hours Charging time: about 1 hours

Rated input: 5V=20mA

# Charging case Specifications

Battery capacity: 180mAh Charging time: 1 hours Rated input: 5V---200mA Usage time: 18 hours

(All technical information depends on actual specifications)

Use Type-C cable to connect the charging case to the 5V power

adapter. This device does not support fast charging head. (Warm tip: If the charging bay indicator light flashes red, charge the charging case in time.)

Charging

- Charge the charging bay: White lights change slowly Charging bay is fully charged: Indicator is off · Charging the earphones is not fully charged:Green
- light flashing Indicator Fully charge the earphones: Green light on Low charge: White flashing
- Power on: Blinking red and blue Power off: Red light flashes 3 times
- BT pairing status: Red and blue lights flash Indicator
  - Earphones are successfully paired: Indicator is off

# Product Operation Instructions

Option 1: Remove the headset from the charging case, the headset will turn on automatically.

Option 2: When the headset is off, press and hold the touch area on the headset for 6 times, the headset will turn on.

Option 1: Put the headset back into the charging case, the headset will switch off.

Option 2: Press and hold the touch area on the headset for 6 times , the headset will switch off.

Step 1: Remove the headset from the charging case, the headset will automatically switch on and once switched on, it will automatically execute the command.

Step 2: Open the Bluetooth list on your smart device, find the device model (showed in the package cover) and press the connect button (supports monaural sound).



### Touch button control

### Left/right headset control



Volume down: click the function area on the left headset (L) four times Volume up: click the function area on the Previous song: triple-dick the function area on the left headset (L)

Next song: triple-click the right headset function area (R) Pause/playback: press the function area on the headset twice

# Hadnsfree phone mode

# Left/right headset control (incoming call)



Answer: press the function area on the headset twice Reject: press and hold the headset

Hang up: press the function area on

Activate voice assistant (smart devices support voice assistant)

■■ Left/right headset control



key for 2 seconds (except under call status)



# FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.