

Metal appearance

Figure 9

Inside Configuration of the EUT




Figure 10

Inside Configuration of the EUT




Figure 11
Inside Configuration of the EUT





Figure 12
Inside Configuration of the EUT



Non-metal appearance

Figure 13

Inside Configuration of the EUT




Figure 14

Inside Configuration of the EUT




Figure 15
Inside Configuration of the EUT



Figure 16
Inside Configuration of the EUT




Figure 17
Inside Configuration of the EUT




Figure 18
Inside Configuration of the EUT




Figure 19
Inside Configuration of the EUT



Figure 20
Inside Configuration of the EUT



Figure 21
Inside Configuration of the EUT



Figure 22
Inside Configuration of the EUT




Figure 23
Inside Configuration of the EUT




Figure 24
Inside Configuration of the EUT



Figure 25
Inside Configuration of the EUT




Figure 26
Inside Configuration of the EUT



Figure 27
Inside Configuration of the EUT



Figure 28
Inside Configuration of the EUT

