

# User Guide for IT108

True Wireless Stereo Earphones



This device complies with Part 15 of the PCC rules. Operation is subject to the following two-conditions: 
1) this device may not cause barouful interference, and 2) this device must accept any interference received, including interference that may cause underived operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the PCC rules. These limits are designed to provide reasonable protection against harmful americance in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to sadio communications. However, there is no guarantee that interference will not occur in a particular sistallation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

Recrietit the receiving anterna.

Increase the separation between the equipment and recover-

Connect the equipment into and surfet on a circuit different from that to which
the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.


Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

PCIC ID-ZAXINITION

# English ----- 01-08 Deutsch ---- 09-16 Français ---- 17-24 Italiano ----- 24-32 Español ---- 33-40

- 01 EN -

# **Table of Product Contents**



### **Product Specification**

Bluetooth Version:	5.3
Support:	HFP/A2DP/HSP/AVRCP
Charging Port:	Type-C


02 EN -

6-8 hours of use per full charge of both earbuds (actual battery life varies with song type and volume requirements) Battery life:

1 hours for earbuds / 1.5 hours for charging case Charging time:

Transmission range: 15 meters (without obstacles)

#### Introduction



#### How do I pair two headphones with my phone?

- Please make sure both the earbuds and the charging case are fully charged before first use.
- · Step 1

Take both earbuds out of the charging case and both earbuds will power on and start pairing automatically (If the earbuds are not connected to your device for more than 5 minutes, the earbuds will automatically turn off. Press the MFB button for about 5 seconds to manually turn on the earbuds when prompted "Power on".)

The indicator light of one earbud will flash white and blue alternately, and the

#### Step 2

Enable the Bluetooth pairing mode on your phone device, search and select "IT108" to connect. (You should hear a voice prompt "Connected" when wearing earbuds).

indicator light of the other earbud will slowly flash blue when paired successfully

- If indicator light of earbud is off, it means the phone is connected
- · Automatic connection

By default, the earhods will connect the last paired phone automatically when power on.

Clear TWS and phone pairing

Put the earphones into the charging box, open the cover and press the button of the charging box for 10 seconds

- Frompt
  - If you have any problem pairing the two earbuds with your phone, put the earbuds back in the charging case and repeat the above steps.
  - 2. These earbuds can be used not only together, but also individually If you want to use single earbud, just take one earbud out of the case and connect it to your phone, or when using two earbuds, manually turn off one earbud or put one back in the charging case and you'll be able to use the other one earbud alone.

# Functions

#### • Telephone Communication 📞

Answer call:	tap once
Hang up:	press and hold the key for 2s
Refuse incoming call:	press and hold the key for 2s

#### • For Music 🎵

Play/pause	tap twice	
Previous track	press and hold "L" for 2s	
Next track	press and hold "R" for 2s	
Activate Siri	quickly tap for three times	
Turn down volume	single tap on left earbud	
Turn up volume	single tap on right earbud	

#### Charging

#### Earbuds Charging

The earbuds will only be charged when you place them in the charging slots correctly. (You can charge the charging case and the earbuds at the same time, or you can charge the charging case first and then the earbuds.


The indicator light will show red while charging.

The charging case will stop charging automatically and the indicator light on earbods will go out when fully charged.

When the earbuds are charging in the charging case, the digital display bar of the case will keep blink

#### · Case Charging

There is a Type-C usb charging cable in the package, please use it to charge the case directly. During charging, the digital display will flash and display the battery level in real time. When fully charged, the number shows 100.



### Charging Alerts ①

- After using it for a long period of time, due to the exidation of the magnet connector, the earbuds might not be charged or even turned on.
- You can fix this problem by cleaning the magnet connectors on the earbuds and charging case with an alcohol wipe
- Put the earbuds in the charging case, the earbuds will turn off immediately and the charging case will start to charging automatically.
- The earbuds will connect the last paired phone automatically.

#### Storage and Maintenance

- If the earbuds have not been used for more than 3 months, we recommend that you charge it.
- Please use an charger approved by FCC (Federal Communications Commission).
- Children aged 12 and under require adult supervision.
- Do not expose the earbuds to high or low temperatures, and do not use the earbuds during a thunderstorm.
- Avoid free fall or violent shock to the device. Keep the device away from sources of fire and do not place the device in water.

#### Frequently Asked Questions

- Q: Why don't these earlinds pair with my phone?
- A : Make sure the earbuds are fully charged and powered on.
  - Make sure your phone's Bluetooth is enabled
  - If there is no problem with the two points stated above, turn off the powered-on earbuds after 5 continuous and quick clicks.
  - Put them back into the charging case and close the lip, wait for 1 minute, then open the charging case and reconnect the earbuds to the phone.
- Q: Why does the music cut in or out?
- A : First, keep the earbuds no more than 15m away from your phone (no obstacles).

If the distance is less than 15m, follow these steps:

- Put the earbuds back into the case and close the lid, manually click "forget the IT108" on your phone
- 2. After 10 seconds, open the charging case and reconnect these earloads with your phone
- Q: Why the earbuds still won't be charged or disconnect from the phone after I put them in the case and close the lid?
- A : Make sure the charging case is not in a low battery state.
  - If the charging case is in a low battery state, the earbuds will neither be charged nor disconnected.
  - In this case, please use a type-c charging cable to fully charge the case.
- Q : Are these earbuds sweat- and water-resistant?
- A : These earbuds are sweatproof and slightly waterproof.

For electronic devices, we do not recommend that you submerge the earbuds in water.

For more detailed product FAQs, please contact our customer service.

#### Activation & Warranty

Permanent replacement of damaged, defective item or missing components. Please activate via email below within 15 days. earbudsvip19@gmail.com

- 08 EN -