© Arlo Technologies, Inc. Arlo, Arlo logo, and Every Angle Covered are trademarks of Arlo Technologies, Inc. App Store is a service mark of Apple Inc. Google Play and the Google Play logo are trademarks of Google LLC. Other trademarks are for reference purposes.

Si ce produit est vendu au Canada, vous pouvez accéder à ce document en français canadien à arlo.com/docs.

(If this product is sold in Canada, you can access this document in Canadian French at arlo com/docs)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For regulatory compliance information including the EU Declaration of Conformity, visit www.arlo.com/about/regulatory/.



Arlo Technologies, Inc. 2200 Faraday Avenue, Suite 150 Carlsbad, CA 92008 USA

Arlo Technologies Intl. Ltd. Ground Floor, Building 3 University Technology Center Curraheen Road, Cork, T12 EF21 Ireland

August 2019





Set up your Arlo Video Doorbell

1. Download the Arlo app and follow the setup instructions for Arlo Video Doorbell









2. Connect the power kit to your existing chime.



Replace your existing doorbell with your Arlo Video Doorbell.

The Arlo Video Doorbell requires a wired doorbell and chime with voltage between 16V AC and 24V AC, and a 10VA transformer.



What's in the box







Power kit



Release pin





Wall screws and anchors

(These parts are attached to each other in the box)



15° mounting plate







Optional wire extensions, wire fasteners, and extra screws

Tools

- A Phillips head screwdriver is required to install the doorbell (not provided).
- You might also benefit from having a drill, a level, and a ladder.

Need help?

We are here for you.

Visit www.arlo.com/support for quick answers and resources:

- How-to videos
- Troubleshooting tips
- The Arlo Support phone number for your location