

GIANT ELECTRONICS LTD.

MODEL: T8270D

[illegible]

REV.

PRE.BY

DATE _____

CHK.BY

DATE _____



APP.BY

DATE _____

KELLY ZHU July 13,04

BIRD CHENG Sep 13,04

James Ho Sep 13,04



The diagram illustrates the structure of the serial number SN:XXXXWECXXXX. The SN is composed of four parts: APC CODE (RRSS), LOCATION, YEAR, and MONTH. The serial number is a 4-digit code, with examples provided for each digit position: 0001, 0002, 9999, 001A, 999A, 001B, 999Z, A001, A999, B001, and Z999. The diagram also includes a note: MAKE SURE NO.

SN:XXXXWECXXXX

APC CODE (RRSS)
(SUPPLIED BY CUSTOMER)

LOCATION

YEAR

MONTH



Serial number
4 Digits
eg. 0001
0002
9999
001A
999A
001B
999Z
A001
A999
B001
Z999
MAKE SURE NO

Format						Use					
XXXXWYMXXXX						Child serial number for single unit.					
Digit Sequence	1	2	3	4	5	6	7	8	9	10	11
Code Format						Year of Manufacture	Month or Calendar Week	Serial Number			
Character	X	X	X	X	W	Y	M	X	X	X	X

Characters	Description												
XXXXX	APC CODE (CUSTOMER SUPPLY THIS INFO)												
W													
Y	A--2000, B--2001, C--2002, D--2003, E--2004, F--2005, G--2006,.....EG.												
M		1	2	3	4	5	6	7	8	9	10	11	12
	NT/FY	A	C	E	G	J	L	N	Q	S	U	W	Y
	DG	B	D	F	H	K	M	P	R	T	V	X	Z
XXXXX	Sequential four-digit number. The numbers will start over at the start of each week/month.												

GIANT ELECTRONICS LTD.

MODEL: T8270		TITLE: MAIN UNIT PACKING				
REV.	PRE.BY	DATE	CHK.BY	DATE	APP.BY	DATE
A	SKY XU	6/Aug/04	QL SUN	6/Aug/04	JAMES HO	6/Aug/04



NOTES:
1. STCIK THE FCC LABEL AND BARCODE&SN LABEL INTO BATTERY BOX