100 GSM ART PAPER, TWO-SIDED PRINTING, BLACK & WHITE

INSIDE PAGES

INTRODUCTION

Thank you for choosing our 5 in 1 LEO Desk Lamp: This versattle lamp combines the functionality of a lighting solution with convenient wireless charging capabilities for Qi-compatible devices. With its foldable hinge for easy watch charging and USB-A and Type-C USB watch charging ports, it offers a multi-functional and user-friendly experience. This user manual. will guide you through the setup process and provide instructions for optimal usage of the LED Lamp.

FEATURES

- · Qi-Compatible wireless charging
- · AirPods wireless charging
- · Multiwhite light settings
- · Clock display
- · Alarm
- . Type-C USB and US8-A charging ports for smart watch charging
- · Wireless phone charging stand
- · Apple Watch charger holder
- · 20W Type C USB PD Charging Adapter

WIRELESS CHARGING CAUTIONS AND TIPS

- . To prevent damage to the phone or the charger
- Remove metal cases, or cases with any magnet/metal. components, from phone before charging.
- . Do not place metal objects on the charger during charging · Qi wiretess chargeable phones with metallic finishes will
- charge normally. · Very thick phone cases can obstruct wireless charging
- For effective charging, it may be necessary to reposition the phone or remove the case.
- · Consider tuning off your phones vibrating notifications during charging, as vibrations may cause your phone to shift position on the charger and stop charging.

Troubleshooting Tip: The power adapter is equipped with overload protection. In the unlikely event that the lamb and the charging of multiple products cause too much load on the power adapter, the the adapter may switch off. If this happens, turn off the lamp or remove one of the products being charged for some time, until the charging load decreases.

GETTING TO KNOW YOUR 5 IN 1 DESK LAMP



INSTALLATION

- . Carefully remove the LED Lamp and its accessories from the packaging
- . Unfold the lamp by extending the lamp arm and adjusting it to your desired height.
- . Connect the lamp to the 20W Type-C USB Power Adapter provided using the included cable and connect adapter to wall

Tip: For 15W phone charging: to ensure charging of some fully discharged 15W phones you may need to power off the LED light for some time if the phone will not remain charging. Note: To ensure proper operation, only use the supplied 20W

power adapter and the supplied 3A USB Type C power cable, or an equivalent 20W PD power adapter and 3 USB Type C cable.

LIGHTING

- . To active the light: tap the Power button. The initial setting is cool white light at 50% brightness.
- . To change the light modes. When the light is on, tap the Power button to change the light mode between cool white light, warm white light, and white light combination.
- . To change the brightness level, tap and hold the Power button, the brightness with increase until it becomes 100%. Remove your finger and tap and hold again to decrease the light level

Note: If you do not change for 5 seconds, the last setting will be extensifically saved.

TO TURN OFF/ON THE DISPLAY

Press the clock and alarm key at the same time to turn off the clock display. Shortly press the clock key or the alarm key to reactivate

CLOCK SETTING

- 1. To set the hour: Press and hold the Clock button, that is located to the left of the power key, until the hour digits start flashing.
- 2. Repeatedly tap the Clock button to change the hour digits. Stop tapping when you reach the desired hour setting and wait for the hour digits to stop flashing. The hour is now set.
- 3. To Set the minutes: Press and hold the Clock button until the hour digits start flashing, lift your finger and press again until the minute digits start flashing.
- 4. Repeatedly tap the Clock button to change the minute digits. Stop taping when you reach the desired minute setting and wait for the minute digits to stop flashing. The minutes are now set.
- 5. To change from 12-hour to 24-hour mode: Briefly tap the Clock button. The AM icon and PM icons will display in 12-hour mode. No AM or PM icons will be displayed in 24-hour mode.

ALARM SETTING

- 1. To set the hour: Press and hold the Alarm button, that is located to the right of the power key, until the hour digits start flashing.
- 2. Repeatedly tap the Alarm button to change the hour digits. Stop taping when you reach the desired hour setting and wait for the hour digits to stop flashing. The hour is now set.
- 3. To Set the minutes: Press and hold the Alarm button until the hour digits start flashing, lift your linger and press again until the minute digits start flashing.
- 4. Repeatedly tap the Alarm button to change the minute digits. Stop taping when you reach the desired minute setting and wait for the minute digits to stop flashing. The minutes are now set.
- 5. To activate / deactivate the alarm: Briefly tap the Alarm Clock button. Turn aff clack display.

CHARGING

PHONE WIRELESS CHARGING

. With the lamp extended, place the phone over the wireless. charging symbols, in the upright (portrait) or horizontal (landscape) orientation. The phone will begin to charge.

EARPHONE CASE STAND WIRELESS CHARGING

· For Airpods (2nd generation) or Airpods (3rd generation) that have cases that can be charged wirelessly, or Airpods Pro Call generations), place the case on its holder ledge on the rear lower side of the lamp with the case's status light facing out and up. Make sure that the case is flat against the back panel of the lamp. Once the case is positioned and aligned correctly, the case's status light should illuminate for a few seconds indicating that the case has started to be wirelessly charged.

Note: Other Gi compatible wireless charging earphone cases may also be charged if the case can physically fit, and be aligned correctly, on the Airpods wireless charging ledge and positioned flat against the back panel of the lamp.

WATCH CHARGER SET UP

The 5 in 1 Lamp is equipped with an Apple watch charger holder where you can place your Apple watch charging puck (not included) to charge your Apple watch.

- 1. Unfold the upper back hinge to reveal the watch charging
- Open lower back panel door to expose the smart watch charging port comportment
- 2. Insert your watch charging puck's cable (not supplied) through the too back opening and thread it down to the charging compartment and plug its USB plug into the matching USB charging port.
- 3. Pull down excess cable into the compartment and close the lower back panel door.
- 4. Insert your watch charger into the circular watch charger
- 5. Place your watch securely on the watch charger and the charging will start.

MAINTENANCE AND SAFETY INFORMATION

- · Read all the instructions before using the product, and use the product as intended
- Disconnect the USB cable once the product is fully charged.
- . Keep close supervision of this product if being used around
- Do not expose the product to rain or moisture, and do not use nearby water such as swimming pools, bathtubs, or sinks.
- Do not expose the product to heat sources, the sun, or leave in a hot vehicle.
- Do not place metal items on the surface of the product.
- Do not modify or try to use the product for a non-intended purpose.
- Do not cover the product with paper or other materials. Use in a well-ventilated area when charging.

OUTSIDE PAGES

- · Wireless chargers generate heat when charging, and the wireless charger may temporarily stop charging if it gets too hot.
- Do not use if damaged or modified.
- · Do not dissemble. There are no serviceable parts inside.
- · Do not place magnetic strip cards or similar magnetically sensitive items between the phone and the charger. Wireless charging uses magnetic induction that could damage these items.
- . Your phone will not charge wirelessly if it is connected to your computer's USB port, or if it's connected to a USB power adapter or other USB charging source.
- . Do not use abrasive cleaning solvents to clean the unit.
- . If you have a pacemaker or other such device, consult a physician before using this product.

This device complies with part 15 of the FCC Rules. Operation is Subject To the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

If this equipment does cause harmful interference to radio or felevision reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reprient or relocate the receiving antenna.
- . Increase the separation between the equipment and receiver.
- . Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not explicitly approved by the party responsible for compliance could void the user's authority to operate this equipment.

ONE YEAR LIMITED WARRANTY

self as limitations and exclusions that they made to one

WHAT THIS COMPRES INVERSIGNAL CONCESS, TREADED OF COMBAGE PRINCE CARRY, IN-I. Mentil THES (AMMED Interleads As placed in the probability COVERS, RESECCION CONFIDENCE RESEARCH, Research Cabbos, sees Accumulates No., 21 Minarceast, As placed as the straige (LIA, suspends to this consent of the environments of the sees of the product containing in the time of the probability of the free forms delice to a research of the sees of the confidence of the confidence of the confidence of the sees of the confidence of the confidence of the sees of Restood. This is, in what I they recity is not transferrable found the petyroid ju

3, 1999, 1879/94/1904 RETURN FOR CYTHAN ARE THE DISTORTING THE PRODUCT AND you are not satisfied with the Praillet for any require, you the to the relative of compliance with the relative's return policy.

ITY CONDITIONS, HOW TO GET SERVICE IF YOU MANT TO CLASH UNDER THE CARTEST Weithort I have reading a chiefe under the Limital Warderby, the context of the Product must be the recovered the manifest that posterior representantly supplications, and the sample with Moster Cables, and Accession in Limital and describe the elegant falsas, and be comply with Moster Cables, and Accession in Limital and the strength obtained in these stranging beatur, Social thereo Cables, and Accession in Limital local beat to execute publication stranging beatur, Social thereo Cables, and Accessions in the Johnson in another default or with respect to a manned Product II of Adversaries, at its resemble from the arrival of the secondaries of the returned Product I fall the Product is as unadable Product infection Paymes Cables, yet Accessions in the War and Looks of return shopping to system and will sendance or all appears and the theory assembled to recover the paying to any transfer to any endance.

EMIGRETHES CARTED INVESTMENT DOES NOT COVER This Control Numerity does not sower th LAMAN THIS LAMINED INVESTMENT DOCKS NOT COYEN THIS LAMBAN MARKANING USE LINEAR MARKANING CHILDREN IN CONTINUED IN CONTINUE including fact out finished to lightening, Wood, narrante, sentingsate, or functiones or fall any son-Viscose Cables, Jean Accessome Not-branched rendering photolasts, even Epachaged or sold soft titteme Cables, Jean Notal passess for preferant. This Limited Whateng does not cover ongraditis partis, such along tertimine, serieus starmagé in tisze to defente in restorials un Armanolitys of the Prochect, or onflusion leven if paulogued on solid-with this piochects. Historia

Califor, new Assessment (so, mounterweck) that you use only authorized excess provides his dissiplinated by report (washingless late of the Product or softman can impair the Product's performance and may invalid the Lindolf Worserty.

is DOVELARISH OF INTRACTOR'S image a stated above to the involved exercises, and in the exercises exercised by applicable inc. three or Califers, line increasing the distribution of express required, and particles or exercise and conditions off express to the product for failure the required and product for failure the representation of exercised and particles of exercised and product for the examinant solvent presentated by applicable law, Moreov Califers has forced by a failure to calculate the characters of expression of the characters of expression and the characters of expressions.

a. CREATER CF CHARACTER IS ADMITTED TO the province of extraction of the first processor of processor of the state of the processor of the state first any consequential, including any obsessor in that data or but profits, assisting from a relating to the bracket, and Monro Calles, and Autonomists to Calles, the Autonomists to Calles, and Au

7. LIMPTORTECTS CANDILITY The House Cabilos, tekn houseconies but, online seen A CHIEF CHESTRE CHESTRE THE RESPONDENCE CARRIES, New Accessories has carries assessing and CALASTONICA CHESTRE AND THE PROPERTY TO A CHESTRE AND THE PROPERTY OF THE STATE OF THE PROPERTY OF exalting from your social the product information, services, or product. Product informat prombed by the remines is not intended as a substitute for direct researcal adapting the Advantation for example, a territorian provided through the correct or out introded as a udictions for walking and waller indications in the home and on the product, not for a fixed party receivoring sensors that expedient above state.

rights. This integrable have primer legal rights that very by other province or jumification. Unamers, some of the limitations in the Limitati Novemby way not apply or cartion obtains, previous or productions. The every of this is of intered Novemby will apply in the vertice permitted by applicative bee. For a full investigation of year legal rights year drawing where to the

Please after Γ -Educations than to precise narrarity classes. Customers incated outside of U.S. will be required for all disposing costs.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body

5 in 1 Western Charging LED Desk Lamp. 20W Typer C 658 PD Charging Adapter 3A 3N Typer-C to Typer C 658 Power Cable

SECUCIONI . DC 5V/3A,9V/2.22A, 12V/1.67A Type-C = USB Subpat: For Smart Watch Charging Sirpats Wireless Charger Sulpat: SW Windows Charget Dalput: 5W-15W-15W-15W 20W Type-C 858 PD Charger Retpot: 5V BC, 3W FV BC, 2 22W 12V BC, 1 &7A







PLEASE MAKE SURE THAT THIS COVER PAGE IS VISIBLE WHEN FOLDED.