

Conducted Test Setup Placement: (With Cradle for USB interface)



Front View of the Test Configuration



Side View of the Test Configuration

Conducted Test Setup Placement: (With Cradle for RS232 interface)



Front View of the Test Configuration



Side View of the Test Configuration

Conducted Test Setup Placement: (Without Cradle for USB interface)



Front View of the Test Configuration



Side View of the Test Configuration

Conducted Test Setup Placement: (Without Cradle for RS232 interface)



Front View of the Test Configuration



Side View of the Test Configuration

Radiated Test Setup Placement: (With Cradle for USB interface)



Front View of the Test Configuration of Unintentional



Rear View of the Test Configuration of Unintentional

Radiated Test Setup Placement: (With Cradle for RS232 interface)



Front View of the Test Configuration of Unintentional




Rear View of the Test Configuration of Unintentional

Radiated Test Setup Placement: (Without Cradle for USB interface)



Front View of the Test Configuration of Unintentional



Rear View of the Test Configuration of Unintentional

Radiated Test Setup Placement: (Without Cradle for RS232 interface)



Front View of the Test Configuration of Unintentional



Rear View of the Test Configuration of Unintentional

Radiated Test Setup Placement: (Intentional)



Front View of the Test Configuration of Intentional



Rear View of the Test Configuration of Intentional