多功能智能賠償 使用说明书

歼、关机

1. 开机:按开机械3秒开机,面灯闪3下(推示 會: 开机) 批开机

2. 关机: 投开机键3秒关机, 红灯亮2秒灭(提 示音:关机) 即关机

3. 自动关机: 开机启不选报子机或与手机断开 连接后,如无任何操作。5分钟后得自动关机

配对连接

1. 并机进入配时模式、红灯里灯交替闪烁。与 軍牙炎各连接

2. 手机配対: 开机未连接手机3击开机键 (撤 示音: 質牙巴英提)

按键操作说明

1. 并机后: 双击开机建中英文切换(未连接室 牙状态下使用)

2. 通话模式:(已连锁定牙状态下使用) (1) 按1次开机键接听电话/注新电话

(2) 双出开机键"嘭"块能烫音助手。单出开 机罐关闭

(3) 长接开机键1.5秒拒绝操防电话

首先对级使用本公司的产品表示原制在使用之 前请先详结阅读此说明书、正确使用此产品。 为了更好的服务本用户手册的内容可能变更。 因为产品的性能和功能而发生的变更将不做另 行通知。 ·产品单介

本产品基與有立体声音竭功能的面牙很竭,模 作助便,美观实用,便于救带。采用签牙芯 片,兼容主流品提手机和早板电路等置牙设 备达到CD级高品质香酒、持久绿煎、左右双 喇叭.并致式定向发音,无障碍提收外界声音,不 影响获取周围环境信息、安全、智能、健康、 便班。 -似壁透帶

智能關係、智能限順充电线、使用说明书、谢 练者活布

·产品使用提示

1. 使用水产品前请仔细阅读说明号。并保留本 说明书。

2. 百次使用, 请先将本产品充满电。

3. 如果产品长期(超过两类)不充电,使用指读时 MOR.

1. 请您以任何理由拆除或维修改第本产品、否 到可能会导致起火、电子击穿甚至彻底损坏水 产品。

2. 请物将设备置于温度过低或过高(0°CL)(下或 45°CULEMBER.

- 3. 请勿将产品规则腐蚀烂液体。
- 4. 不能特別協致在犯光下长时间刷纸, 否则容 **基型形、老化、折断。**
- 5. 请勿得充电线磁型调器近金属物体、以防磁 吸金属物体后引起的知路负险。

· 期要安全信息

1. 在使用本产品用, 请先阅读所有安全信息以 确保正确和安全使用。 2. 使用未经添制造商认可的电源,充电器延率

- 池、可能引发火灾、爆炸或其他危险 3. 请使用本制造商认可且与运型号设备配套的
- 4. 请在温度O'C~35'C范围内使用多产品、当场
- 城里度过期成过低时,可能会引发设备故障。 5. 本设备使用不可拆卸的内置电池, 勇勿 自
- 行更换电池、以免担坏电池或设备、电池只能 由授权服务中心更高。

细、并从电源指度上被被充用器。连续充电时 阅读初期过12小时。

- 7. 请保持设备干燥。
- 8. 若设备或其他任何部件不能正常工作,请勿 自行動標準品。 9. 连接其他设备时,请参考使用说明书的连接

6. 紅充陶完學、诸斯开充电路与末设备的连

方法,不要維維连維不配倉的设备。

▲ 为避免坏力受损,请勿长时间使用高含量。 ▲ 请请请信任关法律法规、不要在以下环境使用。

- ·知加油站、油库、化学业库附近等存储有票 然是哪物或化学品的环境,严禁使用设备。 请勿在医院手术室、急诊室、深切治疗部等
- 场所使用此设备:为避免干扰医疗议器工作。 使用此设备时调运用心研起用器、幼叶器、植 人寫解等医用设备,请保持此设备和起排器之 周期715毫米的距离。

老養在小人區疗设备附近使用此设备请咨询医 四和设备制造海,

请遵守有关领车的使用此设备的所有安全警 告和知识.

言而天气时、为耐免雷击事故、调勿在室外 产品保修凭证

产品保修期内出现非人为组坏的性组故障可以 享受下列三组服务:

自收集之日和7日内。产品出现非人为损坏的 性能故障,用户可选择追回放款或者更换效型 每阶级格的产品。 自收货之日起15日内,产品出现非人为损坏

的性能故障,用户可选择更採用型易用取格的

自收货之日起一年四、产品出现率人为报环 的性能故障,用户可有高家维修。

以下情况不在"三和"服务范围之内:

- 米5200000000倍,採用、碳镍、动态、温用、进 用、事效、你们如果说、法次产品和品、财策。
- 超过"三程"服务有效期的。
- 医火灾、水灾、雷击等不可抗力造场的损坏。
- 因人为原因导致的产品性细故障。
- 未按说明书要求使用而造成拒坏的。

保修卡

周白:

尊敬的用户,本保师卡是您将来申请保修的凭 证、请您配合销售商填写并妥赛保管各用。

用户姓名

旅影响话

信息	通讯地址	
	电子邮箱	
PIL	科研场 相	
	产品名称	
	产品型号	
信息 信息	产品条件	
	名群	
	18 址	
	联系电话	
	ALEXAND.	
	領售日期	
	发情号码	
新注		

Multifunctional Smart Glasses Instruction Manual

Turn on and off 1. Power on: Press the power on button for 3:

seconds to power on. When the trive light flownes 3: times (prompt tone: Plower inst. if its powered on 2. Power off: Press the power faither for 3 seconds to turn of the device. The red light will be on for 2 seconds and then off (prompt tone: Power off); indicating that the device is turned off-3. Automatic Shutdown: After turning on the steviole. and not connecting it to the phone or disconnecting if from the phone, if there is no spendion, the device will automatically shut down after 5 minutes Pairing connection

1. When the mouse is turned on, it emers the parting receds, with the red and blue lights flashing attemptivity, and connects to the Bluetouth device 2. Mobile phone painting. When the phone is harried: on but not connected, press the power button 3 times. (prompt lone: fillulated): is connected): Key operation instructions

1. After startur: Double-click the power-on button towellch between Chinese and English Justic when not connected to Stuetooth; 2. Call mode: (Used when Blastonin is connected)

(1) Press the power hulton once to answer or hang. up the phone (2) Double-click the power builton "Beep" to wake up

the voice assistant, and click the power button to turn

to repaid the sail

(4) Press and hold the power button for 1.5 seconds. to call back 3. Muse Mode: (Used when connected via

Bit whooling (1) Click the power bulton to pause or play the music

(4) 抵接升机键1.5秒间模电线

(2)3击开机键播放下一曲

(3)4击开机键螺纹上一曲

(1)右边河前滑动:音星。

(2)右边内压制动: 音量-

LED報示灯灯灯目动地灭。

4. 音量调号

5. 拍照功能

佐电规警

(1)单击开机腱暂伸音乐/模胶音乐

开启和机状态下革后潜动即可护周

机】, 红灯长美1秒, LED 指示灯光。

竞电中, LED 指示灯红灯长亮。 充电完成

请商提示【3分钟请查播报2次,只服2次就关

3. 資外模式 (己追願並牙状态下使用)

(2) Press the power truton three times to play the next song (3) Press the power trutton four times to play the

printing sing. 4. Volume argustment

(1) Delpe forward on the right. Volume +

(2) Slide the right side backward: Volume -S. Carriero function:

When the camera is on, you can lake a photo by swiping back and forthto prover this phoneCharging. During charging, the red LEO indicator light remains on all the time. When charging is completed. He mul-LED indicator light will automatically go off. Low electricity starm

Vises prompt (Vises broadcast twice witten 3 ... minutes, only twice before shutdown), the red light. remains on for 1 second, and the LEO indicator light gors off.

Statement

First of all, we would like to express our graftlude for your use of our company's producte! Please read this morrual canelully before use and use this product correctly. The content of this user mursual may be shanged in order to provide better service. Changes size to the performance and functions of the product will not be notified separately. · Product triniduction

This product is a diseaseth gasses with stereo sound function. It is easy to operate, beautiful and practical. and convenient to carry. It adopts a Bluelooth chip and a compatitie with mainstream brand mobile phones, tablets and other Bluetooth devices. achieving CD-level high-quality sound quality, long Saftery life, and dust speakers on the left and right. Open directional pronunciation, unobstructed receptor of external sounds, no impact on obtaining information about the surrounding environment, safe, intelligent, healthy and commented.

Packaging list

Sirrort planers, smart placers charging cobies, user munuals, plusies dearing states Product Usage Tipe 1. Please read the instruction manual carefully before

using this product and keep it. 2. Für the first use, please fully sharge this product. 3. If the product is not charged for a long time prome than two weeks), please charge it before use.

1. Do not dismantly or modify this product for any reason; otherwise it may cause fire, electronic Breakdown or even complete damage to the product. 2. Do not place the device in an environment with temperatures that are too low or too high dislow T'C. or above 45°C). 3. Do not let the product cores into contact with

corrosive liquids. 4. Do not expose pleases to the our for a long firm. otherwise they are prone to deformation, aging and

1). Do not place the magnetic and of the charging. cable close to mariot objects to prevent the risk of short circuit caused by magnetic attraction of metal

Important security information 1. Soften storing this product, please read of the safety

trames.

information first to ansure correct and safe use. 2. Using power supplies, chargers or batteries that have not been approved by the original manufacturer may cause fire, explosion or other dangers:

3. Please use the accessories approved by this menufacturer and correspitive with this model of equipment. 4. Please use this product within the temperature

range of 0°C to 35° C. When the ambient temperature is too high or too lose. E may cause equipment biture. fi. This device uses a non-verse while built-in lightery. Please do not replace the battery by yourself to avoid

damaging the battery of the dovice. The battery conserly be replaced by an authorized service center. 6. If the charging is complete, please disconnect the charger from this deviceCorrect and urplug the charger from the power socket. When charging continuouslyPlease do not exceed 12 hours. 7. Phases keep the expensed dry

8. If the equipment or any other components ac not

work properly, please do notSelf-repair products. 5. When connecting other devices, please refer to the parmedian instructions in the user rtunualMethod. Do not connect incompatible devices at will.

A To avoid hearing damage, do not user high: valume for a long time. A Please abute by relevant laws and regulations and during use in the following environments.

It can be stored new gas Motions, oil depots, chamical warehouses, at: The use of equipment is strictly prohibited in an anympresent with flammable. explicative substantians or characters.

Please do not be in the operating room, emergency

more, improve care unit, etc. of the hospital The place uses this equipment. To avoid interfering with the operation of medical instruments. When using this device, please keep away from pacemakers, hearing AIDS and implants/When inserting medical devices such as counteer implants, please keep these devices and pacemakersA distance of more than 15 contimeters between them. If you need to use this. device rear your personal modical apparent. present consult a doctor Teachers and equipment manufacturers. Please abide by all safety warnings regarding

the use of this device while drivingNatice and During thunderstorm weather, to evest lightness

sittike accidente, do not use outdoore Do not charge the product in high-humidity places. such as bathrooms, otherwise it may cause electric

shock, personal injury, fire and damage to the charger. Physics stricts by the relevant legal regulations that explicitly prohibit its use in any environment.

请勿在浴室等高湿度的地方对产品进行充

电,西领会导致触电,人身伤害,起火和充电器

请遵守在任何环境里跟确禁止使用的租关法

编架材置:PC1414/TH90/五金

場片場格: 透明新变、潮福等

排机时间:180円置建造模状态)

充电电压和电波: DCSV/LA最大充电电流法

长期不使用时: 每2个月对电池至少务电一次

建筑定。

·产品参数

操於秘匿:PC/TAC

直牙协议:54

克电影第二15日

电池容量: 100mAh

死电时间:1-20-81.

声声: 四面引, 立体声

使用时间:5H

160mAh

其關懷示:

 Product paremeters Frame material: PC1414/TR90/hardware Liena material: PC/TAC

Lons specifications: Transparent gradient. sunglement, etc. Biuertooth Protocut 6.4 Charging time 1.5 hours

Battery ospecity: 100mAn

Unique time: 5 hours Standby time: 188 hours (Shednoth connection

Channel Due specieers, stemo Charging voltage and rument DCSWTA, with a maximum charging current of 160mAh

Warm numinities: Charging time: 1-2 hours.

When not in use for a long time, charge the battery at least once every two receives

Product warranty certificate The following three guarantees service can be

esagetrant for report

enjoyed for performance facts that occur during the product warranty period due to mon-human damage. ... Without 7 stays from the state of receipt. If the product has performence builts that are not caused by human factors, the user can choose to refund the payment or replace if with a product of the same model and approfication + Within 15 days from the date of recept. If the

product has a performance fullier that is not caused by Numian factors, this cost may choose to replace it with a product of the same model and specification. William one year from the state of receipt, if the product has performance faults that are not caused by human factors, the user can send it to the

The following situations are not present by the "free jauwantees" service:

 Unauthorized repet, misuse, imiliation. regispence, Muse, liquid Ingress, accident, attention or tearing, defacement of product bitters and seats. Beyond the validity period of the "firee guarantees" service.

 Damage couned by force majoure such as fire. fixed and lightning strike · Product performance failures caused by human

 Damage caused by fallum to use in accordance. with the instructions.

Door user, this womanly oard serves as your proof. for future warranty applications. Please cooperate with the sellor to FR it out and wase it properly for

future use User name THE NO. Accress Email Post mete. Hothid rame

Blarcode Resulter name.

Warranty card

Reseller address

Model No.

Reseller M. Postonde

Punchasing diele

Anymore no.

Петик.

(1) has one and hold the power button for 1.8 sempeds

FCC Warning

15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to

provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions. may cause harmful interference to radio communications. However. there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

FCC RF Radiation Exposure Statement:

- 1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
- 2. This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 5mm between the radiator and your body.