Quick Start Guide




Download the free app and start printing instantly! Scan this QR Code or visit www.coreinnovationsinc.com/printer

CTP100LG


Getting Started

Please read instruction card for proper setup before use.

PLEASE FOLLOW INSTRUCTIONS BELOW TO CORRECTLY LOAD PAPER ROLLS.




- Carefully close the lid.





In the Box

Quick Start Guide



Device Overview





Overheated/ Output tray is open

Warranty Card





Blinking Red Light

Oharging / Out of paper /

Load Printer Paper





Pull 1" inch of the paper roll and place outside of the you and tear at a 45° angle printer for optimal printing Close the lid



on paper roll and place as shown



4. Once on the "My Printer" page, search for "CoreLargePrint" on the available device list and tap to

for **InstaPrint** on the App Store® or

3. Connect to Bluetooth® via the app.

In the app, click on the profile tab.

Then click on the "My Printer" icon

Product Specifications

Battery Capacity: 2600mAh Printing Type: Inkless Thermal Bluetooth® Version: 5.2 Image Quality: 203 DPI Charging Input: USB-C®

Bluetooth® Setup

. Download the Windows™ or MacOS® printer driver at:

www.coreinnovationsinc.com/printer

Windows™/MacOS® Setup

- 2. Install the downloaded driver and follow the on-screen instructions
- 3. Connect your printer using the included USB-C® cable (use the USB-C® adapter if
- 4. Start printing by selecting "CTP100LG" from the printer list when prompted

Important Safety Warning

Avoid using or storing in the following locations. Damage to the printer may be caused.

- Do not leave in an exposed area with direct sunlight or near heat-generating equipment.
- Do not leave in an area where temperature or humidity is excessively high or low, or changes
- Do not leave in an area exposed to water or liquid. Avoid dropping or harsh impact to the printer, as damage may be caused
- Avoid entry of foreign objects or materials, as damage
- When cleaning do not use volatile liquid (thinner benzine etc.) or wet cloth. Deterioration or discoloration may occur. Use a drv. soft cloth.
- Do not move the printer or place harsh impact on printer while in printing or standby operation. Printer power may
- disconnect and print data may be lost. When charging your device, gently connect or disconnect charging cable to avoid damage.
- Improper charging can result in damaged printing Please mind the paper cutting teeth. This area is sharp and can cause harm if not careful.
- This device contains small parts and is not recommended
- for kids under 3 years old Adult supervision is recommended for kids under 13
- years old. This equipment is not suitable for use in locations where children are likely to be present Disassembly of printer will cause damage and void
- If severe bulging occurs to battery, please discontinue use

FCC Caution

his device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expres approved by the party responsible for compliance co void the user's authority to operate the equipment. comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This

- equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Regrient or relocate the receiving antenna.
- Increase the separation between the equipment and
- Connect the equipment into an outlet on a circuit
- different from that to which the receiver is connecte
- Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Need Help?

Email us at support@dpaudiovideo.zendesk.com or call us at 1-833-909-CORE (1-833-909-2673). We are available Monday - Friday, 9am-5pm PST, except majo

For information on recycling, please visit https://www.coreinnovationsinc.com/support

© 2024 Core Innovations, All rights reserved. Core

Innovations is a trademark of DP Audio Video.

© 2024 Bluetooth SIG, Inc. All rights reserved. The

the combination mark (Bluetooth word mark and

Bluetooth® trademarks including the BLUETOOTH word

mark, the figure mark (the runic "B" and oval design), and

third party trademarks are the property of their respective

rights reserved. Google, Android and Google Play are trademarks of Google LLC. © 2024 Apple Inc. All rights

reserved. Apple and App Store are trademarks of Apple

design) are owned by the Bluetooth SIG. These and al

owners. Used with permission. © 2024 Google Inc. All

A WARNING: Cancer and Reproductive Harm www.P65Warnings.ca.gov

