

WHM900 Frequency Table

00	915.027455 MHz
01	903.00MHz
02	905.00MHz
03	907.00MHz
04	909.00MHz
05	911.00MHz
06	913.00MHz
07	915.50MHz
08	917.00MHz
09	919.00MHz
10	921.00MHz
11	923.00MHz
12	925.00MHz
13	927.00MHz
14	912.50MHz
15	914.00MHz
16	914.50MHz
17	910.00MHz
18	919.50MHz
19	910.50MHz
20	913.50MHz
21	911.50MHz
22	912.00MHz
23	917.50MHz
24	907.50MHz
25	903.50MHz
26	926.50MHz
27	922.00MHz
28	909.50MHz
29	905.50MHz
30	918.50MHz
31	925.50MHz
32	921.50MHz
33	924.50MHz
34	916.00MHz
35	904.50MHz
36	916.50MHz
37	920.00MHz
38	918.00MHz
39	908.50MHz
40	926.00MHz

41	920.50MHz
42	904.00MHz
43	906.50MHz
44	908.00MHz
45	927.50MHz
46	922.50MHz
47	906.00MHz
48	924.00MHz
49	923.50MHz