




工艺：折页（订装）  
表面覆哑膜  
共22页



1				DIMENSIONAL TOLERANCE				DRAWN BY: 何峥嵘2023. 4. 18	材质:	128g双铜	型号:	说明书			
									CHECKED BY:	数量:		机型:	M8011-8012		
								APPROVED BY:		特殊处理:		料号:			
									3RD. ANGLE'S		UNITS	MM	规格:		版本:
ITEM NO.	DESCRIPTION	DRAWN BY	DATE												
A	B	C	D	E	F	G	H	I	J						

# A1895 Pro Wireless Keyboard

## User Manual



### FCC:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

# CONTENTS

English----- 01-05

한국인----- 06-10

ไทย----- 11-15

Español----- 16-20

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

\*RF warning for Mobile device:


This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

# English

## Product Description




LCD display (including manual switch)



1. Bluetooth status light
2. Caps Lock Indicator
3. Power display
4. Charging indicator
5. Manual Power switch


## Instructions For Use

1. The keyboard will automatically power on after the keyboard is opened from the folded state to 90°, LCD display lights up. Tips: If the display is not bright, please close it and open it again or use manual power on (double-click the '  ' sign on the LCD).


1




2








3





2.Align the tablet with the correct model to the camera hole and place it on the keyboard magnetic bracket.































3.The Bluetooth signal will automatically activate  blink on the LCD screen after booting, turn on the iPad Bluetooth and search for "A1895 Pro" and connect. After the connection is successful, the indicator light  will auto off.









4.After use, close the tablet and keyboard, and the keyboard will automatically shut down.











## Product Description

Purpose	Function Button	Purpose	Function Button
Undo input	 + 	Play / Pause	 + 
Brightness -	 + 	Next song (music)	 + 
Brightness +	 + 	Mute	 + 
Turn on/off Virtual keyboard	 + 	Volume of sound -	 + 
Open search	 + 	Volume of sound +	 + 
Turn on/off Siri	 + 	Keyboard light on/off	 + 
Previous (Music)	 + 	Keyboard light color switch	 + 

## IOS trackpad gestures

 <p><b>Tap:</b> Press with one finger until you felt a little click</p>	 <p><b>Tap and hold:</b> Press and hold with one finger</p>
 <p><b>Drag:</b> Tap and hold an item, then swipe your finger across the trackpad to move it</p>	 <p><b>Go to the Home Screen:</b> Swipe the pointer across the bottom of the screen with one finger. Once the Dock appears, swipe the pointer across the bottom of the screen again. Or tap the bar at the bottom of the screen</p>
 <p><b>Open the Dock:</b> Swipe the pointer across the bottom of the screen with one finger</p>	 <p><b>Open Control Center:</b> Move the pointer with one finger to select the status icon in the upper right, then tap. Or select the status icon in the upper right, then swipe up with one finger</p>



 <p>Scroll up or down: Swipe up or down with two fingers</p>	 <p>Scroll left or right: Swipe left or right with two fingers</p>
 <p>Open Search from Swipe down with two fingers</p>	 <p>Zoom: Place two fingers close together. Pinch to zoom in, or pinch to zoom out</p>
 <p>Open the Today view: When the Home or Lock screen is visible swipe right with two fingers</p>	 <p>Switch between open apps: Swipe left or right with three fingers</p>
 <p>Go to the home screen: Swipe up with three fingers</p>	 <p>Open the App Switcher: Swipe up with three fingers, pause, then lift your finger. Or pinch with four fingers, pause and lift your fingers</p>

## Tips:

- iPad operating system: IOS 15.0 and above.
- Sensitivity setting: Settings→General→Touchpad→Tracking speed (adjust to a suitable speed).
- Abnormal touch function:
  - (1) Settings→Accessibility→Touch→AssistiveTouch is turned on or off.
  - (2) When there is no mouse icon on the tablet screen, you can double-finger zoom once to restore the touchpad.


## Indicator lights and other function descriptions






1. Power on / off: Double-click the "  " power key or unfold the keyboard at 90° to power on, and fold it to 0° to power off.
2. Power display: "  " power display value 0%-100%

3.Charging display light: "  " charging white light is breathing and flashing, fully charged white light is always on.

4.Caps Lock Indicator: In the uppercase input mode, the indicator light "  " displays the character A in uppercase, and does not display in the lowercase input mode.

5.Bluetooth connection: After the keyboard is turned on, it automatically enters the pairing state and releases the Bluetooth signal light.If the Bluetooth signal light disappears after not being connected for a long time, press and hold "  " for 3 seconds to re-enter the pairing mode, and the Bluetooth signal light flashes at the same time, turn on the tablet and turn on the Bluetooth function, find "A1895 Pro", and click pairing.

6.Low battery reminder: When the battery is lower than 20%, the % symbol flashes on the display.

7.Reset: Press and hold  +  +  at the same time to restore factory settings.

## Product Parameters

Brand Name	Goojodoq
Model	<b>A1895 Pro</b>
Lithium battery capacity	<b>600mAH</b>
Charging time	≥3 hours
Charging current	<b>400mA</b>
Working voltage	3.3–4.2V
Lights out working current	<10mA
Working current in backlight mode	≥ <b>77mA</b>
Continuous working time with backlight on	≥ <b>6-8</b> hours
Light off continuous working time	≥ <b>100</b> hours
Standby time	≥1500 hours
Backlight sleep time	<b>60</b> seconds
Keyboard sleep time	10 minutes

## Tips

1. Please store and use the product at room temperature.
2. Do not disassemble, repair and remodel the product by yourself.
3. Do not expose this product to rain or wet environment.
4. Do not use chemical solvents to wipe this product.
5. Do not throw, to avoid product damage due to falling.
6. If not used for a long time, charge the product every 2 months.
7. Do not throw it away at will, or put it in a fire at high temperature, so as not to cause danger.




# 한국인

## 제품 설명



LCD 디스플레이(수동 스위치 포함)



1. 블루투스 상태 표시등
2. Caps Lock 표시기
3. 전원 표시
4. 충전 표시기
5. 수동 전원 스위치

## 사용 지침


1. 키보드가 접힌 상태에서 90°로 열리면 키보드가 자동으로 켜지고 LCD 디스플레이가 켜집니다.

팁 : 디스플레이가 밝지 않으면 닫았다가 다시 열거나 수동 전원을 켜기를 사용하십시오(LCD에서 '🔌' 기호를 두 번 클릭).


1




2




3




2. 올바른 모델의 태블릿을 카메라 구멍에 맞추고 키보드 마그네틱 브래킷에 놓습니다.



3. 블루투스 신호는 부팅 후 LCD 화면에서 자동으로 " " 감박임을 활성화하고 iPad 블루투스를 켜고 "A1895 Pro"를 검색하고 연결합니다. 연결이 성공하면 표시등 " "가 자동으로 꺼집니다.









4. 사용 후 태블릿과 키보드를 닫으면 키보드가 자동으로 종료됩니다.











## 제품 설명

목적	기능버튼	목적	기능버튼
입력 취소		재생/일시정지	
밝기 -		다음 곡(음악)	
밝기 +		음소거	
가상 키보드 켜기/끄기		소리의 크기 -	
검색 열기		소리의 볼륨 +	
시리 켜기/끄기		키보드 표시등 켜기/끄기	
이전(음악)		키보드 표시등 색상 스위치	

## IOS 트랙패드 제스처

 <p>탭: 약간 딸깍 떨어질 때까지 한 손가락으로 누릅니다.</p>	 <p>탭 앤 홀: 한 손가락으로 길게 누르기.</p>
 <p>끌기: 항목을 길게 탭한 다음 손가락으로 트랙패드를 쓸어넘겨 이동합니다.</p>	 <p>홈 화면으로 이동: 한 손가락으로 화면 하단에서 포인터를 밟니다. Dock이 나타나면 포인터를 화면 하단에 다시 바릅니다. 또는 화면 하단의 바를 탭하세요.</p>
 <p>Dock 열기: 한 손가락으로 화면 하단에서 포인터를 스와이프합니다.</p>	 <p>제어 센터 열기: 한 손가락으로 포인터를 이동하여 오른쪽 상단에 있는 상태 아이콘을 선택한 다음 탭하십시오. 또는 오른쪽 상단의 상태 아이콘을 선택한 다음 한 손가락으로 위로 살짝 밟습니다.</p>

 <p>위 또는 아래로 스크롤: 두 손가락으로 위 또는 아래로 스와이프</p>	 <p>왼쪽 또는 오른쪽으로 스크롤: 두 손가락으로 왼쪽 또는 오른쪽으로 스와이프</p>
 <p>두 손가락으로 아래로 스와이프하여 검색 열기</p>	 <p>확대/축소: 두 손가락을 서로 가까이 놓습니다. 확대하려면 핀치하고, 축소하려면 핀치합니다.</p>
 <p>오늘 보기 열기: 홈 또는 잠금 화면이 표시될 때 두 손가락으로 오른쪽으로 스와이프</p>	 <p>열려 있는 앱 간 전환: 세 손가락으로 왼쪽 또는 오른쪽으로 스와이프</p>
 <p>홈 화면으로 이동: 세 손가락으로 위로 스와이프</p>	 <p>앱 전환기 열기: 세 손가락으로 위로 쓸어넘기고 잠시 멈춘 다음 손가락을 뗍니다. 또는 네 손가락으로 오므렸다가 잠시 멈춘 후 손가락을 뗍니다.</p>

## 팁:

·iPad 운영 체제: IOS 15.0 이상.

·감도 설정: 설정→일반→터치패드→추적 속도(적절한 속도로 조정).


·비정상적인 터치 기능:

(1) 설정→접근성→Touch→AssistiveTouch를 켜거나 끕니다.







(2) 태블릿 화면에 마우스 아이콘이 없을 때 더블 핑거 줌을 한 번 하면 터치패드가 복원됩니다.

## 표시등 및 기타 기능 설명



1.전원 켜기/끄기: "  " 전원 키를 두 번 클릭하거나 키보드를 90°로 펴서 전원을 켜고 0°로 접어 전원을 끕니다.

2. 전원 표시: "  " 전원 표시 값 0%-100%

- 충전 표시등: "  " 충전 흰색 표시등이 숨쉬고 깜박이며 완전히 충전된 흰색 표시등이 항상 켜져 있습니다.
- CapsLock 표시등: 대문자 입력 모드에서 표시등 "  "는 문자 A를 대문자로 표시하고 소문자 입력 모드에서는 표시하지 않습니다.
- 블루투스 연결: 키보드가 켜지면 자동으로 페어링 상태로 들어가 블루투스 신호등을 해제합니다. 오랫동안 연결하지 않은 후 블루투스 신호등이 사라지면 "  "를 3초 동안 길게 눌러 페어링 모드로 다시 들어가고 블루투스 신호등이 동시에 깜박입니다. 태블릿을 켜고 블루투스 기능을 켜고 "A1895 Pro"를 찾아 페어링을 클릭합니다.
- 배터리 부족 알림: 배터리가 20% 미만이면 디스플레이에 % 기호가 깜박입니다.
- 재설정: "  +  +  "를 동시에 누르고 있으면 공장 설정으로 복원됩니다.

## 제품 매개변수

브랜드명	Goojodoq
모델명	A1895 Pro
리튬 배터리 용량	600mAH
충전 시간	≥3 시간
충전 전류	400mA
작동 전압	3.3-4.2V
소등 작동 전류	<10mA
백라이트 모드에서 작동 전류	≥77mA
백라이트가 켜진 상태에서 연속 작업 시간	≥6-8시간
소등 연속 작업 시간	≥100시간
대기 시간	≥1500 시간
백라이트 절전 시간	60초
키보드 절전 시간	10 분


## 팁

- 상온에서 보관 및 사용하십시오.
- 제품을 임의로 분해, 수리, 개조하지 마십시오.
- 본 제품을 비나 젖은 환경에 노출시키지 마십시오.
- 화학 용제를 사용하여 본 제품을 닦지 마십시오.
- 낙하로 인한 제품 손상을 방지하기 위해 던지지 마십시오.
- 장기간 사용하지 않을 경우 2개월마다 제품을 충전해 주십시오.
- 임의로 버리거나 고온의 불 속에 넣지 마십시오. 위험하지 않습니다.

## รายละเอียดสินค้า



จอแสดงผล LCD (รวมถึงสวิตช์แบบแมนนวล)



1. ไฟแสดงสถานะบลูทูธ
2. ตัวบ่งชี้ Caps Lock
3. จอแสดงผลพลังงาน
4. ไฟแสดงสถานะการชาร์จ
5. สวิตช์ไฟด้วยตนเอง


## คำแนะนำสำหรับการใช้งาน

1. แป้นพิมพ์จะเปิดโดยอัตโนมัติหลังจากเปิดแป้นพิมพ์จากสถานะพับเป็น 90° , จอ LCD จะสว่างขึ้น เคล็ดลับ : หากจอแสดงผลไม่สว่าง โปรดปิดและเปิดใหม่อีกครั้งหรือเปิดเครื่องด้วยตนเอง (ดับเบิลคลิกที่เครื่องหมาย '  ' บน LCD)

1



3



2

