

**CW-ARBT20SKI-CRM User Manual**  
03-2024

**(Fold Inward)** — — — — 

(Back)

(Front Cover)

[illegible]

Page 01

## Before You Begin

**Caution**

## Getting Started

### Tech Specifications

### Wireless Mouse

- In the box:
  - Wireless Mouse
  - Nano USB Receiver
  - User Manual

### Battery Requirements:

3 x AAA Batteries (not included)

### Product Specifications:

Product Name: Wireless Mouse  
Model Number: WM001-2024  
Manufacturer: Wireless Mice Co.  
Interface: USB  
Transmission Distance: 10 meters

To ensure easy and proper use, please follow the following instructions when using the wireless mouse. Read the user manual for details, diagrams, and warnings.

- THE DEVICE IS HOT TO USE** – Do not touch the device or try to use it. It is too hot.
- Do not disassemble, modify, or repair the device.**
- Do not recharge in water.**
- Do not use the unit to enhance temperatures (hot or cold), over heat, burn, freeze, or over condition.

Do not use the USB ports, above and below the edge of the device to be connected to. Do not connect the device directly connected with any electronic equipment like mobile phone, tablet, computers, etc.

### Mouse & Keyboard Use:

Step 1: Insert 3 x AAA batteries into the wireless mouse (not included).

Step 2: Plug the included nano USB receiver into your computer's USB port.

Step 3: Click the left and right mouse buttons, or the keyboard buttons to work.



### Wireless Keyboard

Notes:

- 2.4 GHz Wireless Keyboard
- 24 Keys Full Size Keyboard
- Carbon Fiber Construction
- Keyboard Frequency: 40.713 MHz/2.4GHz
- Keyboard Frequency: 4000-110
- System Support: Windows 10/8/7/XP/2000/2003/2008/2010/11/12/13/14/15/16/17/18/19/20 system
- Not compatible with Linux

### Wireless Mouse

Notes:

- 2.4 GHz wireless mouse
- Easy Plug & Play
- 8KHz Resolution 2.4GHz
- Resolution: 1000 DPI
- System Support: Windows 10/8/7/XP/2000/2003/2008/2010/11/12/13/14/15/16/17/18/19/20 system
- Not compatible with Linux

Note: The mouse & keyboard after 1 minute without use. When you click the mouse button or keyboard buttons, they will stop working again.

**CW-ARBT20SKI-BLS User Manual**  
03-2024

**(Fold Inward)** — — — — 

(Back)

(Front Cover)

**Free Online Support**

The device can be used with both Windows and Mac OS.

**Software:** The device is compatible with Windows XP and Mac OS. The user's manual provides detailed information on the software and the device's operation.

**Warranty:** The device is covered by a 3-year warranty. The warranty is valid only for the original purchaser and is not transferable. The warranty is void if the device is used for commercial purposes or if it is damaged by fire, flood, or other external factors.

**Technical Support:** For technical support, please visit our website at [www.colorways.com](http://www.colorways.com). You can also contact our customer service team at 1-800-555-1234.

**Warranty Information**

**3-Year Limited Warranty:** The device is covered by a 3-year limited warranty. The warranty is valid only for the original purchaser and is not transferable. The warranty is void if the device is used for commercial purposes or if it is damaged by fire, flood, or other external factors.

**Exclusions:** The warranty does not cover damage caused by misuse, accident, or neglect. It also does not cover the cost of shipping or handling fees.

**How to Claim:** To claim the warranty, you must provide proof of purchase and a description of the problem. Please contact our customer service team for more information.



**colorways**

**Wireless Mouse & Keyboard Combo**

Page 01

## Before You Begin

**Caution**

## Getting Started

### Tech Specifications

[illegible]

**CW-ARBT20SKI-TAN User Manual**  
03-2024

(Fold Inward) - - - - ►

(Back)

(Front Cover)

[illegible]

Page 01

## Before You Begin

**Caution**

## Getting Started

### Tech Specifications

[illegible]