





KM-300说明书

尺寸: 135 X 90mm (折后尺寸)
工艺: 双面印刷, 105g铜版纸.

<div>135mm</div> <div>90mm</div>					KM-300说明书 尺寸: 135 X 90mm (折合尺寸) 工艺: 双面印刷, 105g铜版纸																																
<div>KM-300</div> <div>Bluetooth Speaker Product Manual</div> <div></div>		<div>KM-300</div> <div>Thank you for purchasing the KM-300. Please read this user manual carefully for any questions and difficulties. Please note that the play time depends on the selected volume level. The speaker supports Bluetooth wireless technology, TF card, USB2.0 and AUX audio cable function.</div>		<div>Package Contents</div> <div><ul style="list-style-type: none">• Bluetooth Speaker x1• TYPE-C Charging cable x1• Standard audio cable x1• Product manual x1</div> <div></div>		<div>Functions:</div> <div><ul style="list-style-type: none">• Answer Incoming Calls: Short press the "D" Button• End Calls: Short press the "D" Button• Reject Incoming Calls: Long press the "D" Button• Redial: Quickly press "D" twice to call back the last call• Switch Modes: Short press the M button to select modes(Bluetooth/AUX/TF Card/USB2.0)• Volume Increase: Short press the " + " button in steps for increasing the volume• Volume Decrease: Short press the " - " button in steps for decreasing the volume• Play/Pause: Short press the "D" to play or pause the tracks• Previous Track: Long press the " - " button for returning to the previous track• Next Track: Long press the " + " button for skipping to the next track• RGB Function: Long Press M button for switch on and off RGB light, Double click on M button to switch between RGB light modes</div>		<div>Bluetooth Connectivity:</div> <div><ul style="list-style-type: none">• Turn the speaker on. Its LED indicator blinks white until the pairing is done• Activate the phone's Bluetooth function and search for KM-300. As soon as the speaker gets selected and paired by you, the connection gets indicated by a sound prompt.</div> <div>Note:</div> <div><ul style="list-style-type: none">• If you are having connection troubles, then remove KM-300 from the list of paired devices on your phone, keep the phone closer to the speaker and try pairing again</div> <div>AUX Mode:</div> <div><ul style="list-style-type: none">• You can switch to AUX mode by using the AUX cable to connect the phone and the speaker, and then short pressing the M button• In AUX mode, you can control audio playback media through the device (cannot answer calls, and the speaker cannot control mobile phones)</div>																													
<div>TWS:</div> <div>You can connect two KM-300 and virtually forge them into one speaker for a greater impact.</div> <div>For TWS connection:</div> <div><ul style="list-style-type: none">• Turn on both the speakers• Press and hold on the "D" one of the two speakers for about 2 seconds until you hear a beep• After releasing "D", it may take a few more seconds for the speakers to connect• Activate the phone's Bluetooth function and search for KM-300 to establish pairing</div> <div>Charging:</div> <div><ul style="list-style-type: none">• KM-300 beeps once every 5 minutes when the battery is low. After three such indications, the speaker automatically turns off• Use the provided charging cable to charge the speaker• When the speaker is charging, the LED indicator turns steadily red. When the speaker is fully charged, the indicator light is green</div>		<div>Note:</div> <div>Please avoid using the speaker while it is in charge as it may decrease the battery's performance</div> <div>Specifications:</div> <div><table><tr><td>Speaker Type:</td><td>Portable Wireless Speaker</td><td>Frequency:</td><td>20Hz-20kHz</td></tr><tr><td>Bluetooth Version:</td><td>V5.0</td><td>SNR:</td><td>104dB</td></tr><tr><td>Working Range:</td><td>10m</td><td>Output Power:</td><td>40W</td></tr><tr><td>Water Resistance:</td><td>IPX4</td><td>Input Voltage:</td><td>5V/2.5A(MAX20W)</td></tr><tr><td>Speaker Size:</td><td>2.75" x2</td><td>Play Time:</td><td>4-25 hours</td></tr><tr><td>Audio input:</td><td>BT/TF/AUX/USB2.0</td><td>Charging Time:</td><td>3.5-7 hours</td></tr><tr><td>Battery:</td><td>4000mAh</td><td></td><td></td></tr></table></div> <div>Power ON/OFF</div> <div>You may long press the power button to switch the speaker ON/OFF.</div>		Speaker Type:	Portable Wireless Speaker	Frequency:	20Hz-20kHz	Bluetooth Version:	V5.0	SNR:	104dB	Working Range:	10m	Output Power:	40W	Water Resistance:	IPX4	Input Voltage:	5V/2.5A(MAX20W)	Speaker Size:	2.75" x2	Play Time:	4-25 hours	Audio input:	BT/TF/AUX/USB2.0	Charging Time:	3.5-7 hours	Battery:	4000mAh			<div>Warning:</div> <div><ul style="list-style-type: none">• Please charge the speaker according to the charging norms mentioned on packaging to protect the battery• Do not disassemble the product• Do not submerge the product inside water• Please keep this product safe from coming in contact with any liquid• Don't use/store this product in extreme temperatures• Please keep the product away from anything that generates heat, such as radiators, stoves, etc.• In order to have hearing protection and an extended speaker life, avoid listening to songs on maximum volume• Don't try to dismantle/repair the product on your own.</div> <div><small>This device should be installed and operated with a minimum distance of 15cm between the device and the user.</small></div> <div><small>This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.</small></div>		<div>These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</div> <div>If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</div> <div><ul style="list-style-type: none">--Reorient or relocate the receiving antenna.--Increase the separation between the device and receiver.--Connect the device into an outlet on a circuit different from that to which the receiver is connected.--Consult the dealer or an experienced radio/TV technician for help</div> <div>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment</div>		<div></div>	
Speaker Type:	Portable Wireless Speaker	Frequency:	20Hz-20kHz																																		
Bluetooth Version:	V5.0	SNR:	104dB																																		
Working Range:	10m	Output Power:	40W																																		
Water Resistance:	IPX4	Input Voltage:	5V/2.5A(MAX20W)																																		
Speaker Size:	2.75" x2	Play Time:	4-25 hours																																		
Audio input:	BT/TF/AUX/USB2.0	Charging Time:	3.5-7 hours																																		
Battery:	4000mAh																																				