

# User's Manual

BLUETOOTH SPEAKER  
Model NO.:W25




## Basic Specification

- \*BT version:JL5.3
- \*Material:ABS
- \*Output power (RMS):5W
- \*Battery capacity:400mAh
- \*Charging time:1-2 H
- \*Working hour:3-4 H
- \*Speaker driver size:52mm
- \*Product Size: 99\*41\*95mm

## Product Feature

- \*Bluetooth music playback
- \*Hands Free call
- \*RGB light.

## Instruction of Buttons



- 1.Power on/off.
- 2.Short press previous song,Long press decrease the volume.
- 3.Short press next song,Long press increase the volume.
- 4.Play, pause.
- 5.Answer the phone/Hang up the phone.
- 6.TYPE-C charging port.

1

## Operation Instruction

- 1.Bluetooth connection: Turn on the W27 Bluetooth speaker and switch to Bluetooth mode, search for the Bluetooth name "W27" with your mobile phone or other devices and connect, and the connection will be successful. when you hear the prompt tone.
- 2.RGB light switching:When W25 is on, Short press 1 to change the RGB mode,there are 2 light modes.
- 3.Hands Free call:Short press 5 to answer the phone or hang up,long press 5 to refuse the answer.
- 4.Charging tip: Insert the USB cable into the TYPE-C charging port, the red light is on to indicate charging, and the red light is off to indicate that the charging is complete.

## Common problems and solving methods

1. After playing for a long time,the device will often turn off in auto. The battery is insufficient, please charge it to full power and them turn on.
2. The device does not work very well whether beyond the effective distance of Bluetooth connection,or some barriers on there.
3. Can not connect the Bluetooth Is the Bluetooth in search-able mode or not,or reboot the speaker. There are too many Bluetooth devices around you, try to turn off them.

## Attention

1. Use this product under normal temperature environment.
2. Do not play in the wet environment.
3. Avoid the damage of falling.
4. Do not dismantle or repair the speaker by yourself.
5. Built-in battery,do not throw the speakers in the fire.

2

# 用户说明书

BLUETOOTH SPEAKER  
Model NO.:W25




## 基本参数

- \*蓝牙版本:5.3
- \*产品材质:ABS
- \*输出功率:5W
- \*电池容量:400毫安
- \*充电时长:1~2 H
- \*播放时长:3~4 H
- \*喇叭尺寸:52mm
- \*产品尺寸:99\*41\*95mm

## 产品功能

- \*蓝牙音乐播放
- \*支持蓝牙通话
- \*RGB灯效

## 按键以及接口说明



- 1.长按电源开启/关闭；短按切换RGB灯效。
- 2.短按切换上一首歌曲；长按降低音量。
- 3.短按切换下一首歌曲；长按增加音量。
- 4.音乐播放/暂停。
- 5.接听电话/挂断电话。
- 6.长按开机或关机；短按暂停或播放；双击按键切换收音机模式。
- 7.TYPE-C充电口。

1

## 操作说明

- 1.蓝牙连接：将W25蓝牙音响开启并切换到蓝牙模式，用手机或其他设备搜索蓝牙名称"W25"并连接，听到提示音即连接成功。
- 2.RGB灯光切换：开启W25的情况下，短按 1 进行切换，共有2种灯光模式。
- 3.蓝牙通话：短按 5 接听或挂断电话，长按 5 拒绝接听电话。
- 4.充电提示：将USB线插入TYPE-C充电口，红灯亮表示充电，红灯熄灭表示充电完成。

## 常见问题及解决方法

- 1.长时间播放后，设备经常会自动关闭。电池电量不足，请将其充满电后再开机。
- 2该设备不工作得很好是否超出了蓝牙连接的有效距离，或在那里的一些障碍。
- 3无法连接蓝牙是否蓝牙处于可搜索模式或重新启动扬声器。你身边的蓝牙设备太多了，请关掉部分蓝牙设备。

## 注意

- 1.常温环境下使用本产品。
- 2.不要在潮湿的环境下玩耍。
- 3.避免坠落造成的伤害。
- 4.请勿自行拆卸或修理扬声器。
- 5.内置电池，请勿将扬声器扔进火中。

2

## FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

### RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.