



VIMOTO Motorcycle Communication System

VIMOTO WILD BTR Quick Guide



(WILD BTR)



(WILD V10X/V10S)





Bluetooth



Product Overview

Indicator Light

Mainboard Button

Charging Port (Type-C)

Volume Up Button

Multi Function Button

Bluetooth Intercom Button

Volume Down Button



Important Note:
Before using headphones, please pair morboard and Remote first. When performing subsequent operations, ensure that morboard and remote remain connected to guarantee normal functionality.

Indicator Light

Pairing In Progress

Red & Blue Lights Alternating

Charging

Red Light Solid

Charging Complete

Red Light Off

Multi-Riders Intercom (Private Mode)
Group Remote In Progress

Intercom Light Fast Blink

Bluetooth Multi-Riders / Dual-Riders Intercom Intercom In Progress

Intercom Light Slow Blink

Pairing In Progress

Red & Blue Lights Alternating

Disconnected

Blue Light Slow Blink (Low Battery, Red Light Slow Blink)

Intelligent Voice Active

Blue Light Fast Blink (Low Battery, Red Light Fast Blink)

Connected (Phone/DODO/Adapter)

Blue Light Double Blink (Low Battery, Red Light Double Blink)

In Call/DODO Intercom

Blue Light Triple Blink (Low Battery, Red Light Triple Blink)

Awaiting Reconnection

Blue Light Fast Blink (Low Battery, Red Light Fast Blink)

Power On/Off & Factory Reset

Power On/Off

Long Press(3s)

(Power-Off State)
Power On

(Power-On State)
Power Off

Blue Light Illuminates For 1s n Turns Off

Power On Prompt Tone

Red Light Illuminates For 1s n Turns Off

Power Off Prompt Tone

Factory Reset (Ensure Mainboard & Remote Connected)

Simultaneous Button Press(3s)

Red And Blue Lights Solid For 2s

"Factory Reset Complete"

Note: Device Will Automatically Power Off After A Successful Factory Reset.

Pairing Of Mainboard And Remote

Mainboard Start Pairing (Power-Off State)

Long Press(6s) To Star Pairing (Mainboard)

Note: Auto Cancel Pairing After 120s.

Remote Start/Cancel Pairing

Press And Hold Both Buttons For 3s To Star/Cancel Pairing (Remote)

Pairing Of Mainboard&Remote

Long Press(6s) To Star Pairing (Mainboard)

Long Press(3s) To Pair (Remote)

Quick Pairing (Before Pairing, Ensure Mainboard & Remote Are Connected)

Pair With Phone

Long Press(3s) To Pair (Remote)

Bluetooth Search & Pair (Phone)

Pair With DODO

Note: Pair With DODO After Phone Pairing.

Long Press(3s) To Pair (Remote)

Bluetooth Search & Pair (DODO)

Cancel Pairing

Long Press(3s) To Cancel Pairing (Remote)

Reconnect

Auto-Reconnect Power On

Long Press(3s)

Note: Auto-Reconnect To Phone/Adapter On Power-On.

Manual Reconnect 1

Short Press (Mainboard)

Awaiting Reconnection (Phone)

Manual Reconnect 2

(Remote)

Note: After Morboard Is Turned On, When Remote Control Board Is Paired Without Connection, Press Any Key To Connect Back.

Battery Level Audio Announcement

Auto Power On Alert

Long Press(3s)

Note:Power On Auto- Battery Report.

Auto Low Battery Alert

(Battery <15%, Announces Every 10 Mins)

"Low Battery, Please Charge"

Manual Battery Alert

(Idle)

Long Press(1s)

Or

(Idle)

Long Press(1s)

Low Battery Auto-Off

(Battery <5%, Auto-Shutdown in 10s)

"Low Battery, Shutting Down Soon"

Call

Answer Call

(Incoming Call)

Short Press

End Call

(Call In Progress)

Short Press

Activate Voice Assistant

(No Call/DODO Intercom)

Double Press

Voice Command: [Xiao Wei, Xiao Wei]

Deactivate Voice Assistant

(Voice Assistant Active)

Double Press

Reject Call

(Incoming Call)

Long Press(1s)

Cancel Call

(Outgoing Call)

Short Press

Unmute Microphone

(Microphone Muted)

Long Press(1s)

"Microphone On"

Mute Microphone

(Call In Progress)

Long Press(1s)

"Microphone Muted"

Enable Auto Answer

(With Auto Answer Disabled)

Simultaneous Button Press(1s)

"Auto Answer Enabled"

Disable Auto Answer

(With Auto Answer Enabled)

Simultaneous Button Press(1s)

"Auto Answer Disabled"

Increase Call Volume

(Call In Progress)

Short Press

Decrease Call Volume

(Call In Progress)

Short Press

Music

Play Music

(When Music Is Paused)

Short Press

Pause Music

(When Music Is Playing)

Short Press

Previous Track

(When Music Is Playing)

Long Press(1s)

Next Track

(When Music Is Playing)

Long Press(1s)

Increase Music Volume

(When Music Is Playing)

Short Press

Decrease Music Volume

(When Music Is Playing)

Short Press

Background Music Playback

DODO Intercom & Music Mixed

Listen To Music While Using DODO Intercom

Bluetooth Multi-Riders Intercom & Music Mixed

Listen To Music Bluetooth Multi-Riders Intercom

Bluetooth Dual-Riders Intercom & Music Mixed

Listen To Music Bluetooth Dual-Riders Intercom

DODO Intercom

Increase Intercom Volume

(DODO Intercom In Progress)

Short Press

Decrease Intercom Volume

(DODO Intercom In Progress)

Short Press

Bluetooth Multi-Riders Intercom

Public Mode

Intercom Light Slow Blink

"Multi-Riders Intercom Public Mode" (Auto-Connect, Announces "X People" When Number Changes)

When Public Mode Is Enabled, Device Will Automatically Connect To Riders Within Discoverable Bluetooth Range. (Up To 8 Riders)



Create An Intercom Group

1. Intercom Light Fast Blink

"Multi-Riders Intercom Group Started" (Riders Who Need To Join/Create An Intercom Group)

2. Auto-Connect

"Intercom Group Members: X"

3. Confirm That All Riders Are Fully Connected Based On Audible Prompt

Any Member: Short Press To Save Network

4. Group saved, device stars private mode.

Intercom Light Slow Blink

"Intercom Group Created Successfully"

Cancel Intercom Group

Long Press(3s)

"Cancel Multi-Riders Intercom Group Remote"

Unmute Microphone

(Microphone Muted)

Long Press(1s)

"Microphone On"

Mute Microphone

(Multi-Riders Intercom)

Long Press(1s)

"Microphone Muted"

Increase Intercom Volume

(No Music In Multi-Riders Intercom)

Short Press

Decrease Intercom Volume

(No Music In Multi-Riders Intercom)

Short Press

Bluetooth Dual-Riders Intercom

Pairing: Compatible With V10x/V10s/XR/V9X/V9S/V8S (Both Headset 1 And Headset 2 Must Perform The Step)

1. Long Press(3s)

Red & Blue Lights Alternating

"Please Pair"

2. Short Press

Red & Blue Lights Alternating

Intercom Light Fast Blink

"Dual-Riders Intercom Pairing"

3. Automatic Pairing

Microphone Muted

Long Press(1s)

"Microphone On"

Mute Microphone

4. Dual-Rider Intercom ParingSuccessful, Intercom Headset Connected"

Long Press(1s)

"Microphone Muted"

Cancel Pairing

Long Press(3s)

"Cancel Pairing" "Cancel Dual-Person Intercom Pairing"

Unmute Microphone

(Microphone Muted)

Long Press(1s)

"Microphone On"

Mute Microphone

Increase Intercom Volume

(No Music During Dual-Person Intercom)

Short Press

Decrease Intercom Volume

(No Music During Dual-Person Intercom)

Short Press

Intercom Mode Switching

Multi-Riders Intercom Private Mode

Multi-Riders Intercom Public Mode

Dual-Riders Intercom

Intercom Off

Short Press

DODO Intercom

Multi-Riders / Dual-riders Intercom

Double Press

Note:

1. DODO Intercom: RDODO Intercom Can Only Be Switched To When Device Is In Foreground With Screen Active.

2. Switch Back To Last Used Intercom Mode (Multi-Riders Or Dual-Riders).

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.