

## TRITON

### SETUP

Fully charge Power Bank before first use with the included cable.

While charging, the display continually shows battery capacity as follows:

- 1 flashing LED = < 25% capacity
- 1 solid LED, 1 flashing LED = 25-50% capacity
- 2 solid LEDs, 1 flashing LED = 50-75% capacity
- 3 solid LEDs, 1 flashing LED = 75-99% capacity
- 4 solid LEDs = 100% capacity

When not charging, press the button to view capacity:

- No LEDs = 0% capacity
- 1 flashing LED = 0-10% capacity
- 1 solid LED = 10-25% capacity
- 2 solid LEDs = 25-50% capacity
- 3 solid LEDs = 50-75% capacity
- 4 solid LEDs = 75-100% capacity

### WIRELESS CHARGING

1. Attach Power Bank to MagSafe-compatible iPhone and/or case.
2. Press the button at the bottom to turn on Power Bank.
3. Charge indicator appears in the upper right corner of the phone (standard function), and the first Power Bank LED displays green during charging.
4. Power Bank auto-stops charging when the phone is full.
5. To manually stop charging, press and hold the button.

Note: The wireless output is automatically enabled when connected to a power source.

### DUAL-DIRECTION CABLE CHARGING

- To charge a device with Power Bank via a USB-C cable:
  - Plug the cable into Power Bank and then into the device.
  - Charging starts automatically. If it does not, press the button to initiate charge.
- Recharge Power Bank with a USB-C cable and charger.

### REMOVING POWER BANK

- Remove Power Bank from the phone with one hand, using a twist motion from the bottom.

### CHARGING STAND

- Plug the cable into the port on the stand and into the supplied wall adapter.
- Plug the wall adapter into the wall.
- To charge Power Bank, press it into the charging stand.
- Ensure Power Bank is fully inserted into the stand and contacts the charging pins.
- LEDs on Power Bank illuminate to indicate charging.

### CAR MOUNT

- To install the Car Mount:
  - Loosen nut and snap ball into mount.

- Press button, place mount in desired location and release button to lock in position. Ensure the clamp lip is behind the vent fin.
    - Adjust angle and tighten nut to secure.
  - To remove the Car Mount:
    - Press on power bank through circle opening on the mount.
  - To remove the battery from the Car Mount:
    - Locate the small hole on the back of the mount.
    - Press finger through hole to release the battery.
    - Remove the battery from the mount.
-