## **Translator**



# **Manual**



Welcome to use the smart translator. It is recommended that you read the instructions carefully before using the translator.

#### **About**

Smart translators are not only language translators, business translators, and travel translators. Through smart translators, you can meet friends ar ound the world, and make friends and chat with foreigners around the world without language barriers. It is also a multi-language learning machine for children to help children learn multi-language and enhance their language ability.

### **Features**

Long use time, high capacity battery.

Loud & high sound quality speakers, adapted to public and noisy environ ment.

3.0 inch touch screen + 5 M pixel camera.

Support multi-languages translation, high correct rates with rapid respons e time.

The menu is concise and the operation is simple.

## Quick guide:

Before using the translator, please follow the following simple steps: Please check the packaging accessories first.

Please try to ensure that you use it in a wireless network environment. If there is no wireless network, you can also use the offline translation function.

#### Wireless network

After the device is turned on, connect to the wireless network, find the menu "Settings"-"WIFI", and then log in and connect to the wireless network.

## **Device charging**

When the battery is low, the battery icon in the status bar at the top of the screen will change to a low battery icon. When the battery is low, s ome functions of the device may not be available. When the battery pow er is lower than 3.4V, the device will automatically shut down. At this tim e, you need to charge the device to continue using it.



## **Button function introduction**

On/off button: short press lock screen or wake up the screen, Long pres s to power off\on.

Translate A, B Button: Long press to enter voice recognition mode

Back button: return to the previous page.

Charging Port: charging

## Power on and off

Power on: Press and hold the device power button until the screen displays the startup screen. It takes a certain amount of time to initialize the device, please wait patiently

Shut down: long press the device switch button, a dialog box pops up, c lick The "Shutdown" option can turn off the device.

#### screen savers

#### Turn off or turn on the screen manually:

- · When the screen is on, press the power button to turn off the screen.
- · When the screen is off, press the power button to turn on the screen.

## Turn off the screen automatically:

If there is no operation on the device during the default standby time of the system, the device will automatically turn off the screen. Short pres s the power button to turn on the screen.

#### Status Bar

The top of the device screen displays some status information about the device, such as: WIFI network status, Bluetooth, power, and time information.

#### Main function introduction:

#### Online translation/offline translation:

The translation function has two modes: online translation and offline translation, which will automatically switch according to the current status of the translation machine.

Online translation currently supports real-time translation between languag es in more than 100 countries and regions (will change with version upd ates).

Offline translation currently supports more than 10 popular languages for offline translation (will change with version updates). When the translation n machine is offline, the translation is automatically switched to offline translation. (Please download the corresponding offline translation package in advance before use)

On the translation homepage or on the translation interface, click the lan guage button to enter the language selection list, and click the source la nguage\target language option you need.

#### **Speech Recognition:**

Long press the translation A button or the translation B button on the de vice to enter the voice recognition state, release the translation button to automatically recognize and analyze the voice, and automatically translat e into the set target language and broadcast the voice. The list shows t he text records of voice translation. When there are too many translation records, swipe the page up and down to view the translation records.

#### Collection:

Long press the translation result to pop up the option, click the favorite to succeed, select the favorite on the main interface to enter the favorite page to view the favorite record, click the favorite record on the favorite page to broadcast the voice, long press to delete the favorite.

Note: currently supports a maximum of 50 translation result collections

#### Audio Recording translation:

Recording recognition: click on the voice icon just below the recording in terface to start recording;

Recording result saving: Click the stop icon just below during recording, a confirmation box for saving operation pops up, and the recording file is automatically saved after clicking confirm.

Click the icon in the upper right corner to view the recording content.

#### Photo translation:

#### language selection:

The translator currently supports photo translation in more than 40 languages; click the language option at the top of the photo translation interface to enter the language selection list, and click the source language\target language option you need;

Photo translation: Tap the screen to focus on the text that needs to be t ranslated, and then tap the camera button at the bottom of the screen. After recognition, the translated text will be displayed, and the voice ann ouncement can be played by clicking on the text. Long press the photo frame in the lower left corner to delete the current photo and translation result.

#### Settings:

Volume control: Drag the icon and slide left and right to adjust the volume.

Connect\Replace WIFI: Configure the WIFI network of the device.

Clear translation record: You can choose to clear the voice translation record or the photo translation record.

Language setting: You can set the system menu language.

Online upgrade: Check the version information and update the firmware

version.

Display: Drag the icon and slide left and right to adjust the brightness of the screen. The sleep mode can be selected from 4 screensaver mode s of 30 seconds, 1 minute, 3 minutes, and never turn off the screen.

Time and date: Two ways of automatic setting and manual setting are provided.

Change wallpaper: You can choose your favorite wallpaper to change. Firmware upgrade: Check the version information and update the firmware version.

Key tone: Turn on or off the beep of a 'di' when you press the translati on key.

Restore factory settings: delete all records and settings, and restore to f actory default settings. (Please proceed with caution)

Device information: View the version, model, SN and storage space of the current device.

Battery	3.7V 1400mAh
Standby time	About 160H
Charging	1A Charging current at approximately 1-2 hours
Use time	About 8-10H
Pixel	500M AF auto focus
Screen size	3.0 inch IPS
Touch screen	Support
Software system	Android
RAM	1G
ROM	8G
WIFI	2.4G (802.11 b/g/n)
Bluetooth	Support
Body weight	100g
Size	121*42*11mm
Online languages	more than 100 languages
Offline languages	more than 10 languages
Photo language	more than 40 languages

(subject to change with version updates)

This equipment has been tested and found to comply with the limits for a Class B digital d evice, pursuant to part 15 of the FCC Rules. These limits are designed to provide reason able protection against harmful interference in a residential installation. This equipment g enerates, uses and can radiate radio frequency energy and, if not installed and used in a ccordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to c orrect the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receive r is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufact urer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device m ust accept any interference received, including interference that may cause undesired op eration.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontroll ed environment. This device and its antenna must not be located or operating in conjuncti on with any other antenna or transmitter.

