




## 802.11ac-20 CHANNEL 2, SPURIOUS 30 MHz ~ 3 GHz




## 802.11ac-20 CHANNEL 2, SPURIOUS 2 GHz ~ 25 GHz




## 802.11ac-20 CHANNEL 6 CARRIER LEVEL




## 802.11ac-20 CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




## 802.11ac-20 CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz




## 802.11ac-20 CHANNEL 10 CARRIER LEVEL




## 802.11ac-20 CHANNEL 10, SPURIOUS 30 MHz ~ 3 GHz




## 802.11ac-20 CHANNEL 10, SPURIOUS 2 GHz ~ 25 GHz




## 802.11ac-20 CHANNEL 11 CARRIER LEVEL




## 802.11ac-20 CHANNEL 11, SPURIOUS 30 MHz ~ 3 GHz




## 802.11ac-20 CHANNEL 11, SPURIOUS 2 GHz ~ 25 GHz




## 802.11ac-40 CHANNEL 3 CARRIER LEVEL




## 802.11ac-40 CHANNEL 3, SPURIOUS 30 MHz ~ 3 GHz




## 802.11ac-40 CHANNEL 3, SPURIOUS 2 GHz ~ 25 GHz




### 802.11ac-40 CHANNEL 4 CARRIER LEVEL




### 802.11ac-40 CHANNEL 4, SPURIOUS 30 MHz ~ 3 GHz




### 802.11ac-40 CHANNEL 4, SPURIOUS 2 GHz ~ 25 GHz




### 802.11ac-40 CHANNEL 6 CARRIER LEVEL




## 802.11ac-40 CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




## 802.11ac-40 CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz




## 802.11ac-40 CHANNEL 7 CARRIER LEVEL




## 802.11ac-40 CHANNEL 7, SPURIOUS 30 MHz ~ 3 GHz




## 802.11ac-40 CHANNEL 7, SPURIOUS 2 GHz ~ 25 GHz




## 802.11ac-40 CHANNEL 8 CARRIER LEVEL




## 802.11ac-40 CHANNEL 8, SPURIOUS 30 MHz ~ 3 GHz




## 802.11ac-40 CHANNEL 8, SPURIOUS 2 GHz ~ 25 GHz




## 802.11ac-40 CHANNEL 9 CARRIER LEVEL




## 802.11ac-40 CHANNEL 9, SPURIOUS 30 MHz ~ 3 GHz




## 802.11ac-40 CHANNEL 9, SPURIOUS 2 GHz ~ 25 GHz




## 802.11ax-40 CHANNEL 3 CARRIER LEVEL



## 802.11ax-40 CHANNEL 3, SPURIOUS 30 MHz ~ 3 GHz




## 802.11ax-40 CHANNEL 3, SPURIOUS 2 GHz ~ 25 GHz







### 802.11ax-40 CHANNEL 4 CARRIER LEVEL




### 802.11ax-40 CHANNEL 4, SPURIOUS 30 MHz ~ 3 GHz



### 802.11ax-40 CHANNEL 4, SPURIOUS 2 GHz ~ 25 GHz




### 802.11ax-40 CHANNEL 5 CARRIER LEVEL







## 802.11ax-40 CHANNEL 5, SPURIOUS 30 MHz ~ 3 GHz




## 802.11ax-40 CHANNEL 5, SPURIOUS 2 GHz ~ 25 GHz




## 802.11ax-40 CHANNEL 6 CARRIER LEVEL




## 802.11ax-40 CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




## 802.11ax-40 CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz




## 802.11ax-40 CHANNEL 7 CARRIER LEVEL



## 802.11ax-40 CHANNEL 7, SPURIOUS 30 MHz ~ 3 GHz



## 802.11ax-40 CHANNEL 7, SPURIOUS 2 GHz ~ 25 GHz



## 802.11ax-40 CHANNEL 8 CARRIER LEVEL

