



802.11ax-HE40 – Ant 3

Channel 179 (6845MHz) RU242/62

The Reference Level




The Mask Data




Channel 187 (6885MHz) RU242/62

The Reference Level




The Reference Level




Channel 195 (6925MHz) RU242/61

The Reference Level




The Mask Data




802.11ax-HE40 – Ant 3

Channel 211 (7005MHz) RU242/61

The Reference Level




The Mask Data




Channel 227 (7085MHz) RU242/62

The Reference Level




The Mask Data




802.11ax-HE80 – Ant 3

Channel 7 (5985MHz) RU484/65

The Reference Level




The Mask Data




802.11ax-HE80 – Ant 3

Channel 55 (6225MHz) RU484/65

The Reference Level




The Mask Data




Channel 87 (6385MHz) RU484/66

The Reference Level




The Mask Data




Channel 103 (6465MHz) RU484/65

The Reference Level




The Mask Data




802.11ax-HE80 – Ant 3

Channel 119 (6545MHz) RU484/66

The Reference Level




The Mask Data




Channel 135 (6625MHz) RU484/65

The Reference Level




The Mask Data




Channel 151 (6705MHz) RU484/65

The Reference Level




The Mask Data




802.11ax-HE80 – Ant 3

Channel 167 (6785MHz) RU484/66

The Reference Level




The Mask Data




Channel 183 (6865MHz) RU484/66

The Reference Level




The Mask Data




Channel 199 (6945MHz) RU484/65

The Reference Level




The Mask Data




802.11ax-HE80 – Ant 3

Channel 215 (7025MHz) RU484/66

The Reference Level




The Mask Data




802.11ax-HE160 – Ant 3

Channel 15 (6025MHz) RU996-1

The Reference Level




The Mask Data




Channel 47 (6185MHz) RU996-1

The Reference Level




The Mask Data




802.11ax-HE160 – Ant 3

Channel 79 (6345MHz) RU996-2

The Reference Level




The Mask Data




Channel 111 (6505MHz) RU996-1

The Reference Level



The Mask Data




Channel 143 (6665MHz) RU996-1

The Reference Level




The Mask Data



802.11ax-HE160 – Ant 3

Channel 175 (6825MHz) RU996-2

The Reference Level




The Mask Data




Channel 207 (6985MHz) RU996-1

The Reference Level




The Mask Data




802.11ax-HE20 – Ant 2

Channel 1 (5955MHz) RU26/0

The Reference Level



The Mask Data




Channel 1 (5955MHz) RU52/37

The Reference Level




The Mask Data




Channel 1 (5955MHz) RU106/53

The Reference Level



The Mask Data




802.11ax-HE20 – Ant 2

Channel 49 (6195MHz) RU26/4

The Reference Level



The Mask Data




Channel 49 (6195MHz) RU52/38

The Reference Level




The Mask Data




Channel 49 (6195MHz) RU106/53

The Reference Level




The Mask Data




802.11ax-HE20 – Ant 2

Channel 93 (6415MHz) RU26/8

The Reference Level




The Mask Data




Channel 93 (6415MHz) RU52/40

The Reference Level




The Mask Data




Channel 93 (6415MHz) RU106/54

The Reference Level




The Mask Data




802.11ax-HE20 – Ant 2

Channel 97 (6435MHz) RU26/0

The Reference Level




The Mask Data




Channel 97 (6435MHz) RU52/37

The Reference Level




The Mask Data



Channel 97 (6435MHz) RU106/53

The Reference Level



The Mask Data

