






K400 PLUS TV

Setup Guide
Guide d'installation

-  1. Connect the USB receiver to a laptop and the TV.
-  2. Press the power button on the TV.
-  3. Turn the TV on.
-  4. Visit logitech.com/options



logitech.com/support/k400plus

EU Directive 2014/53/EU:

Y-R0055-Proprietary 2.4 GHz (2400 - 2483.5 MHz): 2405 - 2474 MHz; 6.47 dBm

C-U0008-Proprietary 2.4 GHz (2400 - 2483.5 MHz): 2405 - 2474 MHz; 2.21 dBm



logitech®