

EZCast TwinX C-1 Wireless Display Transmitter Quick Start Guide

Rev 1.0



Product information is subject to change without prior notice.



How to mirror


1 Simply plug into laptop or mobile

Plug EZCast TwinX C-1 to Type C port on laptop or mobile. Wait a few seconds until the flashing light on EZCast TwinX stops, and it will start mirroring automatically. Please make sure to install and pair to EZCast wireless display receiver if flashing over 20 seconds.



2 Stop and restart mirroring

Press the EZCast TwinX button to stop mirroring or restart mirroring.




Note: EZCast TwinX support mirroring for all laptops including Windows and MacOS, and Android mobiles supporting DP output.

How to pair EZCast TwinX with receiver

1 Turn on pairing mode for receiver

Press the reset button (or insert the pin to press) for 2 seconds on EZCast wireless display receiver. Release the button when the screen shows "Release the button to pair with EZCast". Please make sure your receiver has been upgraded to the latest version.

Note: All EZCast wireless display receiver on our website supports EZCast TwinX pairing, except for Magic series products.



2 Press the EZCast TwinX button

Plug EZCast TwinX on laptop or mobile to provide power. Press the EZCast TwinX button to complete pairing while the screen shows "Ready to pair".



Note: There are 3 mode for reset button on receiver, depending on pressing duration.

- (1) Simple click: Switch the receiver to 2.4G/ 5G Hz Wi-Fi mode.
- (2) Press for 2 seconds: Turn on pairing mode for EZCast TwinX.
- (3) Press for 10 seconds: Reset the receiver to default.

EZCast TwinX C-1

無線顯示發射器

快速指南

Rev 1.0



EZCast產品訊息如有更改，恕不另行通知。

如何鏡像


1 接上電腦或手機即可開始投影

將EZCast TwinX接上電腦或手機的Type C接口，等待數秒至EZCast TwinX的閃燈停止，即開始自動投影。若閃燈持續超過20秒，請確保EZCast無線顯示接收器已正確安裝並配對至EZCast TwinX。



2 停止/重新鏡像

點擊EZCast TwinX上的按鈕，可停止或重新鏡像。




注意：EZCast TwinX支援Windows/ MacOS電腦，以及支援DP輸出的Android手機。

如何配對接收器

1 開啟接收器配對模式

長按EZCast無線顯示接收器上的按鈕（或拿針戳進重置孔）2秒左右，待畫面顯示文字“Release the button to pair with EZCast”時放開按鈕。請確保無線顯示接收器已更新至最新版本。

注意：官網上所有無線顯示接收器，除Magic系列之外，皆支援EZCast TwinX配對。



2 按下EZCast TwinX的按鈕

將EZCast TwinX C-1接上電腦或手機供電，在畫面顯示“Ready to pair”時按下EZCast TwinX上的按鈕即完成配對。



注意：無線顯示接收器上的重置孔，根據按壓時間不同，有三種設定模式。

- (1) 按壓一下：切換接收器的Wi-Fi模式為2.4G/5G。
- (2) 長按2秒：開啟接收器的配對模式，供EZCast TwinX配對。
- (3) 長按10秒：將接收器回復原廠設定。

EZCast TwinX C-1

无线显示发射器

快速指南

Rev 1.0



本手册所提到的产品规格和资讯仅供参考，如有变更，恕不另行通知。

如何镜像


1 接上电脑或手机即可开始投屏

将EZCast TwinX接上电脑或手机的Type C接口，等待数秒至EZCast TwinX的闪灯停止，即开始自动投屏。若闪灯持续超过20秒，请确保EZCast无线显示接收器已正确安装并配对至EZCast TwinX。



2 停止/重新镜像

点击EZCast TwinX上的按钮，可停止或重新镜像。




温馨提示： EZCast TwinX支持微软、苹果电脑，以及支持DP输出的安卓手机。

如何配对接收器

1 开启接收器配对模式

长按EZCast无线显示接收器上的按钮（或拿针戳进重置孔）2秒左右，待画面显示文字“Release the button to pair with EZCast”时放开按钮。请确保无线显示接收器已更新至最新版本。

温馨提示：官网上所有无线显示接收器，除Magic系列之外，皆支持EZCast TwinX配对。



2 按下EZCast TwinX的按钮

将EZCast TwinX C-1接上电脑或手机供电，在画面显示“Ready to pair”时按下EZCast TwinX上的按钮即完成配对。



温馨提示：无线显示接收器上的重置孔，根据按压时间不同，有三种设定模式。

- (1) 按压一下：切换接收器的Wi-Fi模式为2.4G/5G。
- (2) 长按2秒：开启接收器的配对模式，供EZCast TwinX配对。
- (3) 长按10秒：将接收器回复原厂设定。

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



Website: <https://www.EZCast.com>
YouTube: <https://www.YouTube.com/EZCast>