

Operation Description

1. ON/OFF Button : Allows switching between LED modes.
 - (1) Regular Mode : 1st POWER ON → 2nd Dimming → 3rd Flash → 4th OFF
 - (2) Bluetooth Pairing Mode : Double Press (Flashing blue light)
 - (3) Central Control Mode : Convert automatically at the concert.
(Press button 3 seconds will turn pink light on, 3 more seconds changes back to Central Mode.)
2. Pairing with smartphone for event information, software update and mood lighting.
(Note : This function may not operate if software is not updated before the events.)
 - 2.1. Downloading an App
 - (1) QR code : Scan the QR code on the bottom to download the app.
 - (2) Link <https://bit.ly/2FPx2BY> follow to download the app.
 - (3) Refer to FAQ in the app on how to use the app.
 - 2.2. Connecting to Bluetooth and Software Update
 - (1) Turn on the Bluetooth function on the mobile phone.
(For Android, the location permission in the app is required.)
 - (2) Whilst power on, press the button twice, blue light will flash and Bluetooth pairing mode.
 - (3) Turn on the app and press the connect button to pair the devices.
(Note : If software update is required follow the instructions on the app.)
 - 2.3. Mood lighting Mode : Change the mood light color freely through the app
 - (1) Mode 1 : Constant lighting.
 - (2) Mode 2 : Slowly dims in 30-minute intervals.
 - (3) Mode 3 : Repeats dimming every 30 minutes.
3. Central Control Mode
 - 3.1. Within an event hall : When turned on, it is centrally controlled without extra connection.
(Note 1 : Light stick may not operate smoothly if event info is not updated before an event start.)
(Note 2 : Once an event starts, none function other than pink lighting (pressing on/off button for 3 seconds) will work.
 - 3.2. Reacting to songs : When turned on, light stick will automatically operate based on the inaudible frequencies of songs.
(Note 1 : Light stick may not operate smoothly without an update.)
(Note 2 : Once an event starts, none function other than pink lighting (pressing on/off button for 3 seconds) will work.)
4. Squeaky hammer sound can be controlled by slide button on the top.
5. Enclosed hand strap can be attached to the hole on the bottom.
6. Enclosed stand can be used to hold the light stick. (Limited Edition Only)