

Thanks for selecting this mobile phone. For the best performance we recommend that you read the manual carefully.

Contents

Overview.2

1. Introduction3

2. Function of main menu.....4

3. Maintenance and service.....9



■ Overview

Please read the following concise rules carefully. Nonobservance to the rules may lead to danger or violence of the laws. The user's manual gives details about the safety precautions.

■ Emergency call

Make sure the equipment is in the covered area of the network service and the calling function is activated. As per the specific requirements, press the key of finish to clear the screen and return to the standby state. Input the emergency call number (112) and press the call key.

■ Function Description

The phone is a perfect combination of humanized design and exquisite workmanship, the streamline and ingenious body is comfortable to hold. With streamline and ingenious frame, it feels comfortable to hold the mobile phone in your hand. It supports TXT electronic book, Blue-tooth, dual SIM cards with one standby, network camera, camera, FM and etc, It makes your work more convenient and your free time more fun with the combination of keyboard, florid colored screen, pleasant bells, cartoon head portrait for incoming calls, strong file management function (supporting T-FLASH card), fashionable camera function and long time tape recording function, music player, video player.

■ Introduction

Insert the SIM card and the battery

Ask your SIM card dealer whether he has provided SIM card service and the method of usage who may be service provider or other dealers, SIM card and its contacts are vulnerable to scratch or bending. Attention shall be attached when use, insert or take out the card.

■ Inserting/taking out T-FLASH CARD

Only use approved and compatible T-FLASH card applicable to the mobile phone. Approved memory card trade standard is applied; however, certain bands may not be completely compatible with the mobile phone. Using incompatible memory card may damage not only the card and the mobile, but also the data stored in the card.

■ Charging the battery

Check the model number of the charger before using it to charge the mobile, Only use approved battery, charger and accessories applicable to the specific mobile model. Using other types of battery, charger and accessories may violate the certification or warranty terms of the equipment and may result in danger, Refer to the dealer for supply of relative approved accessories.

■ Startup and shutdown

Press the key of power supply to start up or shut down the mobile phone, If it is prompted to input PIN or UPIN, please input the required password (shown as **** on the screen).

Function of main menu

■ Contacts

Save the information of contacts , including names and telephone numbers in the contacts.

■ Message

Write a message: You can choose to send the complete message from SIM card 1 or SIM card 2,

You can choose multiple receivers to send the message to more than 1 person..

■ Call logs

By telephone if you need to check you call logs>click select call logs menu>View: 1.All calls

2.SIM1/2 missed calls 3.SIM1/2 Dialed calls 4.SIM1/2 Received calls 5.SIM1/2 Rejected calls

6.Delete call logs 7.call timers.

■ Settings

Phone settings

1.1.Date&Time : You can set the phone's time and date and the format.

1.2.Language Settings: You can select the phone's display language .

1.3.Shortcut Settings: You can set the phone right soft keys and the navigation key shortcut functions.

1.4.Auto power on/off: After setting the time, and by that time the phone will auto power on/off.

1.5.Power management: Battery remains.

1.6.Restore factory settings: Enter the correct password of the phone will have to change your phone settings back to factory default state value, the user of the function be used with caution. (Default password: 1234).

Display Settings

1.1.Animation effect: Set power on/off animation.

1.2.Wallpaper setting: Set wallpaper.

1.3.Idle display settings:You can choose to display or not display.

1.4.Brightness:The menu is to control of mobile phone screen brightness

1.5.Display backlight :The menu is to control of mobile phone display backlight time.

1.6.Keypad backlight :The menu is to control of mobile phone Keypad backlight time.

Call settings

This is some of the communications settings. There are have Dual-SM, Call divert, Call waiting, Call barring, Hide ID and others.

Security

PIN/PIN2:The SIM1/2 security setting need provided network operator .for more details, please contact your operator.

Phone locked: You can switch on or off to activate the phone lock function to protect your phone.

Modify the phone password:You can change password here. The default password is “0000”.

Privacy:You can open the privacy protection function, set up mobile privacy.

Auto keypad lock:You can set the on/off automatically lock screen mobile phone.

Lock screen by end key:Set end key as dedicated key to lock the phone.

Fixed dialing:You can set a fixed dialing.

Connections

Configure the network parameter in the place.

■ **Multimedia**

■ **Camera**

In the options of camera, you may set the photometry mode, flash light, exposure compensation, avoidance of flickering, postponing shooting, white balance, photo quality, photo size, special effect, profile and etc. You may enter the album to check the formats that the cell phone supports.

■ **Image viewer**

Check the pictures in the memorial card in formats supported by the cell phone.

■ **Video Recorder**

phone provides video recording, select video footage that can enter the video recording. In the preview video press OK button to begin, press stop again, can have white balance, exposure compensation, night mode, avoid flashing to set one by one. Settings are stored path cell phone or memory card. Restore all the camera options of setting for the system default values.

■ **Video player**

Check the video files in the memory card supported by the cell phone.

Play your favorite video files.

■ **Sound Recorder**

Open the recording function, can pause, stop and play. After recording, the recording can be played

■ **FM radio**

Turn on FM broadcast, and you may press the direction keys of left and right to manually tune the channel. Press the direction key of upward to turn on or off the auto-searching mode. Press OK to record the FM broadcast. Press the direction key of downward to turn on or off FM broadcast. In the options, you may set manually or automatically searching for channels, turning off the background during broadcasting as well as the format of recording thereof.

■ **File Manager**

Phone & memory card

The File Manager list the all the files stored in your phone or memory card. you can new folder, delete folder, view the detail, edit folder (rename, copy, cut), search folder, mark folder, sort the folder, and view the memory status.

■ **Games**

This phone provides you some built-in games. You can also adjust the game settings when you enter the game menu. Please refer to help option of each game for specific operation and instructions.

■ Services

Internet

your mobile Internet support based on wireless application protocol (WAP) service. You can access a variety of WAP service. WAP service need network support, the WAP service availability, price and tax, please contact your network operator or provide you with the service providers of services required.

STK

This function by the network providers, according to the SIM card provides services will appear different menu options. If a SIM card and network supplier does not support this service, this function will not be used. If you need to get more information please contact with network providers.

■ Profiles

There are generally 6 kinds of models (Normal, Silent, Indoor, Outdoor, Earphone, BT). You can start, custom, rename, the ring settings, adjust the volume, ringing mode (including Silent, ringtones, vibration) and other ring mode operation (including ring volume adjustment, caller ID, information prompt, alarm, voice tone, low voltage, the switch machine set).

■ Tools

■ Bluetooth

You may establish wireless connection with other compatible devices with the Bluetooth technology; you may send images, videos, music files and etc. with the Bluetooth technology.

■ Alarm

Set the time of alarm clock, ring signal, ring mode, alarm ring mode and interval between repeated alarm rings.

■ calendar

calendar this feature allows you to view the calendar. In the calendar interface, press left soft key, you can make a new schedule, check the schedule, all schedule, empty, empty all, go to the date

that day, weekly show operation, etc.

■ **Calculator**

Your cellular phone has a built in calculator. Enter the numbers with the keypad.

■ **Torch**

Turn on or off the flashlight. press 0 key on the keyboard for 5secs to power on or off torch.

■ **World clock**

You can view the local date and time via selecting the GMT and city. When the cross points out a certain city, it will show the local date and time.

■ **Stopwatch**

The function for time measurement

■ **Music player**

The music player is used to play music files in supported formats in the current player's list. You may view details of the music files and set the current music file as the ring signal for incoming call. You can enjoy the music with this function.

3. Maintenance and service

Refer to the local dealer for supply of accessories. Hereafter are some precautions for usage of the accessories, Only use batteries, chargers and accessories approved by the manufacturer. Usage of other types of batteries, chargers and accessories may result in violence of the certification or warranty terms or even lead to danger, Keep the equipment dry, Don't keep the equipment in under cooled places; otherwise, when the temperature rises to normal, moisture may be generated within the equipment, resulting in damage of the circuit board. .Only use matched or approved antenna .

FCC Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This Product meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of this Device T102 (FCC ID: ZSW-10-039) has been tested against this SAR limit. SAR information on this can be viewed on-line at <http://www.fcc.gov/oet/ea/fccid/>. Please use the device FCC ID number for search. This device was tested for typical operations 10mm from the body. To maintain compliance with FCC RF exposure requirements, 10mm separation distance should be maintained to the user's bodies

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.