

TF-T02 说明书成品尺寸: 73X93mm128铜版纸覆哑膜钢琴折





TF-T02 True Wireless Bluetooth Headset Instruction manual



earbuds. 2. Don't put the earbuds in the water or any others liquid.The earbuds are not waterproof.

3. If any liquid enters the product by accidentally,please disconnect and remove the connection immediately.

4. Please make sure that there is no water on your hands when Installing or uninstalling the product to avoid electricshock. 5. Do not put the product near by the heat source or expose it to the fire

source directly. 6. Do not put the product in the environment with strong electromagnetic

force, otherwise it will cause product malfunction.

Charging case specifications

Battery capacity: 300mAh Charging time: 1.5 hours Rated input: 5V === 300mA Headset charging times: About 3 times (All technical information is subject to actual performance)

To charge the charging box

The Type-C charging cable connects the charging bay to the 5V power adapter. (Warm tip: When the headset battery is less than 3.3V, it will broadcast a reminder of low battery (voice prompt: battery low). The red light flashes slowly, reminding once every minute. Please charge the earphone in time.



Rated input: 5V===30mA (headset) Rated input: 5V===300mA (charging case)

Power On	The red and blue lights flash alternately
Power Off	The red light flashed three times
Pairing status	The red and blue lights flash alternately
Earphone charging	The red light is on.
Charging the earphone Charging case status	Blue light on
The charging bay is low	Blue light flashing
Charge the charging bay	Blinking red lamp
Charge bay is fully charged	The red light is on
factory data reset	The red light blinks three times

Power Method Method (Startup)

②Shutd Method Method

(Shutdow

③Pairing Step 1: Step 2: Tips: If

) Indicator Status				
	Touch operation	The name and content of harmful	Warranty statement	
wer On The red and blue lights flash alternately	General mode	substances in the earbuds		
wer Off The red light flashed three times	General mode		Disclaimer This user manual does not have any form of guarantee, position expression or	
iring status The red and blue lights flash alternately	Voice assistant: Long press left earphone for 2 seconds to start/close (" drip "sound release)	Part Names Harmful Substances Pb Ha Cd Cr(VI) PBB PBDE	other implication. The mentioned products, specifications and information are for reference only, and the content will also be updated on the web at any time without additional separate notice	
rphone charging The red light is on.	Volume Plus: Click the right earphone		Warranty statement:	
arging the earphone arging case status Blue light on	Volume reduction: Click the left earphone	Printed circuit OOOOOO	The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase("Warranty Period"), under normal	
e charging bay is low Blue light flashing	Music playback mode	Small structural o o o o o	conditions of use due to quality defects damaged, can be repaired. Free repair; free replacement if the manufacturer confirms that it cannot be repaired;	
arge the charging bay Blinking red lamp	Play/Pause: Double click any headset touch button	This form is compiled in accordance with SJ/T 11364.	repaired or replaced product. Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). Purchased by sale	
arge bay is fully charged The red light is on	Last sona: Three strikes left earphone	O:Indicates that the content of the hazardous substance in all	the ticket date shall prevail; if the purchase date cannot be determined, the warranty period shall be 13 (13) months	
ctory data reset The red light blinks three times	Next song: Three strikes right earphone	homogeneous materials of the part is in below the limit required by GB/T 26572.	If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need	
erating instruction er on 12. Remove the earphone from the charging boy and turn on the earphone 22. Long press the left and right earphone touch area for 5 seconds 29. The promotions: "power on!" 20. 41. The headset is not connected within 3 minutes, the device will automatically shuts off 23. If the headset is not connected within 3 minutes, the device will automatically connected shut down 20. and enter the pointing state with moble phones (prompt tone: "Paintg"). 0.	Coll mode Coll mode Coll Coll Couble click the touch button of any headset End Call: Double click the touch button of any headset Reject a call: Press and hold any headset for 2 seconds Coll Coll Couble click the touch button of any headset Reject a call: Press and hold any headset for 2 seconds Coll Coll Couble click the touch button of any headset Reject a call: Press and hold any headset for 2 seconds Coll Coll Couble click the touch button of any headset Reject a call: Press and hold any headset for 2 seconds Coll Coll Couble click the touch button of any headset Reject a call: Press and hold any headset for 2 seconds Coll Coll Couble click the touch button of any headset Reject a call: Press and hold any headset for 2 seconds Coll Coll Couble click the touch button Coll Coll Couble click the touch button Coll Coll Coll Couble click the touch button Coll Coll Coll Couble click the touch button Coll Coll Coll Coll Coll Coll Coll Coll	Xindicates that the hazardous substance at least in a certain homogeneous material of the part exceeds The limit requirements specified in GB/T 26572. The parts marked with "X" on the form are all harmful due to the limitations of global technological development. Substitution of substances. Printed circuit board components: Indiago printed circuit boards and their parts electronic components, etc. and depending on the product model the earbuds you purchased may not contain all the above components. Electronic and electrical products sold in the People's Republic of China must mark this LOGO, the number in the logo represents the product under normal use Environmental protection use period.	to provide an accurate,complete and clearly filled out välid sales invoice. The above guarantee does not apply to the following situations: Liczeeding the validity period of the three packs; 2. Altering the warranty card and product code does not match the product body; 3. Causes caused by misuse,obuse or improper transportation, use,maintenance or storage obstacles or damage; 4. Foilure or damage caused by force majeure (such as earthquake,war,disas- ter, etc.) or accident body; 5. The zipper and tower buckle are damaged due to excessive force; 5. Disconnection or tearing caused by excessive load; 7. Products with signs of burning of flooding; 8. Pharmage, caused by unauthorized disassembly; 10. Aging,discoloratinfication, abrasion, rupture and other losses that occur during the normal use of the product. 11. If the original identification lobel of the product is changed or damaged, this guarantee will become invalid. The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should check on the spot and arise objections to any discrepancies. The above guarantees are all guarantees we make regarding the products, and are only applicable in mainland China Nothing in this document affects consumer rights that cannot be excluded or restricted under the law profit. Service supervision hotline: 400-885-8808	TRANSFORMERS

PDF



				A second s
触摸操作	产品中有害物质名称及含量	保修声明		保修卡
常規模式	「加中有苦物版石协仪召量 部件名称 有書物质 印刷电路组件 〇 〇 〇 〇 〇 外壳等小结构件 〇 〇 〇 〇 〇	免责声明 本使用手册没有任何形式的担保、立场表达或其他暗示,本使用手册所提到的产品、规格 及信息仅供参考,内容亦会随时更新于网页,恕不另行通知。 保修声明: 就太文件附随的产品做如下保证:如产品在您购买日起十二(12)个月("保修期")内,在 正常使用情况下因质量瑕疵发生损坏,能修理的,免费修理;经厂家确认无法修理的,免 费更换;修理或更换后的产高。在剩余保停期(最短不少于30天)内继续享有保修。购 买日以期替发票日期为准,如无法确定购买日,则保修和自产品生产日期起技子三(13)		1木10 下 尊敬的用户,本保修卡是您将来申请保修的凭用户信息 用户姓名 現系电话 通讯地址
播放/暂停:双击任意耳机触摸键 上一曲:三击左耳机 下一曲:三击右耳机	本表格依据SJ/T11364的规定编制 O:表示该有害物质在该部件所有均质材料中的含量均在 GB/T26572规定限量要求以下。 X.表示该有害物质至少在该部件的某一均质材料中的含量超出 GB26572规定的限量要求。 表单标记"X"的部件,皆因全球技术发展水平限制而无法实现有害 物质的替代。	 个月计算。 如申请保修,请先致电产品服务热线,并按我们指示的方式执行。申请保修时,您需要提供准确。完整和清晰填写的有效销售发票。以上保证不适用于下列情况: 1.超过三包有效期的; 2.涂衣保修卡、产品编码与产品本体不符; 3.因误用、滥用或不适当的运输。使用、维护或保管而导致的故障或损坏; 4.因不可抗力(如地震、战争、火灾等)或意外导致的故障或损坏; 5.拉链,塔们因受力过大流动,以下; 5.拉链,塔们因受力过去流动脱坏; 6.因承载过重造成的脱线或素裂: 	TRANSFORMERS	产品信息 产品名称 产品条码/编号/批号 销售商信息
授听来电:双击任意耳机触摸键 结束通话:双击任意耳机触摸键 拒接电话:长按任意耳机触摸键2秒	本表格依据SJ/TI1364的规定编制 印刷电路板组件:"包括印刷电路板及其零部件,电子元器件等, 根据产品型号不同,您所购买的产品可能不会含有以上所有部件 在中华人民共和国境内销售的电子电气产品必须标识此 标志标志内的数字代表在正常的使用状态下的产品的 环保使用期限。	 7.任何因尖锐物体造成的损坏, 8.有烧损或水浸迹象的产品; 9.因置自拆次导致的损坏, 10.产品工常使用过程中发生的老化、脱色、磨损、破裂和其他损耗。 11.如产品质有标识标签被更改或损毁,本保证将失效。 产品及随用物料的齐备和外观完好不属于保证范围,您应在接收产品时当场检验并对任何不符提出异议。 		名称 地址 联系电话 销售日期 备注
音乐模式: 长按右耳触摸键2秒 (提示音: "music mode") 游戏模式: 长按右耳軸摸键2秒 (提示音: "game mode") 恢复出厂设置 左右耳机开机组队未与设备连接状态下,L/R连击5下,耳机红灯快闪三下关机, 恢复出厂设置成功。		以上保证是我们就产品做出的全部保证,且仅在中国大陆地区境内适用。本文件的任何内 容均不影响根据法律规定不能排除或限制的消费者权利。 服务监督热线:400-885-8808		合格 产品编号: 生产日隔: 检查点:

Τ	电子邮件	
T	邮政编码	
-		1
Τ	产品型号	
_		
	邮政编码	
T	发票号码	



Warranty Service

Contact number Sales date Remark

User info	
User name	Email
Contact number	Postal code
Mailing address	
Product information	
Product name	Product number
Product barcode / Serial number	/ Batch number
	1
Vendor information	
Name	
Address	

Postal code	
Invoice number	

Certificate of Approval
Product No: Production Time: QC:

保修卡正面

保修卡反面

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.