

Remote Transmitter Operation

Transmitter part number: #136-1889

Pressing the **LOCK**

button arms the security system and locks the doors


Pressing the **UNLOCK**

button disarms the system and unlocks the doors

Pressing the **TRUNK**

button arms to open the trunk

Pressing the **PANIC** button for seconds will activate the system



Pressing button 3 + button 4 twice in 3 seconds to remote starter the engine system

FCC ID :ELVAT1A

This device complies with FCC Rules Part 15 Operation is subject to the following two conditions (1) This device may not cause harmful interference and (2) this device must accept any interference that may be received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.