


**BACK**

**STROBE**



for use with  
 **Bluetooth**  
enabled devices

# USER MANUAL

**•YOUR JOY PRODUCT**

product can provide a high quality listening experience for your mobile phone, computer and other media devices. Before using this product, carefully read this manual to correct and operate this device please ask your local dealer if you have any questions.

LUOY STROBE Bluetooth® Speaker X1  
Charging Cable X1  
User Manual X1

**•BATTERY CAUTION**

Quest USA Corp  
435 Flatbush Ave  
Brooklyn, NY 11225

@GoJoy & LUV are registered trademarks of Quest USA Corp. All other trademarks and trade names are property of their respective owners. Designed by GOJOY & LUV in New York. All rights reserved. Limited lifetime warranty to activate your product, warranty card to our website [www.gojoy.com](http://www.gojoy.com) & register this product.

dren

## •SPECIFICATIONS

Bluetooth® version: S.O  
Wireless distance: Up to 32ft  
Output Power: 15W  
Horn Type: 40x57mm  
Power Input: DC5V (1.0A)  
Charging Time: 2-3hrs  
Playtime: Up to 2-3hrs with LED light on  
Battery: 3.7V/1200mah

- **BATTERY DISPOSAL**

Please do not attempt to change the battery yourself. If the battery has died, you should follow the disposal instructions listed here. Never dispose of used battery(s)/electronic(s) with ordinary solid wastes. Always dispose of used battery(s)/electronic(s) in accordance with the prevailing community regulations that apply to the disposal of batteries/electronics. If there are no local regulations concerning battery/electronics disposal, please dispose of the device in a waste bin for electronic devices. Many electronics retailers now recycle batteries and other electronic components at no charge.

## • DEVICE FUNCTIONS

- **FUNCTIONS (FOR MUSIC)**
  - Press + Next song
  - Press - Previous song
  - Press and hold + - Raise volume
  - Press and hold - Lower volume
  - Press the **MC** button to play/pause music
- **FUNCTIONS (FOR CALLS)**
  - Press and hold + Raise volume during the call
  - Press and hold - Lower volume during the call
  - Press the **MC** button to answer coming calls and the calls

- POWERING ON/OFF:**
- Press and hold the speaker's **o** button. Please make sure the speaker is charged sufficiently.
- PAIRING THE DEVICE:**
- Make sure the Bluetooth® device is within 32ft of the speaker. The speaker will automatically enter pairing mode when turned on and light up. Enable Bluetooth® on the device you want to connect. The speaker is to and connect your device to. **LOY'S TROBAR**
- CHARGING**
- Connect the charging cable with the speaker and an appropriate charging source.
- CHANGING LIGHTING MODES**
- Press the **o** button to choose from 10 options of LED lights.

- LIMITED LIFETIME WARRANTY

Our product is warranted for a limited lifetime warranty from the date of purchase. The warranty is provided on all material defects and workmanship. Guarantee of 24 months does not apply to decreases in the effective capacity caused by its use or age. WE RESERVE THE RIGHT TO CHANGE TECHNICAL SPECIFICATIONS. For more information, please visit, [www.gojoy.com](http://www.gojoy.com)

## • OTHER IMPORTANT SAFETY INFORMATION

To avoid danger of choking, please keep this product away from babies and children. This product is not a toy. Do not treat this product as household waste. Dispose of this product properly.

product, please contact your local household waste disposal service or the product supplier for more information. Do not place this product in the waste stream. By ensuring that this product is properly disposed of, you will help prevent potential negative consequences for the environment and human health which could otherwise be caused by inappropriate waste handling. For more detailed information about this product, please contact your local household waste disposal service or the shop where you purchased this item.

**Keep this product and its accessories away from excessive heat.** Do not operate this device with a damaged cable. Do not operate this device after it has malfunctioned or been exposed to fire.

**Do not use flammable liquids such as alcohol, acetone, or other cleaning solvents to clean the product.** Do not use sharp objects on the speaker grille or the speaker. Do not expose the speaker to any liquid while it is charging. Do not use the speaker if you suspect it may have become wet. Do not touch the power source or the power button when the speaker is charging.



1

This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment

generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee

that interference will not occur in a particular situation, or if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Plug the equipment into a different outlet or a different branch of the circuit.
- Consult the dealer or a qualified radio/television technician for help.

increase in separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

**RF warning statement:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

PLEASE FOLD ON THE GREEN LINES AND PRINT DOUBLE SIDED. DO NOT PRINT GREEN LINES