

material: 260gsm2 art card, 2C + 1C



iHome

Bluetooth Rechargeable
Waterproof Speaker

Model: iBT155

QUICK START GUIDE

Diagram of the speaker top showing controls:

- Siri/Google
- Color Mode/Battery Level
- Battery LED
- Play/Pause Speakerphone
- Pairing LED
- Power ON/OFF

Diagram of the bottom of the speaker showing ports:

- Reset
- USB in
- Bluetooth Pairing
- Reset
- USB Charging Port

CHARGE UNIT BEFORE USE ABOUT 6 HOURS

Questions? www.ihome.com
1•800•288•2792

Diagram illustrating the connection of the USB charging cable (included) to the USB AC adaptor (not included) and a power outlet.

The diagram illustrates two methods of Bluetooth pairing:

- Pairing The First Time:** This process involves three steps. First, a smartphone with a Bluetooth symbol is shown. An arrow points to a power button icon, which is being pressed by a hand. Another arrow points to a second smartphone displaying the address "1234567890" and a Bluetooth symbol.
- Manual Pairing:** This process also involves three steps. First, a smartphone with a Bluetooth symbol is shown. An arrow points to a Bluetooth symbol icon, which is being pressed by a hand. Another arrow points to a second smartphone displaying the address "1234567890" and a Bluetooth symbol. A clock icon with "2s" indicates a two-second delay.

Answer Call _____

- » The speaker must be on and connected with a paired Bluetooth device to receive calls.
- » Press the **Speakerphone Button** to answer incoming call. Press again to end call.

 SLOW » FAST » FREEZE COLOR »
PULSE TO MUSIC » PRESET PULSE » OFF

- Solid red = charging
- Red LED off = fully charged
- Flashing red = low battery (not connected)
- Flashing blue & Red = pairing
- Solid blue = connected to bluetooth

» Press and hold the **Color Mode Button** when unit is ON but not charging (micro USB cable not connected) to enter Battery Review Mode.

Contact Us: 1-800-288-2792

For warranty and full instructions
visit: www.ihome.com/support

[BACK](#)

» Press and hold to access Siri or Google Assistant using voice commands.

ready
for
water

not
ready for
water



» Make sure the waterproof cover on the back of the unit is completely flush with the unit by pressing along the entire edge of the cover until it is completely and securely in place.

FCC ID: EMOIBT155
IC: 986B-IBT155

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- **Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- **NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAN ICES-3 (B)/NMB-3(B)



iBT155-180913-A

Printed in China

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil ne doit pas produire de brouillage;
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

This device uses an internal non-replaceable rechargeable lithium-ion battery that should last the lifetime of the device. If you suspect your battery may be dead, try charging it for an extended period of time and try resetting the unit. If this fails, contact Customer Service at 1-800-288-2792.

WARNING/DISPOSAL OF UNIT

Do NOT attempt to change the battery. Doing so will void the warranty and could cause injury and damage to your device. To dispose of the unit, follow the instructions below:

- Never dispose of used batteries/electronics with ordinary solid wastes, since they contain toxic substances.
- Always dispose of used batteries/electronics in accordance with the prevailing community regulations.
- Many electronics retailers now recycle batteries and other electronic components at no charge

GENERAL BATTERY PRECAUTIONS

- Never use or charge a battery if it appears to be leaking, discolored, deformed, or in any way abnormal.
- Never disassemble the unit or attempt to remove battery as that could cause leakage of alkaline solution or other electrolytic substances.
- Avoid charging a rechargeable battery when the temperature is not within 5°C - 35° C (41° - 95° Fahrenheit).
- Never expose a battery to any liquid.
- Never expose a battery to excessive heat such as direct sunlight or fire. Never use a battery pack in an unventilated vehicle where excessive internal temperatures may be encountered.
- Always keep batteries out of the reach of infants and small children.