

BYTECH®



Bluetooth®

Thank you for purchasing the Bluetooth headset. Please read all instructions carefully before using and retain the manual for future use and reference.

Package Contents  
Bluetooth Headset  
USB Charging Cable  
Operation Manual



#### CONTROLS

- 1, Multifunction Button (MFB) Answer, end, reject call, Play, Pause, ON/OFF
- 2, Next song/Volume up
- 3, Previous song/Volume down



#### Charging Your Headset:

1. Plugs the Micro-USB charging cable into your headset.
2. Plug the USB port on a computer or power adapter.
3. Charge for 1-3 hours or until the red charging indicator light shuts off.
4. Unplug your headset, it is now ready for use.

#### Pairing the headset with a compatible phone

1. Make sure your headset is turned off.
2. Push the MFB key for about 5-7 seconds until the light flashes blue and red alternately.
3. Activate the Bluetooth® feature on the device, and set the device to search for the Bluetooth® devices. The name of the Wireless Headset is BY-BE-118. See the user guide of your device for instructions.
4. If the pairing is successful, the headset's blue light will flash every 6 seconds.
5. If pass code is requested enter (0000) Once the headset has paired with your device, no password will be needed to reconnect.

#### Power ON/OFF & Reconnecting

- To switch on, press and hold the MFB key until the blue indicator light blinks on and off.
- To switch off, press and hold the MFB key until the red indicator light blinks on and off.
- Adjust volume, Press and hold the + to increase and the - to decrease volume.
- Next song, Momentarily press the -
- Previous song, Momentarily press the +
- Pause song, press the MFB key while music is playing. -

#### Answer a Call

- To answer and end a call Press the MFB key, or use the phone keys.  
(music will automatically pause during phone calls)
- To reject a call Press and hold MFB key, or use the phone keys.
- Redial the last dialed out number, Press the Multifunction button twice quickly.

#### SPECIFICATIONS

Bluetooth Version: 4.2  
Driver Diameter: 10mm  
Impedance: 30Ω  
Sensitivity: 105DB  
Frequency Response: 20-200HZ  
Battery Capacity: 55mah  
Rechargeable Li-Ion Battery  
Playing Time: Up to 2-3 hours  
Bluetooth Range: 33 feet  
The product does not have the full features of BT 4.2. No BLE and EDR (8DPSK)

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: [1] This device may not cause harmful interference, and [2] this device must accept any interference received, including interference that may cause undesired operation. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

#### BYTECH

Bytech NY INC. warrants this product to be free from defects in materials and workmanship to the original purchaser for a period of 12 months from the original purchase date. Bytech responsibility with regard to this limited warranty shall be limited solely to repair or replacement as its option, of any product which fails during normal consumer use. This warranty does not extend to damage or failure which results from misuse, neglect, accident, alteration, abuse, improper installation or maintenance. At any time during the 12-month period following the purchase, the product fails due to defects in material or workmanship, return the defective product (with freight, prepaid) with proof of purchase. Please include \$5.00 for return shipping and handling.

WWW.BYTECH-INTL.COM

Bytech NY Inc.  
2585 West 133rd Street  
Brooklyn NY 11223  
(718) 449-3700

©2018 BYTECH NY INC.

\*All trademarks and copyrights are the property of the respective companies

MADE IN CHINA

