



SPEAKER



IQ sound[®]

USER MANUAL

PARTY SPEAKER WITH FULL PANEL LED LIGHT

MODEL:IQ-8515DJBT



www.supersonicinc.com

Please read this Instruction manual prior to using this unit.

FEATURES

- Led light show:It is has six light style for showing, it is flashing with rhythm beat.
- Spot light: six pcs LED light on both side of panel
- MEGA BASS design

POWER SUPPLY FOR UNIT

- Connect the signal cables according to the back panel connection instruction.
- To sure the correct the voltage, insert electronic source cable, turn on the power switch button.
- Use On/Off button to switch power ON/OFF on unit.

BACK PANEL FUNCTION INSTRUCTION

- AUDIO OUTPUT:To connect with this jack,the audio signal will be played in another speaker
- Switch for power,and switch for LED
- AC input:AC110V/220V

BLUETOOTH MODE

- Short press “Mode” button to switch between Bluetooth connection/Portable storage device/FM / AUX
- On your smartphone, scan and select IQ-8515DJBT ” to pair.
- Sound quality will depend on quality of your media file or distance of smartphone from speaker
- To control volume Long Press “ VOL- ” (volume down) or “VOL+” (volume up).
- To change tracks Short Press “ ◀◀ ” (Previous Track) or “ ▶▶ ” (Next Track).
- To Pause or Release Pause Short Press “ ▶|| TWS”
- TWS:Press two this model speaeker, then long press this button”  three seconds, it will be in TWS.

PORTABLE STORAGE DEVICE PLAY

- Plug in Portable storage device in the slots provided. Please make sure you use the correct file format in your media devices – MP3 FILES ONLY and correct mode has been selected.
- Short press Mode button to switch between Bluetooth /Portable storage device /FM / AUX. Please ensure that your speaker is fully charged & that your files are MP3 format, or correct source has been selected.
- To control volume Long Press “ VOL- ” (volume down) or “VOL + ” (volume up).
- To change tracks Short Press “ ◀◀ ” (Previous Track) or “ ▶▶ ” (Next Track).
- To Pause or Release Pause Short Press “ ▶|| ”
- Please remember to turn off the power of the Speaker before removing the Portable storage device.

FM RADIO

- Short press “Mode”button to switch between bluetooth / Portable storage device / FM / AUX. And then to press "Play" key to choose FM.Please ensure that your speaker is fully charged & correct source has been selected.
- To control volume Long Press “VOL - ” (volume down) or “ VOL+ ” (volume up).
- Short Press”▶|| “ to Auto Scan and preset available frequencies
- To switch between preset frequencies Short Press “ |◀◀ ” or “ ▶▶| ” .

AUX (LINE IN)

- Plug in external device to Aux jack.
- Short press “Mode”button to switch between Bluetooth / Portable storage device /FM / AUX. Please ensure that your speaker is fully charged & correct source has been selected
- To control volume Long Press “ VOL- ” (volume down) or “VOL+” (volume up).

LIGHT SHOW

- Press the button“FLAMING” on the panel, you can choose the light style as you needed.

It has six kinds of light style for you play. The light can be flash with the music rhythm.

DUAL VOLTAGE

- This model is dual voltage design. AC:110V/220V.
- Factory default:110V

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.