

DigiDragon



DigiDragon

Model:G37

Thank you for purchasing this mobile. For the best performance, we recommend that you read the manual carefully.

CALL CENTER.....	2
MULTIMEDIA.....	3
PHONEBOOK.....	5
MESSAGING.....	6
FILE MANAGER.....	6
SETTINGS.....	7
INTERNET.....	10
FUN.....	11
TOOLS.....	11
CALENDAR.....	11
ALARM.....	11
BLUETOOTH.....	12
CALCULATOR.....	12
STK.....	12
WORLD CLOCK.....	12

Call center

You can view your recent call situation.

[Missed calls]: Show all missed calls list, select a view after a missed call occurred the date and time, phone number and times.

[Dialed calls]: Show all dialed calls list, select a view after a dialed calls occurred in the date and time, phone number and times.

[Received calls]: Show all answered the phone list, select a view after a phone that has the date and time of occurrence, telephone number, frequency

[Rejected calls]: Show all refused to answer the phone list, select a view after a missed call occurred the date and time, phone number and times.

Press the OK softkey to enter the options menu can be more than the number of call records in the following:

- Details: View the current record date, time, type.
- Call: Call the current number
- Save: You can save the current record to the phone or SIM card
 - Write message: send the current record of SMS
 - Add to contacts: the number of the record the name added to the existing record which

Multimedia

Camera

The phone supports photo, so you can capture your favorite scenes anywhere. Photos will be saved in the phone comes with a file system, photographs as JPG format, you can phone provides photographs sent to a computer via USB connection to view, can also be set Image for the standby

Note : This function can work without driver under Windows XP by directly connecting your mobile to the computer

Audio player

Play audio files, MP3 songs; to play audio files, MP3 songs, press the Up and Down keys to adjust the volume, press the left and right keys to select the

present, the next song, press the OK button for the on / off Music

Recorder

[Start recording]: Start recording

[Record file list]: The memory card inside the recording file list

[Storage]: Set the locate of storage

[File format]: Set the format of record file

FM radio

[Auto search and save]: Channel auto search and save

[Channel list]: View channel list

[Save]: Save the channel to the channel list

[Manual search]: Manually enter the channel and find

[Open speaker]: Choose whether to open the microphone

[Background play]: Choose whether to open the Background Play

[Record]: Record the FM

[Timing record]: Set the time to record

[Record file list]: The list of FM record file

[Storage]: Set the location of storage

[Help]: FM Help

Phonebook

You have 2 phonebooks in this mobile phone: SIM card and the mobile. The mobile can store 300 phone numbers and the SIM card's capacity depends on its type.

I In standby mode, enter a number, press the call key pieces to make a call, press the OK key to save

▪ If 'To SIM 1/2' is selected, users can edit name and number.

▪ If 'To phone' is selected, the user can edit the name, mobile number, image, ringtone, caller groups

Into the phone book list, the list on the left displays a small icon indicates that the record exists SIM card or mobile phone, the right is the record of the name and number information.

Standby mode, press the right soft key to enter into the address book or from the menu

Into the address book, do the following:

Messaging

The Messaging function is a network service. Sending and receiving Text can only be used if the service is proposed by your network operator.

You can send ordinary Text messages. The SMS is sent to the Text messages center in the network firstly, and then to the target user. If the receiver's mobile is power off or cannot receive messages, the network will store the message temporarily and the store duration is determined by the user configuration and the service provider.

The message will be directly stored in the SIM card if the capacity is not full. A blinking icon at the head row of the main screen will be displayed if the capacity is full. Messages unread

If the Text message has been sent to the receiver, a beep will sound. (If the tone for Text messages and message report are activated).

File manager

[Memory Card]: SD card needs to support T card

[New folder]: Create a new folder.

[Delete]: delete the specified folder.

[Details]: View the folder or file for more information

[Edit]: The selected folder or rename the file or copy

[Search]: Enter the folder name to find out.

LIMITED WARRANTY PERIOD

The warranty period starts at the time of Product's original purchase by the first end-user. Warranty period for the device and accessories is defined below:-

- a) Twelve (12) months for the mobile device [included in the mobile device sales package]
- b) Six (6) months for the following consumable parts and accessories: batteries, chargers.

Note: This Limited Warranty period will not be extended or renewed or otherwise affected due to subsequent resale, repair and replacement of Product. In the event of repairs of any part/s of the unit, this warranty will thereafter continue and remain in force only till the warranty period applicable from date of purchase.

LIMITED WARRANTY NON-APPLICABILITY

- The completed warranty card is not presented to the service engineer at the time of repairs being undertaken/requested.
- The product purchased is not used in the normal customary manner or not according to instructions given in the Instruction manual or Quick Start Guide, as determined by the company personnel.
- The product is not purchased from an authorized sales dealer.
- The original serial number is removed, obliterated, or altered from the product.
- Defects or damage resulting from misuse, accident, neglect, improper testing operation, maintenance, insulation, alteration, modification, tampering or adjustment.
- Defects or damage caused by viruses from your or from a third party's unauthorized access to services, other accounts, computer systems or networks
- Products rented out or transfer of ownership.
- Operations or damage caused by unauthorized accessories or any other equipment used with the product.
- Without permission of Authorized Local Distributor and/or Service Partner. Non-service personnel or customer himself opening the product without permission of Authorized Distribution and/or Service Partner.
- If the Product has been exposed to moisture, to dampness or to extreme thermal or environmental conditions or to rapid changes in such conditions, to corrosion, to oxidation, to spillage of food or liquid or to influence from chemical products.
- If the product is damaged/broken.

ANY CLAIM UNDER THIS LIMITED WARRANTY IS SUBJECT TO YOU NOTIFYING AUTHORIZED LOCAL DISTRIBUTOR OR ITS AUTHORISED SERVICE CENTRE OF THE ALLEGED DEFECT WITHIN A REASONABLE TIME OF IT HAVING COME TO YOUR ATTENTION BUT NO LATER THAN BEFORE THE EXPIRY OF THE WARRANTY PERIOD.

AUTHORIZED SERVICE NETWORK DETAILS

For information on Service Network, please log on to <http://www.somitech.com.cn/service/mobile>

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, tests for each phone are performed in positions and locations as required by the FCC.

For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 5mm from the body. Non-compliance with the above restrictions may result in violation of RF exposure guidelines.