

The Mask Data - Ant 0 (Nss = 2)

802.11be-EHT20

Channel 117 (6535MHz)




Channel 149 (6695MHz)




Channel 181 (6855MHz)




Channel 185 (6875MHz)



Channel 189 (6895MHz)




Channel 213 (7015MHz)



The Mask Data - Ant 0 (Nss = 2)

802.11be-EHT20


Channel 229 (7095MHz)




The Mask Data - Ant 0 (Nss = 2)

802.11be-EHT40


Channel 3 (5965MHz)



Channel 43 (6165MHz)




Channel 91 (6405MHz)




Channel 99 (6445MHz)



Channel 107 (6485MHz)



Channel 115 (6525MHz)



The Mask Data - Ant 0 (Nss = 2)

802.11be-EHT40


Channel 123 (6565MHz)




Channel 147 (6685MHz)



Channel 179 (6845MHz)




Channel 187 (6885MHz)



Channel 195 (6925MHz)



Channel 211 (7005MHz)



The Mask Data - Ant 0 (Nss = 2)

802.11be-EHT40


Channel 227 (7085MHz)



The Mask Data - Ant 0 (Nss = 2)

802.11be-EHT80


Channel 7 (5985MHz)




Channel 39 (6145MHz)



Channel 87 (6385MHz)



Channel 103 (6465MHz)



Channel 119 (6545MHz)



Channel 135 (6625MHz)



The Mask Data - Ant 0 (Nss = 2)

802.11be-EHT80


Channel 151 (6705MHz)




Channel 167 (6785MHz)




Channel 183 (6865MHz)



Channel 199 (6945MHz)



Channel 215 (7025MHz)



The Mask Data - Ant 0 (Nss = 2)

802.11be-EHT160


Channel 15 (6025MHz)



Channel 47 (6185MHz)



Channel 79 (6345MHz)



Channel 111 (6505MHz)



Channel 143 (6665MHz)



Channel 175 (6825MHz)



The Mask Data - Ant 0 (Nss = 2)

802.11be-EHT160

Channel 207 (6985MHz)



The Mask Data - Ant 0 (Nss = 2)

802.11be-EHT320

Channel 31 (6105MHz)




Channel 63 (6265MHz)



Channel 95 (6425MHz)



Channel 127 (6585MHz)



Channel 159 (6745MHz)



Channel 191 (6905MHz)



The Mask Data - Ant 1 (Nss = 2)

802.11ax-HE20

Channel 1 (5955MHz)




Channel 45 (6175MHz)




Channel 93 (6415MHz)




Channel 97 (6435MHz)



Channel 105 (6475MHz)



Channel 113 (6515MHz)



The Mask Data - Ant 1 (Nss = 2)

802.11ax-HE20

Channel 117 (6535MHz)




Channel 149 (6695MHz)



Channel 181 (6855MHz)




Channel 185 (6875MHz)



Channel 189 (6895MHz)




Channel 213 (7015MHz)



The Mask Data - Ant 1 (Nss = 2)

802.11ax-HE20

Channel 229 (7095MHz)



The Mask Data - Ant 1 (Nss = 2)

802.11ax-HE40

Channel 3 (5965MHz)



Channel 43 (6165MHz)



Channel 91 (6405MHz)



Channel 99 (6445MHz)



Channel 107 (6485MHz)



Channel 115 (6525MHz)



The Mask Data - Ant 1 (Nss = 2)

802.11ax-HE40


Channel 123 (6565MHz)




Channel 147 (6685MHz)



Channel 179 (6845MHz)



Channel 187 (6885MHz)



Channel 195 (6925MHz)



Channel 211 (7005MHz)



The Mask Data - Ant 1 (Nss = 2)

802.11ax-HE40

Channel 227 (7085MHz)



The Mask Data - Ant 1 (Nss = 2)

802.11ax-HE80

Channel 7 (5985MHz)



Channel 39 (6145MHz)



Channel 87 (6385MHz)



Channel 103 (6465MHz)



Channel 119 (6545MHz)



Channel 135 (6625MHz)



The Mask Data - Ant 1 (Nss = 2)

802.11ax-HE80


Channel 151 (6705MHz)



Channel 167 (6785MHz)



Channel 183 (6865MHz)



Channel 199 (6945MHz)




Channel 215 (7025MHz)



The Mask Data - Ant 1 (Nss = 2)

802.11ax-HE160

Channel 15 (6025MHz)



Channel 47 (6185MHz)



Channel 79 (6345MHz)



Channel 111 (6505MHz)



Channel 143 (6665MHz)




Channel 175 (6825MHz)



The Mask Data - Ant 1 (Nss = 2)

802.11ax-HE160


Channel 207 (6985MHz)




The Mask Data - Ant 1 (Nss = 2)

802.11be-EHT20

Channel 1 (5955MHz)




Channel 45 (6175MHz)




Channel 93 (6415MHz)




Channel 97 (6435MHz)



Channel 105 (6475MHz)



Channel 113 (6515MHz)




The Mask Data - Ant 1 (Nss = 2)

802.11be-EHT20

Channel 117 (6535MHz)



Channel 149 (6695MHz)




Channel 181 (6855MHz)



Channel 185 (6875MHz)



Channel 189 (6895MHz)




Channel 213 (7015MHz)



The Mask Data - Ant 1 (Nss = 2)

802.11be-EHT20

Channel 229 (7095MHz)



The Mask Data - Ant 1 (Nss = 2)

802.11be-EHT40


Channel 3 (5965MHz)



Channel 43 (6165MHz)



Channel 91 (6405MHz)



Channel 99 (6445MHz)



Channel 107 (6485MHz)




Channel 115 (6525MHz)



The Mask Data - Ant 1 (Nss = 2)

802.11be-EHT40


Channel 123 (6565MHz)




Channel 147 (6685MHz)



Channel 179 (6845MHz)



Channel 187 (6885MHz)



Channel 195 (6925MHz)



Channel 211 (7005MHz)



The Mask Data - Ant 1 (Nss = 2)

802.11be-EHT40

Channel 227 (7085MHz)

