



1. External Photograph of EUT

Brand Name: Zebra / Model Name: TC510K





Brand Name: Zebra / Model Name: TC510K



**2. Photograph of Accessory****Brand Name: Zebra / Model Name: TC510K**

Specification of Accessory		
Adapter 1 (5V/2.5A)	Brand Name	Zebra
	Model Number	SAWA-65-20005A
Adapter 2 (5V/1.2A)	Brand Name	Zebra
	Model Number	PS000081A01
Headset Jumper 1	Brand Name	Zebra
	Part Number	CBL-TC51-HDST25-01
Headset Jumper 2	Brand Name	Zebra
	Part Number	CBL-TC51-HDST35-01
Battery	Brand Name	Zebra
	Part Number	BT-000314-01
2.5mm Earphone	Brand Name	Zebra
	Part Number	HDST-25MM-PTVP-01
3.5mm Earphone	Brand Name	Zebra
	Part Number	HDST-35MM-PTVP-01
Trigger Handle	Brand Name	Zebra
	Part Number	TRG-TC51-SNP1-01
USB cable	Brand Name	Zebra
	Part Number	CBL-TC51-USB1-01
Soft Holster	Brand Name	Zebra
	Part Number	SG-TC51-HLSTR1-01
Exoskeleton	Brand Name	Zebra
	Part Number	SG-TC51-EX01-01
Hand strap	Brand Name	Zebra
	Part Number	SG-TC51-BHDSTP1-03

Remark: For accessories equipped with this EUT, please refer to the following photos.



Brand Name: Zebra / Model Name: TC510K



Brand Name: Zebra / Model Name: TC510K

Adapter 1 (5V/2.5A)



Brand Name: Zebra / Model Name: TC510K

Adapter 2 (5V/1.2A)





Brand Name: Zebra / Model Name: TC510K

Headset Jumper 1





Brand Name: Zebra / Model Name: TC510K

Headset Jumper 2



[illegible]

Brand Name: Zebra / Model Name: TC510K



Brand Name: Zebra / Model Name: TC510K

2.5mm Earphone



Brand Name: Zebra / Model Name: TC510K


3.5mm Earphone





Brand Name: Zebra / Model Name: TC510K

Trigger Handle





Brand Name: Zebra / Model Name: TC510K



Brand Name: Zebra / Model Name: TC510K

USB cable





Brand Name: Zebra / Model Name: TC510K

Soft Holster





Brand Name: Zebra / Model Name: TC510K





Brand Name: Zebra / Model Name: TC510K

Exoskeleton





Brand Name: Zebra / Model Name: TC510K





Brand Name: Zebra / Model Name: TC510K

Hand strap





Brand Name: Zebra / Model Name: TC510K

