








Band4-5MHz-QPSK-19975-1RB#0-PASS


Band4-5MHz-QPSK-19975-25RB#0-PASS



Band4-5MHz-QPSK-20175-1RB#0-PASS

Band4-5MHz-QPSK-20175-25RB#0-PASS







Band4-5MHz-64QAM-20375-1RB#0-PASS

Band4-5MHz-64QAM-20375-25RB#0-PASS



Band4-5MHz-16QAM-19975-1RB#0-PASS

Band4-5MHz-16QAM-19975-25RB#0-PASS

