


# **Quick Start Guide**

**Start Here**

## Phone overview




### ***Knowing the Keys***

Key	Function
Power Key	<ul style="list-style-type: none"><li>• Press and hold to power on, or power off.</li><li>• Press to turn off or on the screen display.</li><li>• Long Press 10-12 Sec to reboot handset.</li></ul>
Home Key	<ul style="list-style-type: none"><li>• Touch to return to the Home Screen from any application or screen.</li><li>• Touch and hold to open Google app</li></ul>
Menu Key	<ul style="list-style-type: none"><li>• Touch to get the options for the current screen.</li><li>• Touch and hold to switch between recent apps.</li></ul>
Back Key	<ul style="list-style-type: none"><li>• Touch to go to the previous screen.</li></ul>
Volume Up/ Down	<ul style="list-style-type: none"><li>• Press or hold to turn the volume up or down.</li></ul>

## Getting started

1. Please make sure that the phone is powered off before proceeding.

2. Install Micro SIM card



SIM Slot 1: Micro SIM card slot

SIM Slot 2: Mini SIM card slot

Note: 4G LTE works in both SIM Slots individually, but not simultaneously (i.e. One SIM slot works as 4G LTE and other as 2G based on the Data subscription set).

## Screen

Flame 7S features a larger 4 inch with 1280\*720 Resolution which makes your phone look fascinating.

### **Screen lock**

You can increase the security of your phone by selecting screen lock .Screen lock settings can be found under "Settings">"Security"> "Screen lock".

### **Customize home screen**

In standby mode, touch and hold an empty area to add set wallpapers. You can also remove items from the home screen, move items, and add items to home screen to customize the home screen.

### **Camera**

Flame 7S is equipped with 0.3 MP front camera and 5.0 MP rear camera, which are designed for you to share wonderful moments with friends and family.

Exposure, zoom in or zoom out, switch between cameras by flipping the icon on the screen and switch between the functions.

## **Internet**

You can enjoy network by selecting 4G, 3G, WLAN, and GSM. Enjoy music, videos, apps and news anywhere and anytime as you like.

## **Make a call**

You can make a call under the interface of speed dial, recent, contacts (which contains a phone number). In standby mode, press call key to make a call.

## **Messaging**

Touch the text box to select an input method. You can insert smiley, picture, audio or video files and send to single or multiple recipients.

## **Email**

The email app enables you to read, compose and send emails, and is configured to work with all the major service providers. Flame 7S supports multiple account mode and you may not miss any email.

## **Music**

Flame 7S supports various music formats as mp3,m4a,aac,3gp,ogg,wav and mid.

## **Videos**

To enjoy a visual feast in a variety of video formats, please choose Flame 7S. You may trim, mute and share a video. Supports video formats as mpeg4, mp4, 3gp, 3gpp, 3gpp2, webm, avi and mpeg

## **Photos**

You will find it very easy to view all the photos. Flick right or left to move among images. Double-tap or pinch the photo to zoom. You may edit, rotate, crop share, and print a photo. Supports photos formats as bmp, gif, jpg, png and wbmp.

## **Intelligent keyboard**

Flame 7S automatically corrects and suggests words as you type and it also supports pictures and audio input.

## **Cut, copy and paste**

Touch and hold text content to bring up the magnifying glass, and then slide your finger to move the insertion points. Then tap to cut, copy, or paste. It is very easy to copy text from web pages, email or text messages.

## **Map**

You can view satellite images or street map with detailed route instructions just as you are walking in the street. The Map app can be used to locate yourself,



view real-time traffic conditions, pedestrian, bus routes or car driving route instructions.

## Extending Battery Life

Few points, to improve battery life.

- Turn OFF radio services i.e. Wi-Fi, Bluetooth and GPS, when not needed.
- Keep screen brightness on Auto Mode.
- Use Bluetooth tethering or USB tethering (when you have a cable) instead of portable Wi-Fi hotspot to share your phone's data service.
- From the home screen, hold the menu key to close the recent apps running in background.

Note:

Due to non-usage of Phone for long time battery may be drained out and it needs to be connect with charger and allow battery to charge about 30-40 minutes in off state. If still the problem persists, suggested to visit the nearest Device Care Centre.

## Correct disposal

- Do not dispose off your mobile and its battery in fire.
- Do not dispose your mobile with the regular waste.
- For proper disposal please contact [customer care](#).



This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, and USB cable) should not be disposed of with other household waste. This product is RoHS compliant.



This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste.

## Safety information

Read all safety information before using the device to ensure safe and proper use.



### Warning

Following are the warning information provided below to prevent incidents such as fire or explosion

- Do not expose the device to physical impact or damage.
  - Do not carry your device in your back pockets or on your waist.
- Use manufacturer-approved batteries, chargers, accessories, and supplies
- Prevent the multipurpose jack and battery terminals from contacting conductive elements, such as metal or liquids.
- Do not touch the device with wet hands. Also, do not use the device in humid environments, such as rest rooms, or during water-based activities, such as swimming.
- If any part of the device is cracked or broken, or if the device becomes very hot, stop using the device immediately and take it to a Device care Centre.
- Do not turn on or use the device when the battery compartment is exposed

**Following are the warnings below to prevent injury to people or damage to the device**

- Do not allow children or animals to chew or suck the device.

- Do not poke eyes, ears, or other body parts with the device or insert the device into the mouth.
- If the device has a camera flash or light, do not use it close to the eyes of people or animals.
- Do not store your device in very hot or very cold areas. It is recommended to use your device at temperature between 5°C to 35°C.
- Do not store your device near or in heaters, microwaves, cooking equipment, or high pressure containers.
- Keep your device dry.
- Do not use your device outdoor during a thunderstorm.
- Comply with all safety warnings and regulations regarding mobile device usage while operating a vehicle



To prevent possible hearing damage when using a headset, do not listen to sound at high volume for long periods.

## Specific Absorption Rate (SAR) Certification information

**Precautions:**

Use a wireless hands-free system (headphone, headset) with a low power Bluetooth emitter

Make sure the cell phone a low SAR

Keep your calls short or send a text message (SMS) instead. This advice applies especially to children, adolescents and pregnant women.

Use cell-phone when signal quality is good.

**FCC RF Exposure Information and Statement**

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types 4G Smart Phone / (FCC ID: 2ALJJ-PL4002) has also been tested against this SAR limit. SAR information on this and other pad can be viewed on - line at <http://www.fcc.gov/oet/ea/fccid/>. Please use the device FCC ID number for search. This device was

tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

#### **FCC Warning**

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference,
- and (2) this device must accept any interference

received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.